

Atos Unify OpenScape Cordless IP V2

Administrator Documentation

A31003-C1020-M100-07-76A9

Atos

Provide feedback to further optimize this document to edoku@atos.net.

As reseller please address further presales related questions to the responsible presales organization at Unify or at your distributor. For specific technical inquiries you may use the support knowledgebase, raise - if a software support contract is in place - a ticket via our partner portal or contact your distributor.

Our Quality and Environmental Management Systems are implemented according to the requirements of the ISO9001 and ISO14001 standards and are certified by an external certification company.



Copyright © Unify Software and Solutions GmbH & Co. KG 03/2023
All rights reserved.

Reference No.: A31003-C1020-M100-07-76A9

The information provided in this document contains merely general descriptions or characteristics of performance which in case of actual use do not always apply as described or which may change as a result of further development of the products.
An obligation to provide the respective characteristics shall only exist if expressly agreed in the terms of contract.

Availability and technical specifications are subject to change without notice.

Unify, OpenScape, OpenStage and HiPath are registered trademarks of Unify Software and Solutions GmbH & Co. KG. All other company, brand, product and service names are trademarks or registered trademarks of their respective holders.

atos.net

Contents

1 OpenScape Cordless IP V2 – Introduction	7
1.1 Components	7
1.2 The DECT network	9
1.3 OpenScape Cordless IP V2 installations	10
1.3.1 Small and medium installations	10
1.3.2 Large installations	11
1.4 Planning your DECT wireless network	13
2 Antenna hints	15
2.1 Mounting the antennas	15
2.2 Aligning antennas	15
2.3 Third-party antennas	15
2.3.1 Notes on the use of third-party antennas	16
3 First steps	17
3.1 Package content	17
3.2 Preparing to use the telephone system	17
3.3 Mounting the device	18
3.3.1 Connecting to the LAN	19
3.4 Installing the Integrator (large installation)	20
3.5 Defining the device role	20
3.6 Wall mounting	22
4 Operation hints	23
4.1 Light emitting diodes (LED)	23
4.2 DECT manager and base stations	23
4.3 Resetting base stations to factory settings via power procedure	24
4.4 Emergency reset to factory settings	25
5 Configuring the system	27
5.1 The web configurator	27
5.1.1 Starting	27
5.1.2 Logging into/off the web configurator	28
5.1.3 Showing/hiding the navigation menu	29
5.1.4 Help function	29
5.1.5 Applying/discarding changes	29
5.1.6 Working with lists	30
5.1.7 Web configurator menu overview	31
6 Network administration	33
6.1 IP and VLAN settings	33
6.2 Address assignment	34
6.3 VLAN	36
7 DECT manager configuration	37
7.1 DECT manager administration	37
7.1.1 Actions	38
7.2 System log	42
7.3 SNMP statistics	43
7.4 Storing management information in MIB format	43

Contents

7.5	Setting time zone	43
7.6	Blocking calls	44
7.7	Setting up DECT manager redundancy	44
7.8	DECT manager registration	45
7.9	DECT manager synchronisation	47
7.9.1	Actions	48
8	Base stations.	51
8.1	Base stations administration	51
8.1.1	Connected base stations	52
8.1.2	Actions	52
8.1.3	Pending base stations	53
8.2	Base station synchronisation	56
8.2.1	Synchronisation planning	56
8.2.2	DECT-based synchronisation	57
8.2.3	LAN-based synchronisation along the synchronisation path	58
8.2.4	Example scenarios for small/medium systems (single DECT manager clusters)	61
8.2.5	Example scenarios for large systems (multiple DECT manager clusters)	63
8.2.6	List of synchronised base stations	67
8.2.7	Actions	69
9	Provider and PBX profiles	71
9.1	Configuring provider and/or PBX profiles	72
9.1.1	Configuring telephony server profiles	72
9.1.2	General provider data	73
9.1.3	Redundancy settings	74
9.1.4	Failover server	74
9.1.5	Network data of the service provider	75
9.1.6	DTMF over VoIP Connections	76
9.1.7	Settings for codecs	76
9.1.8	Display of caller information	78
9.1.9	Service Codes	79
9.1.10	Deleting the profile	79
10	Mobile devices.	81
10.1	Mobile devices administration	81
10.1.1	Actions	82
10.2	Registering/de-registering handsets	84
10.2.1	Registering handsets	84
10.2.2	Registering a set of handsets	84
10.2.3	Parameters	85
10.2.4	De-registering handsets	86
10.2.5	Settings for the handset	86
10.2.6	Online directories	87
10.2.7	LDAP authentication	88
10.2.8	Network mailbox configuration	89
10.2.9	Group pick-up	89
10.2.10	Call manager	90
10.2.11	Missed calls and alarms	90
10.3	Handset Registration Centre	91
10.3.1	Registering handsets time-controlled	92
11	Telephony settings	95
11.1	General VoIP settings	95

11.2	Security settings	96
11.3	Quality of Service (QoS)	97
11.4	Audio quality	97
11.5	Call settings	98
11.5.1	Call transfer	98
11.5.2	Access Code	99
11.5.3	Area Codes	99
11.5.4	International settings	100
11.5.5	Tone Selection	100
12	Online directories	101
12.1	Corporate online directories (LDAP)	101
12.2	Configuring LDAP directories	102
12.2.1	Configuring a LDAP directory	102
12.2.2	Settings for searching the LDAP database and displaying the result	103
12.3	Attributes	106
12.4	LDAP configuration with Windows Active Directory server	107
12.5	Central phone book	107
13	Online Services	110
13.1	Application-Server	110
13.1.1	Actions	111
14	System settings	113
14.1	Web configurator access rights	113
14.1.1	Changing the web configurator password	113
14.1.2	Enabling CLI access to the device configuration	114
14.2	Loading the web security certificate	116
14.3	Capacity licensing	116
14.4	Provisioning and configuration	118
14.5	Security	119
14.5.1	Certificates	119
14.5.2	HTTP authentication	120
14.6	Date and time	121
14.6.1	Fallback option	121
14.7	Firmware	122
14.7.1	Firmware of the local system	123
14.8	Save and restore	124
14.9	Reboot and reset	126
14.9.1	Manual reboot	126
14.9.2	Reset to factory settings	126
14.10	DECT settings	128
15	Diagnostics and troubleshooting	131
15.1	Status information	131
15.2	Base station events	132
15.2.1	Actions	134
15.3	Incidents	136
15.3.1	Actions	136
15.4	System log and SNMP manager	137
15.4.1	SNMP statistics	138

Contents


16 Diagnostics	140
17 Migration	141
18 Using handset connected to a BSIP2 base	143
18.1 Making calls	143
18.1.1 Calling	143
18.1.2 Dialling from the redial list	144
18.1.3 Initiating ringback	144
18.2 Accepting calls	145
18.2.1 Group pickup	145
18.2.2 Accepting/rejecting call waiting	145
18.3 Conversation with three participants	145
18.3.1 Consultation calls	145
18.3.2 Call swapping	146
18.3.3 Conference	146
18.3.4 Call transfer	146
18.4 Message indication	147
18.5 Using directories	147
18.5.1 Opening directories	147
18.6 Using the network mailbox	148
19 LDAP directory – configuration example	151
19.1 Access to the LDAP server	151
19.2 Filters	153
19.2.1 Filter format	154
19.2.2 Name filter	155
19.2.3 Number filter	155
19.3 Attributes	156
19.3.1 Available attributes on handsets or phones	156
19.3.2 Specifying attributes for display on the phone	156
19.4 Display on the handsets	157
19.4.1 Entries in the directory	157
19.4.2 Searching the directory	158
19.4.3 Displaying a directory entry	158
19.4.4 Dialling a number from the directory	159
Index	164

1 OpenScape Cordless IP V2 – Introduction

OpenScape Cordless IP V2 is a DECT multicell system for connecting DECT base stations to a VoIP Communication System. It combines the options of IP telephony with the use of DECT telephones.

1.1 Components

The following illustration shows the components of the OpenScape Cordless IP V2:



DECT integrator

Central management and configuration unit of the DECT multicell system.

The DECT integrator

- contains the central database for the DECT subscribers and base stations
- provides a web interface for configuring the entire cordless system
- enables access for configuration of all DECT managers and their base stations

DECT manager

Management station for a group of base stations. At least one DECT manager must be used in every installation.

The DECT manager

- manages synchronisation of the base stations within clusters
- acts as an application gateway between SIP and DECT signalling
- controls the media path from the phone system to the relevant base stations

Configuring DECT managers → p. 37

OpenScape Cordless IP V2 – Introduction

Components

DECT base stations

- form the wireless cells of the DECT phone network
- provide media processing from the handsets directly to the phone system
- make available connection channels for the handsets (the number is dependent on various factors, such as bandwidth approved, → p. 13)

Configuring the base stations → p. 51

Handsets

- Many handsets are connected per DECT manager and many DECT calls can be held simultaneously (VoIP calls, and phone book or Info Centre accesses).
- Subscribers can accept or initiate calls in all DECT cells with their handset (**Roaming**), and can also switch between the DECT cells during a call (**Handover**). A handover is only possible when the cells are synchronised.

Configuring handsets → p. 81

Communication System

You can connect your DECT telephone system to a Communication System for VoIP, ISDN or analogue telephony, e.g.,

- OpenScape Business
- OpenScape 4000
- OpenScape Voice


The Communication System Unify Office

- Establishes the connection to a public telephone network
- Enables central management of telephone connections, directories, network mailboxes

1.2 The DECT network

The DECT network comprises the overall radio area of the multicell system in which the users can make and receive calls using their handsets.

A specific DECT manager manages the whole or a part of the DECT network, one DM zone. It can comprise one or more clusters.



Clusters

A cluster defines a set of base stations of a DECT manager that shall synchronise in order to perform handover, roaming and overload balancing for handsets.

Handover A handset switches to a new base station during a call.

Roaming A handset in idle mode is connected to the DECT network via a new base.

Overload balancing A DECT connection (for a call or other administrative or customer purpose) is not set up at the current base station, which is fully loaded with active DECT or media connections, but via a neighbour base station, which has free resources to setup/accept the new DECT connection. Overload balancing is only possible inside a DECT manager zone.

Synchronisation

Handover and overload balancing can only be provided by synchronised base stations.

Base stations follow a common synchronisation source in order to synchronise within a cluster. This could be a base station of the cluster (sync level 1) or a common external synchronisation source (→ p. 56).

One DECT manager manages at least one cluster. In some cases, not all base stations connected to one DECT manager can be synchronised for location specific reasons. To organize synchronisation

OpenScape Cordless IP V2 – Introduction

OpenScape Cordless IP V2 installations

just within a subset of base stations connected to one DECT manager, a DECT manager can form multiple clusters (→ p. 56).


In multiple DECT manager installations, cross-cluster synchronisation is possible via DECT manager synchronisation (→ p. 47).

If the DECT connection between specific base stations seems to be not reliable enough, synchronisation can also take place via LAN (→ p. 58).

1.3 OpenScape Cordless IP V2 installations


Different build levels of the OpenScape Cordless IP V2 can be installed.

1.3.1 Small and medium installations




Small installations

- Integrator, DECT manager and a base station are together at the same device.
- Up to 9 further base stations can be managed.
- Up to 50 handsets can be registered.




Medium installations

- Integrator and DECT manager are together at the same device. No base station is enabled at this device.
- Up to 60 base stations can be managed.
- Up to 250 handsets can be registered.



1.3.2 Large installations



In a large installation the integrator is available as an own system component. An integrator is needed when:


- the system comprises more than 250 handsets
- you need more than 60 DECT base stations
- you want to manage more than one DECT manager via one web-interface
- you want to roam with the DECT handsets between multiple DECT managers/locations

OpenScape Cordless IP V2 – Introduction

OpenScape Cordless IP V2 installations


Virtual integrator

- The integrator is available on a virtual machine.
- Up to 100 DECT managers can be used.
- Per DECT manager up to 60 base stations can be managed, 6000 in total.
- Up to 20000 handsets can be registered.




Device role: Integrator only

- The integrator is located alone at a device. No DECT manager or base station is enabled at this device.
- Up to 4 DECT managers can be used.
- Each DECT manager can manage up to 60 base stations, up to 240 base stations can be managed in total.
- Up to 800 handsets can be registered.



In case of a multi-DECT manager roaming installation, calculate some headroom for roaming visitor handsets. They cannot be load-balanced to other DECT managers.

 Information on how to migrate from a small or medium configuration with one single DECT manager to a multiple DECT manager system → p. 141.

Number of parallel calls depending of device role

Base	10
Base + DECT manager	8
Base + DECT manager + Integrator	5

Number of parallel calls per base station depending on the bandwidth: → p. 77

1.4 Planning your DECT wireless network

Careful planning of your DECT wireless network is the prerequisite for successful operation of the OpenScape Cordless IP V2 with good call quality and adequate call options for all subscribers in all the buildings and areas belonging to the Communication System. When deciding how many base stations are needed, and where these should be positioned, both the requirements for the capacity of the Communication System and its wireless coverage, as well as many ambient conditions, must be taken into consideration.

- ▶ For detailed information on planning your DECT network please refer to the service documentation for OpenScape Cordless IP V2.

OpenScape Cordless IP V2 – Introduction


Planning your DECT wireless network

2 Antenna hints

Devices that are intended to be used as base station should be equipped with the external antennas supplied.

2.1 Mounting the antennas

- ▶ Mount the antennas on the threads on the left and right side of the device.



2.2 Aligning antennas

The movable, alignable antennas make it possible to improve the radiation direction of the DECT signal depending on the mounting orientation of the housing. However, the optimal alignment of the antennas can only be determined by a DECT measurement.

Observe the following notes:

- The strongest radiation from a dipole antenna is at right angles to the dipole.
- This stronger radiation should run directly into the room to be covered.
- This stronger radiation should not be reflected indirectly into the target room via a neighbouring metal surface, because this directivity does not apply to the detection of possibly colliding transmitters and thus this would create an imbalance between transmitter power and receiver sensitivity.

2.3 Third-party antennas

You can also use third-party antennas. They are intended for special tasks and conditions, e.g.:

- in difficult environments: e.g. for mounting outdoors or cold storage, or similar.
- in case of long distances: Use directional antennas that can cover a greater distance and channel DECT radiation to cover the area where DECT is needed more accurately.
- for aesthetic reasons: Use of an unobtrusive external antenna that matches the environment. The base station can then be installed invisibly.
- to increase the DECT range: mounting external antennas in a better position than would be possible with the base station due to spatial conditions, (e.g. distance to LAN connection).

Antenna hints

Third-party antennas

2.3.1 Notes on the use of third-party antennas

In case external antennas are used the site survey and the documentation of the deployment (site survey documentation, installation checklist) has to be done very carefully. Support in case of problems is only possible if a high quality documentation of the system installation is available.

Suitable antennas

A list of recommended external antennas can be found in wiki.unify.com.

- The antenna connection must be of the TNC type.
- Only use antennas of the same type.
- Use the same length of cable on both sides.
- Do not mount one antenna inside and the other outside.
- Be sure to connect two antennas (antenna diversity).

Antenna diversity is one of the strongest means against unwanted reflections in a duplex connection between handset and base. If you connect only one antenna, this remedy is overridden.

Use of directional antennas

- Neighbouring base stations must receive signals from each other to optimise channel selection. Using two neighbouring base stations with directional antennas connected and pointing in different directions can therefore be problematic.

Field strength

- The operation of external antennas must not exceed the legal limits of permissible field strength. Check your regional regulations. If in doubt, you can reduce the transmit power in the Web configurator via the **Reduce TX power by 8dB for external antenna operation** option for this unit (→ p. 55).
- When calculating the total antenna gain, take into account that the coaxial cable causes additional attenuation that must be considered.

Cable

In addition to the antennas, you need pre-assembled coaxial cables with the following characteristics:

- a TNC plug for the DECT base on one side
- on the other side an SMA plug for indoor antennas or an N-standard plug for outdoor antennas (plug depends on the external antenna model)
- Length: 5m - 10m, diameter: 5mm

Make sure you tighten the screws on both sides.

3 First steps

3.1 Package content

- One BSIP2
A device can play different device roles in the OpenScape Cordless IP V2 → p. 10
- Two antennas
- Security leaflet
- Screws and wall plugs for wall mounting



3.2 Preparing to use the telephone system

To use the telephone system the following steps must be performed:

- 1 Perform DECT measurement and site planning
During the planning phase of your DECT network you should have created an installation plan for the DECT managers and base stations.
- 2 Connect the devices to the local network → p. 19
- 3 **In small and media installations:**
Configure one device as Integrator/DECT manager → p. 20
In large installations:
Set-up the virtual machine for the Integrator → p. 20
Configure the DECT manager stations and register them on the Integrator → p. 20
- 4 Mount the devices at the planned locations → p. 22
Note: For each location please note down the MAC address of the device you are going to install.
- 5 Configure the local network settings via web configurator → p. 33
You need a PC connected to the local network, so that you can configure your telephone system via the web configurator.
- 6 Perform a firmware update → p. 123
- 7 In case of a multi-DECT manager installation, register the DECT managers at the Integrator → p. 45

First steps

Mounting the device

- 8 Register the base stations at the DECT manager → p. 51

Note: The base stations will go offline for the duration of firmware update. Further configuration of base stations (step 9) could be done via the Integrator Web-UI (and database). But the base stations cannot learn new settings, until they have finished their offline status in case of a firmware update.

- 9 Configure the base station synchronization → p. 56

- 10 Configure VoIP Communication System or provider → p. 71

- 11 Register handsets and perform handset configuration → p. 81

All the handsets to be used for making calls over the OpenScape Cordless IP V2 must be registered at the telephone system. Any handset must get assigned an individual SIP account at the SIP Communication System. When registering, the handset is permanently assigned a VoIP connection as the receive and send connection.

- Create a backup to save your configuration → p. 113



If you want to migrate from a small or medium configuration with one single DECT manager to a multiple DECT manager system, please read the "Migration" chapter first → p. 141.



Information and support for our products can be found on the Internet at:

<http://www.unify.com/>

Select the product to open the relevant product page for your device, where you will find a link to the user guides.

Technical notes, current information about firmware updates, frequently asked questions and lots more can be found on the Internet at:

<http://wiki.unify.com/>

To find out which version of the Integrator/DECT manager firmware is currently loaded, see → p. 122 and/or (see → p. 131).

3.3 Mounting the device

- When installing the base stations, please take into account the technical conditions for positioning and the installation guidelines, which are described in the "OpenScape Cordless IP V2 - Site

Planning and Measurement Guide".

- Install the base stations at the positions you determined when planning or measuring your DECT wireless network.
- The OpenScope Cordless IP V2 device acting as Integrator/DECT manager can be installed anywhere within the range of the local network. It does not need to be installed in the coverage area of the DECT wireless network. Exception: the device comprising the DECT manager also acts as base station.
- The OpenScope Cordless IP V2 devices are intended for wall mounting (see → p. 22).



The devices are designed for indoor use or for outdoor use, in case it is mounted in an outdoor case.

Indoor use:

- The devices are designed for use in dry rooms with a temperature range of +5°C to +45°C.
- Never expose the devices to heat sources, direct sunlight or other electrical appliances.
- Protect your device from moisture, dust, corrosive liquids and fumes.

Outdoor use:

- Base station protection at ambient temperature between -20°C and +50°C.

3.3.1 Connecting to the LAN



DECT manager and base stations must be connected to the same Ethernet or virtual LAN sharing a common broadcast domain.

If you intend to use DECT-LAN synchronisation, please consider the requirements mentioned in section "LAN-based synchronisation along the synchronisation path"(see → p. 56).

You can connect the OpenScope Cordless IP V2 to your local network via a router, switch, or hub. A VoIP Communication System is required for Internet telephony. This must be accessible via the local network and must have network access (to the Internet and/or the analogue or ISDN telephone network), because DECT manager and base stations do not offer any NAT-traversal support. NAT-traversal support of a Communication System or providers might not provide unlimited support for a multicell system with SIP (DECT manager) and media (base station) traffic transferred via different hosts. Otherwise it will only be possible to make calls within the LAN.

You also need a PC connected to the local network, so that you can configure your telephone system via the web configurator.

For each device to be connected to the local network an Ethernet cable is required.

First steps

Installing the Integrator (large installation)

! The OpenScope Cordless IP V2 is supplied with power via PoE (Power over Ethernet). It must be connected to an Ethernet device with PoE functionality (PoE class IEEE802.3af).



- ▶ Pull up the upper part of the housing and fold it forwards **1**.
- ▶ Insert a plug from an Ethernet cable into the LAN connection socket at the top of the device **2**.
- ▶ Insert the second Ethernet cable plug into a LAN socket for your local network or on the PoE switch **3**.
- ▶ Close the flap.

3.4 Installing the Integrator (large installation)

The virtual integrator appliance is offered as single *.ova file, into which the VM configuration and the virtual disk-images files are compiled.

The virtual integrator is designed for and tested with VMware vSphere ESXi. With its low requirements, the virtual integrator appliance might be supported by many other hypervisor solutions, which are not mentioned here.

! By default, the integrator's IP address is set automatically by the DHCP server of your network. As the Integrator must always be reachable by the DECT managers the IP address should not change. Therefore, in the DHCP server configuration the lease time for the Integrator should be set to unlimited.

The Integrator's short boot menu provides an option which allows you to set a static IP address for initial set-up.

3.5 Defining the device role

On delivery all OpenScope Cordless IP V2 devices are configured as base station. To set up the DECT multicell system at least one device must be configured as **All in one** device. Detailed information on device roles, see → p. 7.

You can use the device button on the front side to change the role of the device. The following settings are possible:

- **Base station**
- **All in one** (integrator/DECT manager/base station) with dynamic IP settings
- **All in one** (integrator/DECT manager/base station) with fixed IP settings
- **DECT manager and base station**

All other roles must be set via the web configurator.

Selecting the role

- ▶ Press the device button for at least 10 seconds until all LED switch off . . . the device is now in programming mode.



Base station:

- ▶ Release the button . . . the right LED lights green.



All in one with dynamic IP settings:

- ▶ Short press the device button until both LED light blue. . . . The IP address will be assigned by a DHCP server in your network.




All in one with fixed IP settings:

- ▶ Short press the device button until the right LED lights blue. . . . The following IP settings are set:
IP address: 192.168.143.1
Subnet 255.255.0.0
mask:



DECT manager and base station:

- ▶ Short press the device button until the left LED lights blue and the right LED lights green.



This role is only needed in combination with a virtual/embedded Integrator.

Saving the selected role

- ▶ The selected role is automatically assigned to the device, when the button is pressed for four seconds . . . both LED light red. The device is reset and rebooted (this can take up to 5 minutes).



When changing the device role the system is reset to factory setting. This means, that existing configuration and user data will be lost.

If you change the role of a device that has been acting as Integrator, you should save the configuration previously (see → p. 113).

If you intend to reset the role from base to base/DECT manager:


Before you switch the device role, previously delete the base at any other system where it was registered before. Otherwise problems may occur because the device might be bound to two concurrent systems.

First steps

Wall mounting

3.6 Wall mounting

BSIP2 is intended for wall mounting. After connecting the LAN cable and setting the device role you can place it to the destined location.



For outdoor use the device can also be mounted in an outdoor case. Detailed information on installing the outdoor case can be found in the "HiPath Cordless IP – Service Documentation".

4 Operation hints

4.1 Light emitting diodes (LED)

Depending on the device role the LEDs on the front side show different operational states. The LEDs can have three different colours (red, blue, green) or can be off.



LED status display for base stations can be disabled. (→ p. 124)

4.2 DECT manager and base stations

LED 1 (left)				LED 2 (right)				Description
0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	
								Power off
								Device is booting
								Firmware update in progress
								No connection to LAN or no IP address available/assigned
								Connecting to DECT manager or no connection to DECT manager

Base station operational states

LED 1 (left)				LED 2 (right)				Description
0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	
								Successful connection to DM, synchronising
								Synchronised, DECT ready
								Synchronised, DECT or RTP traffic
								Synchronised, DECT or RTP overload

Operation hints

Resetting base stations to factory settings via power procedure

DECT manager (without DECT)

LED 1 (left)				LED 2 (right)				Description
0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	
								No DECT base inside active
								System traffic / ongoing calls

DECT manager (with DECT)

LED 1 (left)				LED 2 (right)				Description
0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	0.5 s	
								Not synchronised, DECT ready
								Synchronised, DECT ready
								Synchronised, system traffic, no DECT traffic
								Synchronised, DECT or RTP traffic
								Synchronised, DECT or RTP overload
				Depending on traffic state				Connection to the Integrator lost

4.3 Resetting base stations to factory settings via power procedure

The following describes the procedure to reset base stations to factory settings via power procedure. You can use it, if it is not possible to reset the device

- via the web configurator (→ p. 126), for instance because you have forgotten the password for the web configurator or you are experiencing problems accessing the LAN
- via the key procedure (→ p. 19), for instance because the devices are mounted in places that are difficult to access.



The following procedure only applies to base stations. For DECT manager/Integrator you need to use one of the above procedures.

Resetting the device to factory settings is performed by interrupting the boot process.

- ▶ Remove the power supply from the device (unplug the LAN cable).
- ▶ Replug the LAN cable . . . the reboot starts. If the boot process is not interrupted, the standard reboot is performed.
- ▶ Interrupt the boot procedure after 30 sec. at the earliest and 40 sec. at the latest.
 - Once The device is reset as Integrator/DECT manager with a dynamic IP settings.
 - Three times The device is reset as base station.
 - Five times The device is reset as Integrator/DECT manager with fixed IP settings.



This procedure resets all the settings you have made for the device. The procedure deletes the saved data from the base stations and handsets. The base station's assignment to the DECT manager is cancelled. Ongoing calls are cancelled. In the case of an Integrator/DECT manager the whole configuration is reset.

To enable the restoration of your system configuration after a reset, you should regularly save the configuration data to a file (→ p. 124).

If you intend to reset the role from base to DECT manager/base station, previously delete the base at any other system where it was registered before.

4.4 Emergency reset to factory settings

When the device is booting

- ▶ Press the device button for at least 10 seconds until all LED switch off ▶ release the button . . . the device is now in programming mode.
- ▶ Press the device button until
 - both LED light blue: for Integrator/DECT manager with dynamic IP settings
 - the right LED lights blue: for Integrator/DECT manager with fixed IP settings
 - the right LED lights green: for Base station
 - the left LED lights blue and the right LED lights green: for Base station and DECT manager
- ▶ Press the device button for at least four seconds . . . the device is reset and rebooted.

Operation hints

Emergency reset to factory settings

5 Configuring the system

System settings are made via the web configurator of the OpenScape Cordless IP V2 (→ p. 27) and cannot be changed using the handsets.

This applies in particular for:

- Registering and de-registering the handset to the telephone system, handset name.
- All settings for the VoIP account used by a handset for calls.
- Configuration of online directories.

Handset-specific settings are preset on your handset. You can change these settings.

This applies, for example, for Display settings, such as language, colour, backlight etc.

- Settings relating to ringtones, volume, speaker profiles etc.

Information about this can be found in the user guide for the relevant handset.

5.1 The web configurator

Use the web configurator to set up your OpenScape Cordless IP V2 and configure your DECT network.

- Set up the DECT network, register and synchronise the base stations.
- Make basic settings for the VoIP connections and register and configure the handsets you wish to use in the DECT network.
- Save data required to access specific services on the Internet. These services include access to online directories, as well as synchronising the date/time with a time server.
- Save your DECT network's configuration data as files on your PC and reload these in the event of an error. Upload new firmware, if available, and plan firmware updates at a specific date.

5.1.1 Starting



At least one OpenScape Cordless IP V2 device is installed as Integrator/DECT manager (→ p. 20).

A standard web browser is installed on the PC/tablet.

The device housing the Integrator/DECT manager and the PC/tablet are directly connected to one another in a local network. The settings of any existing firewall installed on your PC allow the PC/tablet and Integrator/DECT manager to communicate with each other.



While you are connected to the web configurator, it is blocked to other users. Simultaneous access is not possible.

- ▶ Launch the web browser on your PC/tablet.
- ▶ Enter the current IP address for the Integrator/DECT manager in the address field of the web browser (for example: `http://192.168.2.10`).

Configuring the system

The web configurator

IP address of the device

If the IP address is assigned dynamically via your local network's DHCP server, you can find the current IP address on the DHCP server in the list of registered DHCP clients. The MAC address can be found on the rear of the device. If necessary, contact the network administrator for your local network.

Your DECT manager's IP address may change occasionally depending on the DHCP server settings (→ p. 33).

5.1.2 Logging into/off the web configurator

Once you have successfully established the connection, the login screen is displayed in the web browser. There are two user roles with different IDs:

admin: has unlimited access to all functions of the web configurator.

user: has only limited access to some settings and system information, e.g., handset registration and some system settings. The **user** role must be activated before it can be used (→ p. 113)

- ▶ Enter **admin** in the **Username** text field.
- ▶ Enter the password in the **Password** text field. Default: **admin**
- ▶ Click on **Login**.

Logging on

You will be asked to change the default password and to set the appropriate radio frequency band.

- ▶ Enter a new password in the **New password** field and repeat it in the **Repeat password** field
 - at least one uppercase
 - at least one number
 - at least one special character
 - from 8 to 74 characters
- ▶ Select the radio frequency band used in your region from the list (→ p. 128)
- ▶ Click on **Set** to save the settings and to open the administrator interface



If you do not make any entries for a lengthy period (approx. 10 minutes), you are automatically logged off. The next time you try to make an entry or open a web page, the login screen is displayed again. Enter the password again to log back in.

Any entries that you did not save on the telephone system before automatic logoff will be lost.

Logging off

You will find the log off function at the top right of each web page, below the product name.

- ▶ Click on 



The session is automatically terminated after ten minutes of inactivity.

Always use the logout function to end the connection to the web configurator. If, for example, you close the web browser without logging off beforehand, access to the web configurator may be blocked for a few minutes.

5.1.3 Showing/hiding the navigation menu

On each web configurator page a side menu on the left allows you to navigate through the available functions. The menu currently used is unfolded and the currently selected menu entry is coloured green.

The navigation menu can be displayed permanently or can be hidden in the case the pointer is moved out of the menu area.

► Use the **Auto-hide menu** check box beneath the menu list to show/hide the menu.



unchecked The navigation menu is shown permanently. (Default)



checked The menu is hidden as soon as you move the pointer out of the menu area. Only the upper menu level symbols are shown on the left.

To redisplay the menu: ► Move the pointer to the area the menu symbols are shown.

5.1.4 Help function

Parameter description

► Click on the question mark next to the parameter for which you need information. A popup window is opened displaying a short description for the selected parameter.

Function description for the entire web configurator page

► Click on the question mark in the upper right corner of the page. The online help is opened in a separate window. It provides information about the functions and tasks that can be performed via this page.

You have access to the total online help:

Browse through the online help: ► Use the ◀ ▶ buttons.

Open the table of contents: ► Click on the ☰ button.

Open the index to search for specific keywords: ► Click on the 🔍 button.

5.1.5 Applying/discarding changes

Applying changes

► Select the **Set** button as soon as you have completed your change on a page . . . the new settings are saved and activated on the DECT manager configuration.

Configuring the system

The web configurator



Changes that have not been saved are lost if you move to another web page or the connection to the web configurator is lost, e.g., due to exceeding the time limit (→ p. 28).

Discarding changes

- ▶ Select the **Cancel** button . . . changes made on the web page are rejected and the settings that are currently saved in the telephone system configuration are reloaded.

5.1.6 Working with lists

Changing the appearance of the list

Filtering the list:

- ▶ Enter a search item (full field content) in the text field . . . Only entries containing text matching the search item in any column are shown in the table.

Filtering the list by column content:

- ▶ In the Search in option menu select the columns which should be searched for the entered search item . . . Only entries containing text matching the search item in the selected column are shown in the table.

Sorting the list:

- ▶ Click on the arrows next to the column header to sort the table on the column content in ascending or descending order.

Displaying/ hiding columns:

- ▶ Names of columns which cannot be hidden are greyed out.

Browsing through the list

- ▶ Click on **Previous** or **Next** to scroll through the list page by page.
- ▶ Click on a specific page number, to go to the desired page directly.

5.1.7 Web configurator menu overview

Menu options that are available also in the DECT managers user interface are highlighted grey. The other options are available only on the Intergrator.

Settings	Network	IP/LAN	→ p. 33
		LAN	→ p. 36
	Base stations	Administration	→ p. 51
		Synchronization	→ p. 56
	Provider or PBX profiles		→ p. 71
	Mobile devices	Administration	→ p. 81
		Registration Center	→ p. 91
	Telephony	VoIP	→ p. 95
		Audio	→ p. 97
		Call settings	→ p. 98
	Online services	Application Servers	→ p. 101
	Online directories	Corporate	→ p. 101
	System	Web configurator	→ p. 113
		Capacity licensing	→ p. 116
		Intergrator Config	→ p. 116
		Provisioning and configuration	→ p. 118
		Security	→ p. 119
		System log	→ p. 137
		Date and time	→ p. 121
		Firmware	→ p. 122
		Save and restore	→ p. 124
		Reboot and reset	→ p. 126
		DECT	→ p. 113
Status	Overview		→ p. 131

Configuring the system

The web configurator

Statistics	Base stations	→ p. 132
	Incidents	→ p. 136



The user role has only restricted access to the user interface. If you login as user, most of the menus entries are hidden.

6 Network administration

6.1 IP and VLAN settings

This page is used to integrate the DECT multicell system into your company's local network. It is available in the Integrator and DECT manager user interface for the user role admin.

► **Settings** ► **Network** ► **IP/LAN**

Device name

Device name in the network ?

int-000c2943a323

Address Assignment

Network type ?

IPv4 ▼

IP address type ?

Dynamic ▼

IP address ?

192.168.250.138

Subnet mask ?

255.255.255.0

Standard gateway ?

192.168.250.53

Preferred DNS ?

192.168.250.53

Alternate DNS ?



If you change the IP address of the device or an error occurs when you are changing the IP settings, the connection to the web User Interface may be lost.

IP address changed: ► Re-establish the connection with the new address.

An error occurred: ► Reset the device to the factory settings.

Defining the device role (→ p. 20)

Device name in the network

► Enter a label for the device. It is used to identify the device in network communication.

6.2 Address assignment

Network type

- ▶ Select the IP protocol used in your local network: Currently only **IPv4** is supported.

IP address type

- ▶ Select **Dynamic**, if your device receives the IP address via a DHCP server.
- ▶ Select **Static**, if you want to assign a fixed IP address to the device.

If the **Dynamic** setting is selected, all further settings are automatically configured. They are displayed and cannot be changed.

If you have selected **Static** as the address type, you must create the following settings.

IP address

- ▶ Enter an IP address for your device. This IP address allows your device to be reached by other subscribers in your local network.

The IP address comprises four individual groups of numbers with decimal values from 0 to 255 that are separated by a dot, e.g., 192.168.2.1.

The IP address must be included in the address block used by the router/gateway for the local network. The valid address block is defined by the IP address for the router/gateway and the **Subnet mask**.



The IP address must be unique across the network, which means that it must not be used by another device connected to the router/gateway.

The fixed IP address must not belong to the address block that is reserved for the DHCP server for the router/gateway.

Check the settings on the router or ask your network administrator.

Subnet mask

The Subnet mask specifies how many parts of an IP address the network prefix must comprise. For example, 255.255.255.0 means that the first three parts of an IP address must be the same for all devices in the network, while the last part is specific to each device. In subnet mask 255.255.0.0, only the first two parts are reserved for the network prefix.

- ▶ Enter the subnet mask that is used by your network.

Standard gateway

The Standard gateway is generally the router/gateway of the local network. Your Integrator/DECT manager device requires this information to be able to access the Internet.

- ▶ Enter the local (private) IP address for the standard gateway through which the local network is connected to the Internet (e.g., 192.168.2.1).

Preferred DNS

DNS (Domain Name System) allows you to assign public IP addresses to symbolic names. The DNS server is required to convert the DNS name into the IP address when a connection is being established to a server.

- ▶ Enter the IP address for the preferred DNS server. You can specify the IP address for your router/gateway here. This forwards address requests from the Integrator/DECT manager to its DNS server. There is no default setting for a DNS server.

Alternate DNS

- ▶ Enter the IP address for the alternate DNS server that should be used in situations where the preferred DNS server cannot be reached.

6.3 VLAN

Details in this page are only required if you connect your phone system to a local network that is divided into virtual subnetworks (VLAN – Virtual Local Area Network). In a tagged VLAN, data packets are assigned to the individual subnetworks via tags (markings) that consist of a VLAN identifier and the VLAN priority, amongst others.

► Settings ► Network ► LAN

VLAN

☐ VLAN tagging ?

VLAN identifier ?

6

VLAN priority ?

6

You will need to save the VLAN identifier and VLAN priority on the phone system configuration. Your VLAN provider will supply you with this data.

VLAN tagging

► Select the check box next to **VLAN tagging**, if you want the phone system to use VLAN tagging.

VLAN identifier

► Enter the VLAN identifier that uniquely identifies the subnetwork. Value range: 1–4094.

VLAN priority

The VLAN priority allows voice data transport to take priority, for example.

► From the option menu select the priority for the phone system data.
Value range: 0–7 (0 = lowest, 7 = highest priority; Default = 6)



Ensure that the details in **VLAN identifier** or **VLAN priority** are set correctly. Incorrect settings can cause problems when connecting the DECT manager for configuration purposes. Internal connections between DECT manager and base stations are not tagged and therefore phone functions are not affected.

If required, you must carry out a hardware reset via power procedure (→ p. 22). This means that all settings are lost.

7 DECT manager configuration

DECT manager configuration is only necessary in large installations with more than one DECT manager. It is only available on the Integrator user interface.

To configure the DECT managers of your multicell system

- Create a list of DECT managers with identifier on the administration page
- Log in to the DECT manager devices and register the DECT managers at the Integrator
- Set up the DECT manager synchronisation, if applicable

7.1 DECT manager administration


The page allows you to manage the DECT managers of your multicell network.

It is only available in the Integrator user interface for the user role admin.

► **Settings** ► **DECT manager** ► **Administration**

DECT managers								
<input type="text" value="Search"/>			<input type="text" value="Search in"/>		<input type="button" value="View"/>			
<input type="checkbox"/>	DM Id	DM Name	RPN Group	IP address	Connection status	Capacity	Bases	Handsets
<input type="checkbox"/>	dm1	DM1	0	192.168.25.11	Connected	Small	4	0
<input type="checkbox"/>	dm2	DM2	1	192.168.25.18	Connected	Small	1	0
<input type="button" value="10 entries"/>								
<input type="button" value="+ Add"/> <input type="button" value="Delete"/>								

The page shows the following information for the DECT managers that are registered at the Integrator:

- DM Id** DECT manager identification within the multicell system.
- DM Name** Name of the DECT manager. It can be edited (→ p. 39).
- RPN Group** Part of the RFPI for a DECT manager. PARI and RPN must be locally unique in order to achieve that the RPN group allocated for the base stations of a DECT manager is locally unique in the system too.
- PMID / TPUI Group** DECT manager specific handset group. It is assigned automatically, when the DECT manager is added to the system.
- PMID (Portable part MAC IDentity) uniquely identifies an active handset connection. Assigned individual TPUI uniquely identifies a handset. Assigned PMID is derived from the assigned TPUI.
- The column is hidden by default.
- IP address** IP address of the DECT manager.
- Click on  to open the web user interface of the related DECT manager.
- Connection status** Shows whether the DECT manager is currently connected to the multicell system or not (**Connected** / **Not connected**).
- Connecting a DECT manager → p. 45

DECT manager configuration

DECT manager administration

Bases	Number of base stations located at this DECT manager.
Handsets	Number of handsets assigned to the DECT manager.
Capacity	<p>The value indicates how many base stations, handsets and calls can be handled by the DECT manager. It depends on the activation of the local base of this DECT manager (→ p. 7).</p> <p>Medium The local base of this DECT manager is deactivated. The capacity is 60 external base stations, 250 handsets, 60 calls.</p> <p>Small The local base of this DECT manager is activated. The capacity is 9 external base stations, 50 handsets, 10 calls.</p> <p>The actual values are shown in the Bases limit, Handsets limit and Calls limit columns.</p>
Bases limit	<p>Maximum number of base stations that are allowed to be assigned to the DECT manager.</p> <p>The column is hidden by default.</p>
Handsets limit	<p>Maximum number of handsets that are allowed to be registered at the DECT manager.</p> <p>The column is hidden by default.</p>
Calls limit	<p>Maximum number of calls that are allowed to be active simultaneously.</p> <p>The column is hidden by default.</p>

7.1.1 Actions

Blocking calls

For each DECT manager you can define a period of time in which all calls are blocked.

- ▶ Mark the check box next to the DECT manager you want to configure. Multiple choice is possible.

Detailed information, see p. 38.

Adding a DECT manager to the list

Before you can integrate OpenScape Cordless IP V2 devices as DECT managers into your multicell system, you first have to create a list of DECT managers on the administration page.

- ▶ Click on **Add** . . . the DECT manager page is opened (→ p. 39).


Deleting a DECT manager from the list

- ▶ Select the check box next to the DECT manager you want to delete. Multiple choice is possible. ▶ Click on **Delete** ▶ Confirm with **Yes** . . . all selected DECT managers are deleted.



Before you delete a DECT manager, first consider what to do with the base stations assigned to it. You could export them in order to import them into another configuration. You could delete them from this DECT manager in advance.

Editing the data of a DECT manager

- ▶ Click on  next to the DECT manager you want to edit . . . the DECT manager configuration page is opened (→ p. 39).

Changing the appearance of the list

Filtering the list:

- ▶ Enter a search item (full field content) in the text field . . . only entries containing text matching the search item in any column are shown in the table.

Filtering the list by column content:

- ▶ In the **Search in** option menu select the columns which should be searched for the entered search item . . . only entries containing text matching the search item in the selected column are shown in the table.

Sorting the list:

- ▶ Click on the arrows next to the column header to sort the table on the column content in ascending or descending order.

Displaying/ hiding columns:

- ▶ Click on the **View** option menu on the right ▶ Select the columns you want to be displayed in the table (👁 / 👁 = displayed/hidden).

Names of columns which cannot be hidden are greyed out.

Adding/editing a DECT manager

On this page you enter the data for a DECT manager to be added to the multicell system or edit the data for a DECT manager that is already assigned to the multicell system.

It is only available in the Integrator user interface for the user role admin.

DECT Manager	
DM Id ?	dm1
DM Name ?	<input type="text" value="DM1"/>
Password ?	<input type="password" value="....."/>
RPN Group ?	<input type="text" value="0"/>
Capacity ?	<input type="text" value="Small"/>

DM Id

DECT manager identification within the multicell system. It is assigned automatically. The identity must be used when registering the DECT manager at the Integrator.

After the DECT manager has been added, you should note this identifier to have it available, when you will have to enter the account data later at the DECT manager.

DECT manager configuration

DECT manager administration

DM Name

The name is used to identify the DECT manager within DECT manager lists.

- ▶ Enter a meaningful name for the DECT manager, e.g., referring to the location or organisational unit.

Password

The password must be entered when registering the DECT manager at the Integrator.

- ▶ Enter a password for DECT manager registration.

You should note this password to have it available, when you will have to enter the account data later at the DECT manager.

RPN Group

Part of the RFPI for a DECT manager. PARI and RPN must be locally unique in order to achieve that the RPN group allocated for the base stations of a DECT manager is locally unique in the system too.

- ▶ Select the RPN group number for the DECT manager from the option menu. Values: 0 – 3

Four RPN groups imply that there are potentially eight neighbours for a DECT manager. Neighbouring DECT managers must not have the same RPN group.

Example:

RPN groups of neighbouring DECT managers		
0	1	0
2	3	2
0	1	0

To ensure, that a handset in 3 cannot see two identical RPN from the left 2 and the right 2 area, it is necessary, that any DECT manager coverage area in any direction is large enough, to provide enough isolation between two DECT manager areas of the same RPN group.

Example: Any handset in 3 should either see base stations from the left 2 or from the right 2, but it must be impossible, that a handset in 3 can see base stations from the left 2 and at the same time from the right 2.

Capacity

Defines the role of the device the DECT manager is located on. The device role has an impact on how many base stations and handsets can be handled by the DECT manager (→ p. 7).

Small Besides the DECT manager the device acts also as a base station. The DECT manager can handle up to 10 base stations and up to 50 handsets.


Medium There is only the DECT manager running on the device. The DECT manager can handle up to 60 base stations and up to 250 handsets.

- ▶ Select the desired device role for the DECT manager.



If you change the device role from **Small** to **Medium** and the local base station was synchronization level 1, it will be deactivated. Base stations synchronization needs to be adjusted in order to re-synchronize the system.

Reboot



The 'Reboot' form contains a section titled 'Reboot of' with a dropdown menu currently set to 'DECT Manager'. Below this is a 'Reboot now' button with a circular arrow icon.


- ▶ From the **Reboot of** option menu select the devices you want to reboot: the **DECT manager** only or the **DECT manager and base stations**.
- ▶ Click on **Reboot now** ▶ Confirm with **Yes** . . . the reboot starts immediately.



All existing connections managed by the affected base stations are terminated.

To reboot one single base station: → p. 54

DECT Manager log



The 'DECT Manager log' form is divided into two main sections: 'System log' and 'SNMP statistics'.
The 'System log' section includes a checkbox for 'Activate system log', a 'Server address' field, a 'Server port' field (pre-filled with '514'), and a 'Use Integrator settings' button.
The 'SNMP statistics' section includes fields for 'SNMP manager address', 'SNMP manager port', 'SNMP username', and 'SNMP password', each with a 'Use Integrator settings' button. At the bottom of this section is a 'Download MIB' button.

DECT manager configuration

System log

7.2 System log

The system report (SysLog) gathers information about selected processes performed by the DECT manager and base stations during operation and sends this to the configured SysLog server.

DECT Manager log

System log

☐ Activate system log ?

Server address ?

Server port ?

514

↩ Use Integrator settings

SNMP statistics

SNMP manager address ?

SNMP manager port ?

SNMP username ?

SNMP password ?

↩ Use Integrator settings

Download MIB

Activate system log

- ▶ Mark/unmark the check box to activate/deactivate the logging function.

Server address

- ▶ Enter the IP address or the (fully qualified) DNS name of your Syslog server. Value: max. 240 characters

Server port

- ▶ Enter the port number, where the Syslog server expects to receive requests.

Range: 1-65535; Default: 514

Transport protocol

- ▶ Select the transport protocol used for communication with the Syslog server.

If you want to use the Integrator's system log server configuration settings for the DECT manager:

- ▶ Click on the **Use Integrator settings** button.



To set up the system log server settings → p. 137.

7.3 SNMP statistics

The Simple Network Management Protocol (SNMP) is a common protocol used for monitoring and controlling of network devices. To gather management and statistical information concerning base station events to be processed by an SNMP manager you have to enter the address and authentication information according to the SNMP server configuration.

- ▶ Enter the IP address of the SNMP manager server in the **SNMP manager address** field and the port number used by the SNMP manager in the **SNMP manager port** field. Default: 162

To access the SNMP database authentication is necessary.

- ▶ Enter the **SNMP username** and the **SNMP password**.
- ▶ Click on **Activate/Deactivate** to start/stop collecting statistical information for SNMP.

The SNMP manager access data can be set for the individual DECT manager or for all DECT managers via Integrator configuration (→ p. 131).

- ▶ If for the DECT manager the Integrator configuration should be used, click on **Use Integrator settings**.

7.4 Storing management information in MIB format

For further processing of the statistic data using a MIB browser (Management Information Base) you can download the data for all base stations of the DECT manager in MIB format (Managed Objects).

- ▶ Click on **Download MIB** ▶ Select the location where the MIB file should be stored using the system file selection dialogue . . . the file with the MIB information is stored in TXT format.

7.5 Setting time zone

- ▶ Select the time zone for your location from the Time Zone option menu.

DECT manager configuration

Blocking calls

7.6 Blocking calls

You can define a period of time in which all calls are blocked by the DECT manager, e.g. for maintenance activities. If a user initiates a call in this time, a message is shown on the handset.

Apply new service period to selected DMs

Service action ?	<div>Block new calls ▼</div>
Start time ?	<div>YYYY-MM-DD HH:mm</div>
	<input type="checkbox"/> Immediately
New calls blocked duration ?	<div><div></div> d</div>
	<div><div></div> h</div>
	<div><div></div> min</div>
	<div><div></div> s</div>

Service action

- ▶ Currently only Block new calls is available. If activated, all incoming and outgoing calls are temporarily blocked. To activate the service, enter a start time and the duration, and click on Set.

Start time

- ▶ Enter the date and time when the call block service should be started. Format: YYYY-MM-DD HH:mm.

or

- ▶ Mark the check box Immediately to start the service at once.


New calls blocked duration

- ▶ Determine how long (days, hours, minutes and seconds) the DECT manager should block all calls.

7.7 Setting up DECT manager redundancy

Only available with a virtual integrator managing multiple DECT managers.

On this page you set up the backup DECT manager as redundancy system for the master DECT manager you have selected on the DECT manager administration page (→ p. 35).

-  The DECT manager redundancy feature only provides redundancy for the DECT manager role, but not for the local base station functions. Therefore on both DECT manager devices the DECT base should be deactivated.

A failover to the backup DECT manager takes place when:

- the backup DECT manager recognizes, that significant majority of base stations are disconnected from the master DECT manager,
- the backup DECT manager recognizes, that significant majority of base stations are connectable to backup DECT manager. (Significant means: $\geq 60\% + 1$ of active base stations),

- this situation continuously lasts for more than 7 minutes. This prevents a failover from taking place during the regular software update duration (6 minutes).

DECT Manager

DM Name ?	dm3-2401
Password ?
Backup for ?	dma-2401-4-sued

The name of the DECT manager for which the backup is set up is shown next to Backup for.

- ▶ In the DM Name field enter the name of the DECT manager to act as a backup system.
- ▶ Enter a password to access the Integrator.
- ▶ Now configure the backup DECT manager with the integrator settings. To do this, use the web configurator of the backup DECT manager.

7.8 DECT manager registration

You can now register the DECT managers at the Integrator.

- ▶ Assign the device role **Base station and DECT manager with dynamic IP settings** to the devices that are defined to act as DECT manager (→ p. 20).
- ▶ Enter the IP address for a DECT manager device in the address field of the web browser and login (→ p. 28).
- ▶ Open the **Settings ▶ System ▶ Integrator Config** page

On this page you can register the DECT manager at the Integrator.

It is only available in the Integrator user interface for the user role admin.

Integrator Config

Integrator IP Address	192.168.25.20
DM Id	dm1
Connection password
Connection status	Connected

Integrator IP Address

- ▶ Determine the IP address of the Integrator (e.g. from the VM software or the DHCP server of your network) and enter the IP address in the field.

DM Id

- ▶ Enter the identifier of the DECT manager as defined in the Integrator's DECT manager administration.

Connection password

DECT manager configuration

DECT manager registration

- ▶ Enter the password that is assigned to the corresponding **DM Id** in the Integrator's DECT manager administration.

Connection status

- ▶ Shows whether the DECT manager is currently connected to the multicell system or not (**Connected** / **Not connected**).

If a DECT manager is successfully registered, the corresponding entry in the Integrator's DECT manager list is supplemented by the IP address (→ p. 37).

7.9 DECT manager synchronisation

This page allows you to configure external synchronisation references for synchronisation clusters of your DECT managers.

It is only available in the Integrator user interface for the user role admin.

This way you could configure inter DECT manager synchronisation rules, to get base stations of multiple DECT managers in sync. Cluster-internal synchronisation is defined via base station synchronisation (→ p. 56).

A cluster can synchronise to a cluster-external source, for example:

- The best base station of another cluster within the same multicell system.
Best means the base station with the strongest radio signal.
- An external DECT system referenced by its RFPI.
RFPI is a unique identifier for a DECT system. You can enter a full matching RFPI to reference a specific base station or a part of an RFPI in order to reference a group of base stations.
- The LAN master of a DECT manager.



Further information on RFPI: → wiki.gigasetpro.com

The page allows you to add, edit and delete the cluster synchronization references.

► Settings ► DECT manager ► Synchronization

DECT manager synchronization			
<input type="text" value="Search"/>		<input type="button" value="Q Search in"/>	
<input type="checkbox"/> DM Name	Cluster	Cluster external sync	Reference
<input type="checkbox"/> DM1	1	No external sync	
<input type="checkbox"/> DM2	2	No external sync	
10 entries			
<input type="button" value="+ Add"/> <input type="button" value="Delete"/>			

The table shows the currently defined synchronisation references with the following information:

DM Name

Name of the DECT manager in the multicell system.

Cluster

Cluster number of the DECT manager to which the synchronisation setting applies.

Cluster external sync

Indicates how the cluster is synchronized:

- No external sync** Level 1 base of the cluster will only synchronise internally.
- Best DECT base of DM** Level 1 base of the cluster will synchronise with the best accessible base station of the DECT manager shown in the **Reference** column, regardless of the cluster.

DECT manager configuration

DECT manager synchronisation

Ext RFPI xxx	Level 1 base of the cluster will synchronise with another DECT system referenced by the RFPI shown in the Reference column. Different RFPI matching levels are possible, e.g., Ext RFPI (full match) , Ext RFPI (-1 match) , Ext RFPI (-2 match) , ...
LAN Master of DM	Level 1 base of the cluster will synchronise with the LAN master of the DECT manager shown in the Reference column.

Reference

Reference to the synchronizing external DECT system. In case of **Best DECT base of DM** and **LAN Master of DM** the DECT manager identifier. In case of **Ext RFPI xxx** the RFPI or a part of an RFPI.

7.9.1 Actions


Adding a synchronization reference to the list

► Click on **Add** . . . the DECT manager synchronization page is opened (→ p. 39).

Deleting a synchronization reference from the list

► Select the check box next to the sync reference you want to delete. Multiple choice is possible. ► Click on **Delete** ► Confirm with **Yes** . . . all selected sync references are deleted.

Editing a synchronization reference

► Click on  next to the DECT manager synchronization you want to edit . . . the DECT manager synchronization page is opened (→ p. 39).

Adding/Editing a synchronization reference

This page allows you to define which DECT device is responsible to synchronize a cluster managed by the DECT manager. You can edit an existing entry of the DECT manager synchronization table or add a new entry.

DM Name

► For a new entry: Select a DECT manager from the option menu.

For an existing entry the identifier is shown.

Cluster

► For a new entry: Select a cluster number of the selected DECT manager. Only one synchronisation reference can be set for a cluster.

For an existing entry: The cluster number of the selected DECT manager is shown.

Cluster external sync

- Select the cluster's synchronisation reference:

No external sync	Level 1 base of the cluster will only synchronise internally.
Best DECT base of DM	Level 1 base of the cluster will synchronise with the best accessible base station of the DECT manager. The DECT manager must be selected from the Reference option menu.
Ext RFPI xxx	Level 1 base of the cluster will synchronise with another DECT system. Different RFPI matching levels are possible. Ext RFPI (full match) All bits of the RFPI are considered, i.e., one specific DECT system is referenced Ext RFPI (-1 match) -1 match : the last bit of the RFPI is ignored. Ext RFPI (-2 match) -2 match : the last two bits are ignored The RFPI or a part of an RFPI must be entered in the Reference text field. Matching base stations are used to synchronise.
LAN Master of DM	Level 1 base of the cluster will synchronise with the LAN master of the DECT manager. The DECT manager must be selected from the Reference option menu.

Reference

In case of **Best DECT base of DM** and **LAN Master of DM**:

- From the **Reference** option menu select the DECT manager.

In case of **Ext RFPI xxx**:

- In the **Reference** field enter the RFPI or the part of the RFPI of the base station(s) to which the cluster can be synchronised.

DECT manager configuration

DECT manager synchronisation

8 Base stations

The Integrator/DECT manager automatically recognises the base stations within the network. Base stations need to be confirmed, activated and synchronised.

The menu is only available in the Integrator user interface.

8.1 Base stations administration

This page allows you to assign base stations to the DECT managers.

It is only available in the Integrator user interface for the user role admin.

Use the following web configurator page to assign base stations to the DECT manager.

Settings ► Base stations ► Administration Use the following web configurator page to assign base stations to the DECT managers.

✕ **Settings ► Base stations ► Administration**

Connected base stations

☐ Match whole word

<input type="checkbox"/> MAC address	Base station	RPN	DM Name	FW	Status
<input type="checkbox"/> 7c2f80c6e273	LocalBS	0x2	DM2	V2R2.48.0 (V2.48.0+build.4fa8a54)	Sync
<input type="checkbox"/> 7c2f80c6e5cd	LocalBS	0x2	DM1	V2R2.48.0 (V2.48.0+build.4fa8a54)	Sync
<input type="checkbox"/> 7c2f80e0d639	BS 7c2f80e0d639	0x3	DM1	V2R2.48.0 (V2.48.0+build.4fa8a54)	Sync
<input type="checkbox"/> 7c2f80e0d670	BS 7c2f80e0d670	0x4	DM1	V2R2.48.0 (V2.48.0+build.4fa8a54)	No sync

LED Signalling on Base Stations

Activate signalling of base station status
 ☒ Yes
 ☐ No

Pending base stations

☐ Match whole word

MAC address	DM Name
<input checked="" type="checkbox"/> 7c2f80e0d68b	DM1

There are two tables:




- **Connected base stations** lists all base stations which are already connected to the DECT manager.
- **Pending base stations** lists all base stations which are not yet connected to a DECT manager.

Base stations

Base stations administration


8.1.1 Connected base stations

The page shows the connected base stations with the following information:


MAC address	Hardware address of the base station. With this address the device is uniquely identified within the LAN.										
Base station	Name of the base station. When added to the list the MAC address is used as name. The base station located at the same device as the DECT manager is shown as LocalBS . The symbol  indicates that the base station function is disrupted. The name can be edited (→ p. 54)										
RPN	(Radio Fixed Part Number) Part of the RFPI. Identifies the base station on the air interface. It also enumerates the base station within a DECT manager. Each DECT manager gets a group of RPN to assign to its base stations. So it is possible to identify the DECT manager the base station belongs to.										
DM Name	Name of DECT manager the base station belongs to. The symbol  indicates that the base station function is disrupted										
FW	Version of the currently installed firmware. The turning symbol  indicates that currently a firmware update is in progress.										
Status	Synchronization status of the base station: <table><tr><td>Offline</td><td>Not available</td></tr><tr><td>Deactivated</td><td>Available but not activated</td></tr><tr><td>No Sync</td><td>Activated but not synchronised</td></tr><tr><td>Sync</td><td>Activated and synchronised,</td></tr><tr><td>Sync overload</td><td>Synchronised but DECT overload; attempts were made at this base station to initiate more than the permitted simultaneous calls.</td></tr></table>	Offline	Not available	Deactivated	Available but not activated	No Sync	Activated but not synchronised	Sync	Activated and synchronised,	Sync overload	Synchronised but DECT overload; attempts were made at this base station to initiate more than the permitted simultaneous calls.
Offline	Not available										
Deactivated	Available but not activated										
No Sync	Activated but not synchronised										
Sync	Activated and synchronised,										
Sync overload	Synchronised but DECT overload; attempts were made at this base station to initiate more than the permitted simultaneous calls.										

8.1.2 Actions

Editing base station data

- ▶ Click on  next to the base station you want to edit . . . the data page for the base station is opened (→ p. 54).

Displaying detailed statistical data on the base stations

- ▶ Click on the  button next to the name of a base station . . . statistical evaluations about the base station synchronisation as well as further system information are output.

Deleting base station

- ▶ Select the check box of one or more base stations ▶ Click on **Delete** ▶ Confirm with **Yes** . . . All selected base stations are deleted. They are shown in the list of pending base stations again.

Exporting/Importing the base station configuration

You can export the base station configuration and import it into another DECT manager, in order to change the DECT manager assignment.

Exporting:

- ▶ Select all base stations you want to be transferred via the check mark next to the MAC address.
- ▶ Click on **Export** ▶ Select the location where the export file should be stored using the system file selection dialogue.

Preferably, you want to export and import base stations DECT manager by DECT manager:

- ▶ Filter the base station list by **DM Name**. So you can easily export base stations of this specific DECT manager.

Importing:

- ▶ Click on **Import** ▶ Select the previously exported base station configuration file from your computer's file system.
- ▶ Select the DECT manager into which base station export should be imported from the **DM Name** list and the **IP address type** from the corresponding list.
- ▶ Click on **Import**.



The export contains all data. The import does not contain the data of the local base station, because the local base station is physically bound to the (potential) new DECT manager.

Please review your sync settings after a base station import.

Enabling/Disabling LED status display at the base station

LED displays are enabled by default on all base stations.

- ▶ Select **Yes/No** to enable/disable the LED display on all base stations.

8.1.3 Pending base stations

The **Pending base stations** list shows the automatically recognised DECT base stations in the network that have not yet been registered. If a base station is detected by several DECT managers, there are several entries for one base station. To integrate them into your DECT multicell system, they need to be confirmed and activated.

The base stations are identified by their MAC address.

You can filter the list of pending base stations by specific DECT managers to get the list shorter and to add the base stations DECT manager by DECT manager.

Assigning a base stations to your DECT manager

- ▶ Click on ☒ in the row of the base station you want to add to your system . . . the data page for the base station is opened.



The relation to a DECT manager cannot be edited and changed. To assign a base station to another DECT manager:

- ▶ Delete it from the **Connected base stations** list.. .The base station is displayed again in the **Pending base stations** list, with one entry for each DECT manager that is detecting it on the DECT network
- ▶ Select the base station entry of the desired DECT manager and add it to the system.

Base stations

Base stations administration

Adding/Editing base stations

On this page you enter the data for a base station to be added to the DECT manager or edit the data for a base station that is already assigned to the DECT manager.

It is only available in the Integrator user interface for the user role admin.

Own Base Station Data

MAC address ?	7c2f80c6e273
Name / Location ?	LocalBS
DECT manager ?	local
Status ?	Sync
IP address type ?	Dynamic
IP address ?	192.168.250.168
	To change network settings for local base station go to IP configuration page.
RFPI = PARI + RPN (hex) ?	102D95AF 0x2
Current firmware version ?	V2R0.13.0 (V1.13.0+build.34a799c)
Reduce TX power by 8dB for external antenna operation ?	<input type="radio"/> Yes <input checked="" type="radio"/> No
Activate base station ?	<input checked="" type="radio"/> Yes <input type="radio"/> No
	<input type="button" value="Delete base station"/>
	<input type="button" value="Reboot base station"/>
	<input type="button" value="Set"/> <input type="button" value="Cancel"/>

The following information is displayed and cannot be changed:

MAC address

Hardware address of the base station. With this address the device can be uniquely identified within the Ethernet. It cannot be changed

DM Name

Name of DECT manager the base station belongs to.**local**: The base station belongs to the configuring device.

Status

Synchronization status of the base station:

Offline	Not available
Deactivated	Available, but not activated
No sync	Activated, but not synchronised
Sync	Activated and synchronised
Sync overload	Synchronised, but DECT overload

IP address

Current IP address of the Base station.

RFPI = PARI + RPN (hex)

(RFPI = Radio Fixed Part Identity) unique name of the base station in a multicell DECT network. It consists of:

- PARI (Primary Access Rights Identity): unique system ID of a base station
- RPN (Radio Fixed Part Number): base station number within the DECT network
The two most significant bits in the RPN represent the RPN group of the DECT manager.

Current firmware version

Firmware version currently installed.

The following data can be edited

Name / Location

This name should make it easier to assign the base station within the logical and spatial structure of the DECT network.

- In the text field enter a descriptive name or description for the base station. Value: max. 32 characters

IP address type

The IP address type is copied from the setting for the DECT manager on the **Network – IP/LAN** page (→ p. 33). You can change the IP address type. The settings for the DECT manager and the base stations do not have to match. For example, the DECT manager could receive a fixed IP address so that it will always be able to access the web configurator with the same address, while the base stations receive their IP addresses dynamically.

- Select the desired IP address type from the option menu.

If the IP address type is **Static**, you have to enter the IP address.

IP address

- Enter an IP address for the base station.

Reduce TX power by 8dB for external antenna operation

The transmitting power of the external antennas can be reduced. This may be needed in order not to violate emission regulations, in case the device is equipped with external antennas (→ p. 23).

- Click on **Yes/No** to reduce/not reduce the transmitting power by 8 dB.

Base stations

Base station synchronisation

Activating/deactivating the base station

A base station must be active to manage the calls of the connected handsets. If it is deactivated, it will no longer connect handsets but it still stays in the list of connected base stations.

- ▶ Select **Yes/No** to activate/deactivate the base station.



Please ensure that the base station you want to deactivate is not on sync level 1. Check your sync settings before deactivating a base station. Otherwise your system may no longer work properly

Adding a base station to the Connected Base Stations list

- ▶ Click on **Confirm**

Delete the base station

- ▶ Click on **Delete base station** ▶ Confirm with **Yes** . . . the base station is deleted. It is shown in the list of pending base stations again.

Reboot the base station

- ▶ Click on **Reboot base station** ▶ Confirm with **Yes** . . . the base station is rebooted. All existing connections managed by the base station are terminated.

8.2 Base station synchronisation

Synchronisation and the logical structuring of the base stations in clusters are prerequisites for the functioning of the multicell system, intercell handover, and (over)load balancing. Overload balancing means that a handset can roam to a free base, when current base is fully loaded and cannot accept further handset connections.

Base stations can be synchronised "over the air", meaning that they are synchronised via DECT. If the DECT connection between specific base stations seems to be not reliable enough, synchronisation can also take place via LAN. To carry out the synchronisation you will need the plan of the clusters with the synchronisation level for each base station.



Synchronisation always refers to a cluster. In case you set up several clusters that are not synchronised with one another, there will be no possibility of a handover or (over)load balancing between them.

Synchronisation for handover between base stations in clusters managed by different DECT managers can be configured via DECT manager administration

For detailed information on DECT network planning, please refer to the "HiPath Cordless IP – Service Documentation".



A base station shows its synchronisation status with an LED (→ p. 23).

8.2.1 Synchronisation planning

Base stations that combine to form a DECT wireless network must synchronise with one another to ensure a smooth transition of the handsets from cell to cell (handover). No handover and no (over)load balancing is possible between cells that are not synchronised. In the event of loss of synchronisation, the base station stops accepting calls once all ongoing calls that were being conducted on

the asynchronous base station have ended and then it re-synchronises the asynchronous base station.

The synchronisation within a cluster takes place in a master/slave procedure. This means that one base station (sync master) defines the synchronisation cycle for one or more other base stations (sync slaves).

The synchronisation needs a some kind synchronisation hierarchy with the following criteria:

- 1 There must be one single and common root source for the synchronisation in the hierarchy (sync level 1).
- 2 With synchronisation over LAN there are just two levels needed (LAN-Master and LAN-Slave).
- 3 DECT synchronisation usually needs more than two levels and just one hop, because most base stations won't be able to receive the DECT signal from the root source of the synchronisation (sync level 1). DECT signal providing reference timer synchronisation is relayed along a chain of multiple base stations, until it finally synchronises the last base station in a sync chain.
- 4 The number of hops along any branch of DECT synchronisation tree should be minimised, because any hop can introduce jitter in the synchronisation timer and could so lower the quality of the synchronisation.

Requirements for synchronisation

- The BSIP2 devices must be connected to an 100 Mbit/s switch port with corresponding cabling. The switch port must support
 - multicast/broadcast messages,
 - PoE IEEE 802.3af < 3.8 W (Class 1),
 - VLAN tagging.
- It is recommended to disconnect VLAN from other network devices.
- It is recommended to activate Quality of Service mechanisms.
- The DECT manager and all base stations must be in the same layer 2 segment

8.2.2 DECT-based synchronisation

To relay DECT synchronisation signals from base station A to base station B, base station B must be able to receive signals from base station A with sufficient signal quality.



DECT manager and base stations must be connected to the same Ethernet or virtual LAN sharing a common broadcast domain.

A base station can synchronise with each base station on a higher sync level. The sync level concept allows base stations to automatically select the best suitable base station (having a lower sync level number) to receive synchronisation signal from. Simultaneously, it guarantees a strictly limited number of hops along any branch in the synchronisation tree and to prevent circles between automatically optimised synchronisation chains.

During configuration, assign one level in the synchronisation hierarchy (sync level) to each base station. Sync level 1 is the highest level; this is the level of the sync master and appears only once in each cluster. A base station always synchronises itself with a base station that has a better sync level. If it sees several base stations with a better sync level, it synchronises itself with the base station that provides the best signal quality. If it does not see any base station with a higher sync level, it cannot synchronise.

Base stations

Base station synchronisation

8.2.3 LAN-based synchronisation along the synchronisation path

If the DECT connection between base stations seems to be not reliable enough to permanently guarantee a stable DECT over the air synchronization, e.g., because they are separated by iron doors or a firewall, you can determine that synchronisation should take place via LAN. In this case the base station with the higher sync level will act as LAN master, the base station with the lower sync level is a LAN slave. One base station must be explicitly be defined as LAN master. This should not be the device on which the DECT Manager is also located.

Advantages of LAN synchronisation compared with DECT synchronisation:

- Higher flexibility in the arrangement of the base stations as no synchronisation chains need to be formed.
- Fewer base stations required as the overlapping area of the base stations is smaller. The overlapping area for handset handover can be smaller, because neighboured base stations do not need to receive each other in stable error free quality, but they must still be able to detect each other for the process of dynamic channel selection.
- Configuration of the system is simplified as all base stations can be synchronised on one synchronization master.

Network requirements

- The OpenScape Cordless IP V2 devices must be connected to a switch port of minimum 100 Mbit/s with corresponding cabling.
- The DECT manager and all its base stations must be in the same layer 2 segment (common broadcast domain).

Requirements for LAN synchronisation

- Minimum number of switch hops between master and all slave base stations.
- For internally and uplink switching use Enterprise class switches $\geq 1\text{Gbit/s}$.
- VLAN based QoS could be fruitful to minimise packet delay and its jitter. Switch port based VLAN can isolate base stations from other devices' traffic.
- DSCP (Differentiated Services Codepoint) based QoS could be even more efficient.

Settings for DSCP tagging:

Sync via LAN: PTPv2, DLS (proprietary):
DSCP=CS7=56

RTP: DSCP=EF=46

SIP: DSCP=AF31=26

- Synchronisation via LAN makes intensive use of IP multicasts which have to be supported by the switches.

- Multicast destination address and ports:
PTPv2: 224.0.1.129 UDP via ports 319/320
Proprietary DLS 239.0.0.37 UDP via ports 21045/21046
protocol:

Cascaded switches might need uplink switching of these multicast packets to allow interswitch LAN synchronisation. Otherwise you need isolated LAN-sync clusters, inter-clustersynchronized via DECT.

- IGMP snooping is supported and shall be supported by the switch, to configure and minimise multicast distribution only to the LAN synchronising base stations.

Packet delay jitter

Minimum packet delay jitter between LAN master and LAN slaves is crucial for successful synchronisation over LAN.

- LAN master role should be assigned to that switch port, that offers the lowest packet jitter to all LAN-Slaves.
- If there are several suitable devices, the LAN master role should be assigned to a device that has little traffic.

This is preferably a base station with low VoIP traffic. If in doubt, you can even deactivate DECT at the base station and operate the base station only as LAN master. As a rule, however, this is not necessary.

Devices that include the DECT manager (and the integrator) in addition to the base station are not recommended as LAN masters due to the variety of tasks and traffic to be served. This applies to devices with medium capacity if DECT is deactivated for the base station. The performance advantage thus gained is easily consumed by the DECT manager and integrator functions.

As multiple LAN traffic parameters could have an impact on packet delay and its jitter, specific switches and maximum number of switch hops are required, to guarantee sufficient maximum packet delay jitter.

Consider the following:

- The less switch hops, the lower the transmission delay and its jitter will be.
- The higher the bandwidth or quality of used switches is regarding packet delay and its jitter, the lower the packet delay and the lower the packet delay jitter will be.
- Enhanced packet processing logics (like L3 switching or packet inspection) could have significant negative impact on the resulting packet delay jitter. If possible, they should be deactivated for OpenScape Cordless IP V2 base stations connected switch ports.
- Significantly increased traffic load on a switch, in the range of the maximum throughput, could have significant negative impact on the packet delay jitter.
- VLAN based prioritisation of LAN packets could be a fruitful measure to minimize packet delay and its jitter for OpenScape Cordless IP V2 base stations.

Acceptable Network Jitter for LAN-synchronisation

LAN synchronisation is based on a two layer design:

Base stations

Base station synchronisation

- Native PTPv2 is used to synchronise a common reference timer along all base stations involved.

Target quality benchmark to provide sufficient PTP synchronisation along the base stations, is to have a PTP deviation lower than 500 ns (rms). For this PTP synchronisation a few single deviations > 500 ns are accepted and might just generate first warnings. If the PTP sync packet deviation does continuously exceed this limit of 500 ns, the PTP synchronisation is considered broken and will lead to new start synchronisation procedure.

- Based on the PTP synchronisation LAN master and LAN slave adjust their DECT reference timer to one common offset to the common PTP reference timer. This common offset will be permanently monitored by a proprietary communication.

The target quality benchmark for this synchronisation level is to see reference timer deviation by this DECT reference timer sync packets: DECT-LAN-Sync deviation lower than 1000 ns. A good mean value would be 500 ns (rms).

To meet this criteria the switches themselves do not necessarily need to be PTP aware. But the network should consider the above mentioned guidelines to meet this criteria.

Cluster selective LAN synchronisation

LAN synchronisation consists of two layers:

- Standard PTP which is shared within a multicast IP domain between all DECT managers
- Proprietary DLS (DECT over LAN Sync) which synchronises the clusters isolated within one DECT manager

Multiple DLS domains are possible per DECT manager as DECT manager clusters. A cluster forming an isolated PTP domain needs to have one LAN master of its own. Maximum one LAN master is allowed per cluster.

DLS sync master and slave do care for matching DECT manager and cluster numbers.

Cluster numbers

For LAN synchronisation a cluster needs to be assigned to a PTP domain. This assignment takes place via the cluster number.

Cluster numbers from 1-c to 7-c Build up one **common** PTP
(c = common) sync domain

Clusters numbers 8-i to 15-i (i = Build up an **isolated** PTP sync
isolated) domain per each such cluster
number

- Inter-DM-LAN sync is only possible with matching cluster number (independent from the PTP domain).
- DECT managers forming one common LAN synchronisation domain need to use a cluster number from common domain (1..7) or an identical cluster number of isolated domain (8..15).
- DECT managers using different PTP domains (cluster numbers 8.15) cannot be synchronised by inter-DECT manager LAN synchronisation rule (Reference=**LAN Master of DM x**), but only by inter-DM DECT synchronisation rule.


The mentioned PTP domain in aspect of cluster numbers is only relevant for LAN master and LAN slave base stations. For DECT synchronisation, cluster numbers do not have any additional relevance beside just identifying different clusters.

8.2.4 Example scenarios for small/medium systems (single DECT manager clusters)

Synchronisation for handovers between base stations in clusters managed by one DECT manager are configured via the base station administration using the web configurator. Below are some example scenarios.

Scenario 1: Pure DECT

- Your environment ensures a stable DECT over the air synchronisation
- Cluster 1-c is created to insure handover, roaming and load balancing
- The base station in the centre is DECT level 1 to reduce the amount of sync levels
- Environment blocks DECT signal (e.g., a passage through a fire door)
- Second cluster 2-c is created to cover the area that can't be reached by cluster 1-c
- No handover (active calls are disconnected when switch over between clusters)
- Roaming between clusters is possible (handsets in idle mode can switch between clusters)



Configuration:


Base station	Cluster	Sync Level	LAN Master	Sync Slave
1	1-c	3		DECT
2	1-c	2		DECT
3	1-c	2		DECT
4	1-c	1		DECT
5	1-c	2		
6	1-c	3		DECT
7	2-c	1		DECT
8	2-c	2		DECT

Base stations

Base station synchronisation

Scenario 2: Pure LAN

- Use such a configuration, if all requirements for LAN synchronisation are fulfilled
- Cluster 1-c is created to insure handover, roaming and load balancing
- Base 4 is configured as LAN master
- DECT level has no relevance for pure LAN synchronisation
- Handover and roaming is possible within the whole DECT environment
- That LAN sync is used, does not mean that DECT signal range is not important




Configuration:

Base station	Cluster	Sync Level	LAN Master	Sync Slave
1	1-c	2		LAN
2	1-c	2		LAN
3	1-c	2		LAN
4	1-c	1	<input checked="" type="checkbox"/>	
5	1-c	2		LAN
6	1-c	2		LAN
7	1-c	2		LAN
8	1-c	2		LAN

Scenario 3: DECT-LAN mixed

- Use such a configuration, if your environment is mainly able to synchronise via DECT but there are particular circumstances which cannot always guarantee reliable DECT synchronisation, e.g., a passage through a fire door
- Cluster 1-c is created to insure handover, roaming and load balancing
- Base station 1 in the centre is DECT level 1 to reduce the amount of sync levels
- Base 1 with DECT level 1 is configured as LAN master
- For each base lower than the LAN master you can individually decide whether it should be synchronised via DECT or LAN
- Base 7 is synchronised via LAN and has DECT sync level 4
- Base 8 is synchronised via DECT and will synchronise with Base 7 via DECT, therefore the DECT sync level 5



Configuration:

Base station	Cluster	Sync Level	LAN Master	Sync Slave
1	1-c	1	<input checked="" type="checkbox"/>	
2	1-c	2		DECT
3	1-c	2		DECT
4	1-c	3		DECT
5	1-c	2		DECT
6	1-c	3		DECT
7	1-c	4		LAN
8	1-c	5		DECT

8.2.5 Example scenarios for large systems (multiple DECT manager clusters)

Synchronisation for handovers between base stations in clusters managed by different DECT managers are configured via the DECT manager administration using the web configurator. Below are some examples based on two DECT managers. Detailed information on configuration can be found in the OpenScape Cordless IP V2 - Administrator Documentation.

Scenario 1: DECT – DECT – DECT

- Integrator (virtual or embedded)
- Two devices with role of DECT manager only
- Every DECT manager has two DECT base stations
- Cluster 1-c on the left side uses DECT synchronisation

Base stations

Base station synchronisation


- Cluster 1-c on the right side uses DECT synchronisation too (even if the name is the same, it is a different cluster as it is part of another DECT manager)
- Between the clusters also DECT synchronisation is used

Advantage:

- Users can move within the system with handover and roaming.
- DECT synchronisation, no network requirements for LAN sync.

Attention:

- Enough DECT signal quality should be available within the complete system, also between the clusters.
- Every DECT manager must have a different RPN group.



Configuration:

Base station	DM Name	Cluster	Sync Level	LAN Master	Sync Slave
DECT_Left_A	DM_Left	1-c	1		
DECT_Left_B	DM_Left	1-c	2		DECT
DECT_Right_A	DM_Right	1-c	1		
DECT_Right_B	DM_Right	1-c	2		DECT

Scenario 2: DECT – DECT – LAN


- Integrator (virtual or embedded)
- Two devices with role of DECT manager only
- Every DECT manager has two DECT base stations
- Cluster 1-c on the left side uses DECT synchronisation
- Cluster 1-c on the right side uses DECT synchronisation too (even if the name is the same, it is a different cluster as it is part of another DECT manager)
- Between the clusters LAN synchronisation is used
- Base station **DECT_Left_A** is the PTP source (LAN master)

Advantage:

- Users can move within the system with handover and roaming.
- Synchronisation between the two clusters was not possible due to DECT signal range was not enough. LAN sync is the solution.

Attention:

- The customer network between the clusters must be capable to be used for LAN synchronisation. This needs more configuration in the customer network then using DECT synchronisation.



Base stations

Base station synchronisation

Configuration:

Base station	DM Name	Cluster	Sync Level	LAN Master	Sync Slave
DECT_Left_A	DM_Left	1-c	1	<input checked="" type="checkbox"/>	
DECT_Left_B	DM_Left	1-c	2		DECT
DECT_Right_A	DM_Right	1-c	1		
DECT_Right_B	DM_Right	1-c	2		DECT

Scenario 3: LAN – LAN with isolated PTP domain – DECT


- Integrator (virtual or embedded)
- Two devices with role of DECT manager only
- Every DECT manager has two DECT base stations
- Cluster 1-c on the left side uses LAN synchronisation
- Cluster 8-i on the right side uses LAN synchronisation (cluster 8-i is the first isolated cluster)
- Between the clusters DECT synchronisation is used
- DECT base **Left A** is the PTP source for cluster 1-c
- DECT base **Right A** is the PTP source for cluster 8-i

Advantage:

- Users can move within the system with handover and roaming.

Attention:

- The customer network must be capable to be used for LAN synchronisation. This needs more configuration in the customer network than using DECT synchronisation.
- Every DECT manager must have a different RPN group.



Configuration:

Base station	DM Name	Cluster	Sync Level	LAN Master	Sync Slave
DECT_Left_A	DM_Left	1-c	1	<input checked="" type="checkbox"/>	
DECT_Left_B	DM_Left	1-c	2		LAN
DECT_Right_A	DM_Right	1-c	1	<input checked="" type="checkbox"/>	
DECT_Right_B	DM_Right	1-c	2		LAN

8.2.6 List of synchronised base stations

All activated base stations contained in the **Connected base stations** list appear in the **Base station synchronization** list.

It is only available in the Integrator user interface for the user role **admin**.

► **Settings** ► **Base stations** ► **Synchronization**

Base stations

Base station synchronisation

Base station synchronization							
<input type="text" value="Search"/>		<input type="text" value="Search in"/>		<input type="button" value="View"/>			
MAC address	Base station	DM Name	Cluster	Sync Level	LAN Master	Sync Slave	Status
7c2f80c6e273	LocalBS	DM2	1	1	<input type="checkbox"/>		Sync
7c2f80c6e5cd	LocalBS	DM1	2	2	<input type="checkbox"/>	DECT	Deactivated
7c2f80e0d639	BS 7c2f80e0d639	DM1	2	1	<input type="checkbox"/>		Sync
7c2f80e0d670	BS 7c2f80e0d670	DM1	2	3	<input type="checkbox"/>	DECT	Sync
7c2f80e0d68b	BS 7c2f80e0d68b	DM1	2	4	<input type="checkbox"/>	DECT	Sync
<input type="button" value="10 entries"/>							

For each registered base station the following information is shown:

MAC address Hardware address of the base station. With this address the device is uniquely identified within the LAN.

Base station Name of the base station.

DM Name Name of DECT manager the base station belongs to.

Cluster Number of the cluster to which the base is assigned.

Sync Level Synchronisation level within the sync hierarchy.

Cluster configuration

DM Name

DM1

Cluster 2

Number of base stations

4

LAN Master

x

Sync Slave

DECT

undancy sync level 2→1 to me level 1. Cluster is marked


hronised via er there is no station:

- vated
 - No sync
 - Sync
 - Sync over-load
- Activated but not synchronised
Activated and synchronised,
Synchronised but DECT overload

Reference Sync reference: Sync type:
1 no Sync Slave function, running free
D DECT slave within cluster: name of cluster in **Reference** column

D →	DECT slave running inter DM synchronisation rule Best DECT base of DM : name of DM in Reference column
L	LAN slave within cluster: name of internal DM in Reference column
L →	LAN slave running external/inter DM synchronisation rule LAN Master of DM xy : name of external DM in Reference column
R →	DECT slave running external RFPI synchronisation rule: RFPI in Reference column

Cluster configuration



The page allows you to synchronise the system manually.

- ▶ Select the DECT manager you want to synchronise from the **DM Name** option menu . . . the cluster configuration of the selected DECT manager is displayed below

Synchronising all clusters of the DECT manager

- ▶ Click on **Synchronize all**

Synchronising a specific cluster of the DECT manager

- ▶ From the **Sync Slave** option menu select which kind of synchronisation you want to perform (**LAN** or **DECT**) ▶ Click on **Synchronize**

8.2.7 Actions

Setting up the base station synchronisation

- ▶ Select the cluster to which the base should be assigned to from the **Cluster** option menu.
Base stations only synchronise within the same cluster, meaning that a handover of a handset from one cluster to a neighbouring cluster is not possible. The DECT multicell system can manage up to nine clusters.
- ▶ Select the synchronisation level for the base station from the **DECT Level** option menu.
DECT level 1 is the highest level and may appear only once in each cluster. A base station always synchronises itself with a base station that has a better sync level. If it sees several base stations

Base stations

Base station synchronisation

with a better sync level, it synchronises itself with the base station that has the strongest signal. If it does not see any base station with a higher sync level, it cannot synchronise.

- ▶ Mark the **LAN Master** check box, if the base station should act as LAN master.

If synchronisation via LAN is used, there must be one base station acting as LAN master. Currently the LAN master can only be configured on DECT level 1.

- ▶ From the **Sync Slave** option menu select whether the base station is to be synchronised via DECT or via LAN. For the Sync master leave this column empty.

9 Provider and PBX profiles











You can use up to 20 different VoIP PBX (Telephony Server) or VoIP provider profiles, e.g.

- OpenScape Business (1 profile)
- OpenScape 4000 (1 profile per IP GWY)
- OpenScape Voice (1 profile)
- Unify Office (1 profile)

This page shows all available VoIP connections.

It is only available in the Integrator user interface for the user role **admin**.

► **Settings ► Provider or PBX profiles**

Provider or PBX profiles		
	Name	Domain
1	 IP1	Not configured
2	 IP2	Not configured
3	 IP3	Not configured
4	 IP4	Not configured
5	 IP5	Not configured
6	 IP6	Not configured
7	 IP7	Not configured
8	 IP8	Not configured
9	 IP9	Not configured
10	 IP10	Not configured

Name The name that you have defined for the connection is displayed, or the default name (IP1 - IP20). It can be edited (→ p. 72).


Domain Domain part of the user address. In the case that a connection is not used **Not configured** is displayed.

► Use the **Previous/Next** button to change between VoIP connection 1 to 10 and 11 to 20.

Provider and PBX profiles

Configuring provider and/or PBX profiles

9.1 Configuring provider and/or PBX profiles


- ▶ Click on  next to the name of the VoIP connection you want to edit . . . the provider/PBX configuration page is opened (→ p. 72).

9.1.1 Configuring telephony server profiles


On this page you can edit the data for the selected telephony server profile.


It is only available in the Integrator user interface for the user role admin.


1. VoIP Provider


Connection name or number 


General data of your service provider


Domain 

Proxy server address 

Proxy server port 

Registration refresh time 

Transport protocol 

SRTP options 

☐ Secure Real Time Protocol

☐ Accept non-SRTP calls

Connection name or number

- ▶ Enter a name for the provider or PBX profile. This name is shown in the Provider/PBX list. To distinguish between different connections it should specify the respective VoIP service provider.

9.1.2 General provider data

Domain

- ▶ Enter the domain part of the user address (SIP URI). Together with the phone's user name it is used to build the Address Of Record (AOR) or to build a destination out of the dialed number.

Examples:

sip.domai for john.smith@sip.domain.net
n.net
10.100.0. for 02871913000@10.100.0.45
45

Proxy server address

The SIP proxy is your VoIP provider's gateway server and the first SIP server, where the device should send SIP requests and expects to receive requests.

- ▶ Enter the IP address or the (fully qualified) DNS name of your SIP proxy server (max. 74 characters, 0 - 9, a - z, A - Z, -, ., _).

Examples: **10.100.0.45** or **sip.domain.net** or **sipproxy01.domain.net**

Proxy server port

- ▶ Enter the port number of the first SIP server, where the device should send SIP requests and expects to receive requests.

Range: 1-65535; Default: **5060** (for UDP/TCP), **5061** (for TLS)

DNS SRV SIP server redundancy lookup might provide a different server port which is used then.

Registration refresh time

- ▶ Enter the time intervals (in seconds) at which the phone should repeat the registration with the VoIP server (SIP proxy). A request will be sent to establish a session. The repeat is required so that the phone's entry in the tables of the SIP proxy is retained and the phone can therefore be reached. The repeat will be carried out for all enabled VoIP connections.

Values: 1 - 5 digits, > 0; Default: **600** seconds

Transport protocol

- ▶ Select between UDP, TCP and TLS.

UDP (User Datagram Protocol) UDP is a non session-based protocol. UDP does not establish a fixed connection. The data packets ("datagrams") are sent as a broadcast. The recipient is solely responsible for making sure the data is received. The sender is not notified about whether it is received or not.

TCP (Transmission Control Protocol) TCP is a session-based transmission protocol. It sets up, monitors and terminates a connection between sender and recipient for transporting data.

TLS (Transport Layer Security) TLS is a protocol for encrypting data transmissions on the Internet. TLS is a superordinate transport protocol.

SRTP options

SRTP (Secure Realtime Protocol) is a security profile to ensure confidentiality, integrity, replay protection and message authentication for audio-visual data transmission over IP-based networks.

Provider and PBX profiles

Configuring provider and/or PBX profiles

► Select which calls should be accepted:

Secure Real Time Protocol Security is activated for voice connections.

Accept non-SRTP calls Insecure calls are accepted even when SRTP is activated.

9.1.3 Redundancy settings

Redundancy

Redundancy - DNS query ?

A ▼

Failover Server

Enable registration

☐ Yes ☐ No

Registration server ?

SIP server port ?

5060

Redundancy - DNS query

VoIP providers provide SIP server redundancy for load balancing and service reliability. SIP servers can be identified by DNS using different queries:

A Records just the specified IP addresses and the related port numbers.

SRV + A Finds an available server port for the specified proxy and registration server. DNS SRV allows a client to only have to know what type of service it is looking for instead of the actual server.

9.1.4 Failover server

If **Redundancy - DNS query** = **A**

In case your provider supports a failover server you can enter the data here.

► Enable/disable the use of a failover server via the radio boxes next to **Enable registration**.

Registration server

► Enter the IP address or the (fully qualified) DNS name of the failover registration server.

SIP server port

► Enter the communication port used on the failover registrar.

Range: 1-65535; Default: **5060** (for UDP/TCP), **5061** (for TLS)

9.1.5 Network data of the service provider

Network data of your service provider

Outbound proxy mode ?

Never ▼

Outbound server address ?

Outbound proxy port ?

5060

SIP SUBSCRIBE for Net-AM MWI ?

☐ Yes ☒ No

Outbound proxy mode

The DECT IP multicell system allows you to configure an outbound proxy. Despite of any other SIP protocol rules, if activated (**Always**), the system will always send all outgoing requests towards this outbound proxy. It can be an outbound proxy in the local network provided by the local network provider or in the public network provided by the network/VoIP provider.

► Specify when the outbound proxy should be used.

Always: All signalling and voice data sent by the system is sent to the outbound proxy.

Never: The outbound proxy is not used.

If the further outbound proxy configuration is identical to the proxy and registrar configuration it is useless and will be ignored.



The DHCP option 120 "sip server" sent by a SIP phone would internally overrule the outbound proxy address and port setting. **Outbound proxy mode** is still and exclusively in the hands of the local device administrator. By setting **Outbound proxy mode** to **Never**, you can prevent any usage of DHCP option 120 by the DECT VoIP phone. To allow for DHCP option 120, you should set **Outbound proxy mode** to **Always**.

Outbound server address

This is the address, where the device should send all SIP requests to and where (in case of successful registration) it expects to receive requests from.

► Enter the (fully qualified) DNS name or the IP address of your provider's outbound proxy.

Example: **10.100.0.45** or **sip.domain.net** or **sipproxy01.domain.net**

If the **Outbound server address** field is empty, the system behaves independently of the selected mode, as with **Outbound proxy mode** = **Never**.

Outbound proxy port

This is the port number of the outbound proxy server, where the device should send all SIP requests to (and where it in case of successful registration expects to receive requests from)

► Enter the communication port used by the outbound proxy.

Range: 1-65535; Default: **5060** (for UDP/TCP), **5061** (for TLS)

Provider and PBX profiles

Configuring provider and/or PBX profiles

Outbound proxy port is empty and **Outbound server address** is a name:

The RFC3263 rules will be used to locate SIP servers and select them for load balancing and redundancy.

Outbound proxy port is a fixed number:

The usage of DNS SRV records according to RFC3263 is blocked.

SIP SUBSCRIBE for Net-AM MWI

When activated a subscription is established for the purpose of receiving notifications about new messages on the network mailbox.

- ▶ Enable/disable SIP subscription via the radio boxes next to **SIP SUBSCRIBE for Net-AM MWI**.

9.1.6 DTMF over VoIP Connections

DTMF signalling (Dual Tone Multi Frequency) is required, for example, for querying and controlling certain network mailboxes via digit codes, for controlling of automatic directory enquiries or for remote operation of the local answering machine.

DTMF over VoIP Connections

Automatic negotiation of DTMF transmission ☐ Yes ☒ No

Automatic negotiation of DTMF transmission

- ▶ For each call, the phone attempts to set the appropriate DTMF signalling type for the codec currently being negotiated: select **Yes**.

The system will use the transmission method matching best the received capabilities from the peer based on the following priority order:

- send via RFC2833, if PT for telephone event is provided by the peer
 - send via SIP INFO application/dtmf-relay, if SIP INFO method is supported by the peer
 - send in-band audio
- ▶ No automatic attempts to set DTMF transmission type: select **No** (DTMF transmission type is Audio by default).

9.1.7 Settings for codecs

The voice quality of VoIP calls is mainly determined by the codec used for the transmission and the available bandwidth of your network connection. A "better" codec (better voice quality) means more data needs to be transferred, i.e. it requires a network connection with a larger bandwidth. You can change the voice quality by selecting the voice codecs your phone is to use, and specifying the order in which the codecs are to be suggested when a VoIP connection is established. Default settings for the codecs used are stored in your phone; one setting optimised for low bandwidths and one for high bandwidths.

Both parties involved in a phone connection (caller/sender and recipient) must use the same voice codec. The voice codec is negotiated between the sender and the recipient when establishing a connection.

Settings for Codecs ?

Active codecs

PCMA
PCMU
G729

←

→

↑

↓

Available codecs

RTP Packetisation Time (ptime) ?

20

Signalling options for 'Hold' in Session Description Protocol (SDP) ?

☒ inactive
☐ sendonly

Hold towards Transfer-Target ?

☐ Yes
☒ No

Active codecs / Available codecs

The following voice codecs are supported:

G.722 Outstanding voice quality. The G.722 wideband voice codec works at the same bit rate as PCMA/PCMU (64 kbit/s per voice connection) but at a higher sampling rate (16 kHz).

To enable wideband connections via G.722 you have to activate the codec explicitly on the **Telephony – VoIP** page (→ p. 97)

PCMA / PCMU (Pulse Code Modulation) Excellent voice quality (comparable with ISDN). The required bandwidth is 64 kbit/s per voice connection.

PCMA (G.711 a law): Used in Europe and most countries outside of USA.

PCMU (G.711 μ law): Used in USA.

G.729 Average voice quality. The necessary bandwidth is less than or equal to 8 kbit/s per voice connection.

Activate/deactivate a codec:

- ▶ Select the required codec from the **Available codecs/Active codecs** list and click on ← / →.

Define the sequence in which the codecs should be used:

- ▶ In the **Active codecs** list select the required codec and click on ↑ / ↓ to move it up/down.



Selection of codecs G.722 and G.729 influence the system capacity in direction to lower amount of parallel calls per base station.

Provider and PBX profiles

Configuring provider and/or PBX profiles

Number of parallel calls per base station depending on bandwidth

Codecs enabled	Number of calls
G711 only	10
G729 and G711	8
G722 and G729 and G711	5

RTP Packetisation Time (ptime)

Length of time in milliseconds represented by the audio data in one packet.

- ▶ Select the size of RTP packets to send. Select between 10 / 20 / 30 ms.

Signalling options for 'Hold' in Session Description Protocol (SDP)

Call hold means that a user requests to put an active call on hold. The holding part sends a re-INVITE request to the held client with an SDP offer (Session Description Protocol). This SDP offer contains the attribute line a=inactive or a=sendonly.

- ▶ Select which attribute should be sent in the SDP offer:

inactive The SIP endpoint would neither send nor receive data.


sendonly The SIP endpoint would only send and not receive data.

Hold towards Transfer-Target

The device enables call transfer after consultation or without consultation.

- ▶ Define whether a consultation call with transfer target is put on-hold prior to the execution of the call transfer (**Yes**) or not (**No**).

9.1.8 Display of caller information



Display of Caller Information

Calling Party (User Part) ⓘ PAI+PPI+FROM ▼

- ▶ From the **Calling Party (User Part)** option menu select which information is allowed to be transferred to the receiving part within the SIP header. Which information is actually transferred is determined by the provider.

FROM Only the FROM information can be added.

PPI+FROM Caller identity in the form number@server, e.g.:12345678@192.168.15.1

PPI+FROM P-Preferred-Identity (PPI) or FROM can be added

The P-Preferred-Identity header field is used from a user agent to a trusted proxy to carry the identity the user sending the SIP message wishes to be used for the P-Asserted-Header field value that the trusted element will insert.

PAI+PPI+FROM P-Asserted-Identity (PAI) or PPI or FROM can be added

The P-Asserted-Identity header field is used among trusted SIP entities (typically intermediaries) to carry the identity of the user sending a SIP message as it was verified by authentication.

9.1.9 Service Codes

Service Codes	
Call Completion on (CCBS, CCNR)	<input type="text" value="*6"/>
Call Completion off (CCBS, CCNR)	<input type="text" value="#6"/>

Service codes are key sequences provided by the provider or PBX in order to activate/deactivate specific functions on the handset. You can set the adequate service codes for activating/deactivating CCBS and CCNR.

CCBS (Completion of Call to busy Ringback if busy
Subscriber)

CCNR (Completion of Calls on No Ringback if no answer
Reply)

- ▶ In the text fields **Call Completion on (CCBS, CCNR)/Call Completion off (CCBS, CCNR)** enter the key sequence for activating/deactivating CCBS and CCNR.

9.1.10 Deleting the profile

- ▶ Click on **Delete** to delete the profile ▶ Confirm the operation with **Yes**.

Provider and PBX profiles

Configuring provider and/or PBX profiles

10 Mobile devices

You can use the web configurator to register all handsets on the DECT network and for a VoIP connection. Use the add function of the **Administration** page to register single handsets or use the **Registration Center** to register groups of handsets in one process.

You can edit the settings for handsets, deactivate or delete them and make further settings e.g., for using directories and network services.

The menu is only available in the integrator user interface.

It is available in the Integrator user interface for both the user role admin and user.

10.1 Mobile devices administration

This page allows you to register single handsets to the phone system.

It is available in the Integrator user interface for both the user role **admin** and **user**.

► Settings ► Mobile devices ► Administration

Mobile devices

Search in ▼

View ▼

<input type="checkbox"/> IPUI	Username	Display name	Location	DECT	SIP	Type	FW
<input type="checkbox"/> 02b6a8bdc3	12234567	Peter	DECT-M 2	Registered	✗	"M3 prof."	46
<input type="checkbox"/> 031c152f04	2314567	Mary	DECT-M 2	Registered	✗	"M3 prof."	46

10 entries ▼

+ Add

Copy

Replace

Delete

Export ▼

Import

Global settings

Displayed name in idle display

☒ Username
 ☐ Display name

The currently registered handsets and place holders for handsets that could be registered are listed on the page with the following information:

IPUI	International Portable User Identity used in order to uniquely identify a handset within the DECT network.
Username	User name from the SIP account that is assigned to the handset, usually the phone number. The name is displayed on the handsets when they are in idle status.

Mobile devices

Mobile devices administration

Display name	Display name from the SIP account that is assigned to the handset. The display name indicates the originator of the request when the user initiates a call.	
Location	Name of the DECT manager the handset belongs to.	
DECT	DECT registration state of the handset:	
	Status	Meaning
	To register	System ready to register a handset
	Not registered	Registration not possible
	Registering	Registration in progress
	Registered	Handset is registered
SIP	Indicates, if the handset has a working VoIP connection.	
	✓	A VoIP connection is registered for the handset and a connection has been established successfully.
	✗	There is no VoIP connection configured or it is not possible to establish a connection to the configured VoIP provider.
DND	Indicates, if DND (Do not Disturb) is activated	
Type	Model designation of the handset.	
FW	Current firmware version of the handset.	
PIN	Authentication code defined for handset registration.	

10.1.1 Actions

Adding a handset to the list

- ▶ Click on **Add** . . . the mobile devices data page is opened (→ p. 84).

Copying handset data for another configuration

- ▶ Select the check box next to the handset whose settings you want to copy. ▶ Click on **Copy** . . the mobile devices data page is opened (→ p. 84). The settings of the selected mobile device except personal data are taken over for the new handset configuration.

Replace a mobile device for a user by another one

- ▶ Select the check box next to the handset of a user who should get another handset. ▶ Click on **Replace** . . . the mobile devices data page is opened (page 62). The old mobile device will be set to **To deregister**. Personal provider data will be removed. User-specific data remain preserved. You will be prompted register a new mobile device.

Deleting a handset from the list

- ▶ Select the check box next to the handset you want to delete. Multiple choice is possible. ▶ Click on **Delete** ▶ Confirm with **Yes** . . . all selected handsets are deleted.

Exporting/Importing the handset configuration

You can export the handset configuration and import it into another device, in order to change the DECT manager assignment, e.g., when migrating the multicell system from a single to a multiple DECT manager system (p. 106)

Exporting:


- ▶ Select all handsets you want to be transferred via the check mark ☒ next to the IPUI.

- ▶ Click on **Export** ▶ Select the location where the export file should be stored using the system file selection dialogue.

Importing:

- ▶ Click on **Import** ▶ Select the previously exported handset configuration file from your computer's file system.

Editing the data of a handset

- ▶ Click on  next to the handset you want to edit . . the mobile devices data page is opened (→ p. 84).

Setting the name to be displayed in the idle display

By default the **Username** is displayed in the handset's idle display. You can determine that the **Display name** should be used instead

Changing the appearance of the list

Filtering the list:

- ▶ Enter a search item (full field content) in the text field ... only entries containing text matching the search item in any column are shown in the table.

Filtering the list by column content:



Mobile devices

- ▶ In the **Search in** option menu select the columns which should be searched for the entered search item . . . only entries containing text matching the search item in the selected column are shown in the table.

Sorting the list

- ▶ Click on the arrows next to the column header to sort the table on the column content in ascending or descending order.

Display/hiding columns:

- ▶ Click on the **View** option menu on the right ▶ Select the columns you want to be displayed in the table ( /  = displayed/hidden).
Names of columns which cannot be hidden are greyed out.

10.2 Registering/de-registering handsets

The page allows you to register a handset with the DECT network or to prepare the registration of numerous handsets via the Registration Center. You can assign a VoIP account, enable online directories, and make further settings for the handsets.

It is available in the Integrator user interface for both the user role admin and user.



Registration/de-registration in this context refers to the handset's relationship to the DECT network but not to SIP registration.

10.2.1 Registering handsets

- ▶ Enter an IPUI, if you want to restrict the registration to a specific handset.
- ▶ Enter an authentication code manually or generate it via the **Generate random PIN** button.
- ▶ Enter all configuration data for the handset.
- ▶ Click on **Register now**.

The handset with the matching IPUI is now allowed to register. If no IPUI is defined all handsets within range can register.



The system stays in registration mode as long as it is defined via the **Registration duration** parameter on the **Registration Center** page (→ p. 91). Default: 3 min.

On the handset

- ▶ Start the registration procedure as described in the appropriate documentation. ▶ When prompted, enter the PIN that has been entered or generated.

10.2.2 Registering a set of handsets

You can register a set of handsets without restarting the registration mode. Prepare registration for new mobile devices as follows:

- ▶ Enter the actual IPUI and maybe an individual PIN

or

- ▶ Use wildcards as IPUI (0_1, 0_2, 0_3 ...) and preferably the same PIN for all handsets.
- ▶ Set the **RegStatus** of the handsets to **To register**
- ▶ Open the registration window for a desired time and register all handsets without further Web UI interaction via the **Registration Center** (→ p. 91).

10.2.3 Parameters

Mobile device

IPUI ?

RegStatus ?

Not registered ▼

Authentication Code (PIN) ?

Entry is required

🔑 Generate random PIN

IPUI

(International Portable User Identity) Unique identifier of a handset within the DECT network. If you edit an existing handset registration entry, the IPUI is shown and cannot be changed.

For a new entry:

- ▶ Enter the IPUI of the handset that should be allowed to register with the DECT network in the text field.

If the field is empty, any handset will be allowed to register.

RegStatus

DECT registration status of the handset entry. The option menu allows you to change the status.

Status	Meaning / possible action to change the status
To register	The system is ready to register a handset using these settings. ▶ Select Not registered to disable registration.
Not registered	No registration possible. ▶ Select To register to allow a handset to register using these settings.
In registration	Registration in progress. ▶ Select Not registered to cancel the running registration process.
Registered	The handset is registered. ▶ Select To deregister to de-register the handset.

Authentication Code (PIN)

This PIN must be used on the handset to register with the DECT network.

- ▶ Enter a PIN in the text field. Value: 4 digits


or

- ▶ Click on **Generate random PIN** . . . a four-digit PIN is generated and shown in the text field.

Mobile devices

Registering/de-registering handsets

10.2.4 De-registering handsets

- ▶ In the handset list click on  next to the handset you want to de-register. The status is **Registered**.
- ▶ From the **RegStatus** option menu select **To deregister**. ▶ Click on **Set** . . . the handset is de-registered.

DECT de-registration successful: The handset is deleted from the **Mobile devices** list.

DECT de-registration not successful: The handset stays in the **Mobile devices** list with status **To deregister**.

In the handset list an empty entry in **To register** status is shown. As long it is not deleted, you can re-register the handset (or any handset if no IPUi is given) via the **Mobile devices** the edit page or the Registration Center.

10.2.5 Settings for the handset

When registering a handset you can define important settings and assign functions at the same time.

Personal provider data

Personal provider data

A separate SIP connection must be assigned to each handset.

Authentication name ?

admin

Authentication password ?

.....


☐ Show password ?

Username ?

Display name ?

VoIP provider ?

IP1 ▼

Configure the VoIP account for the handset. If the handset is successfully registered,  will be shown in the **SIP** column in the **Mobile devices** list.



The VoIP/PBX account must be set-up beforehand (→ p. 72).

VoIP provider

- ▶ Choose a configured VoIP PBX/provider from the option menu.

The connection must be configured on the **Provider or PBX profiles** page (→ p. 72).

- ▶ Enter the access data for the VoIP account in the relevant fields. These fields may vary depending on the PBX/provider profile.

Authentication name

- ▶ Specify the SIP authentication (HTTP digest) name. The **Authentication name** acts as access ID when registering with the SIP proxy/registrar server. It is usually identical to the phone number for the VoIP account. Value: max. 74 characters

Authentication password

- ▶ Enter the password for SIP authentication (HTTP digest). The phone needs the password when registering with the SIP proxy/registrar server. Value: max. 74 characters

Username

- ▶ Enter the caller ID for the VoIP provider account. It is usually identical to the phone number for the VoIP account. Value: max. 74 characters

Display name

The display name is used for presentation of the caller's name. In rare cases SIP networks check the display name for any local policy of the SIP network.

Usually, the display name is optional.

- ▶ Enter any name that should be shown for the caller on the other participant's display. Value: max. 74 characters

If **Display name** is empty, the **Username** or the phone number will be used.

10.2.6 Online directories

The user can call up various directories using the handset control or INT key.

Online directories	
Directory for direct access ?	Online directories ▼
Corporate directory for INT key ?	▼
Automatic look-up ?	Deactivated ▼

Directory for direct access

The user can press and hold the directory key (bottom of the control key) to open either the list of online directories or the local directory of the handset.

- ▶ Choose which directory is called up with the directory key.

Online directories A list of online directories is opened via the directory key.

The online directories must be set-up beforehand (→ p. 81)

Local directory The local directory is opened via the directory key..

Mobile devices

Registering/de-registering handsets

Corporate directory for INT key

If any online directory is available and configured the user can open it by pressing the INT key (left on the handset's control key).

- ▶ Choose from the list which directory is opened with the INT key.

Automatic look-up

- ▶ Select an online directory from the list for **Automatic look-up** or deactivate this option. When there is an incoming call, the caller's name is read from this directory and shown in the display (the availability of this function depends on the online directory provider).

10.2.7 LDAP authentication

Up to 10 directories in LDAP format can be provided by the phone system. The access to a corporate directory can be provided individually for specific handsets.

LDAP authentication

To authenticate mobile devices individually, activate this function in online directory settings.

Selected LDAP book	NO LDAP ▼
Show other LDAP servers	<input type="radio"/> Yes <input checked="" type="radio"/> No
LDAP authorization type	Global ▼
Username ?	<input type="text"/>
Password ?	<input type="password"/>

Selected LDAP book

- ▶ Select the LDAP directory to be provided on the handset from the option menu.



At least one LDAP directory must have been set-up (→ p. 81).

Show other LDAP servers

- ▶ Select **Yes** if directories of other LDAP servers should be shown.

LDAP authorization type

- ▶ Select how the user authentication should be performed:
 - Global** Credentials are set for all handsets during the LDAP directory set-up.
 - User** Individual credentials are used.
 - ▶ Enter **Username** and **Password** in the appropriate text fields.

SIP The credentials for the user's SIP account are used (**Authentication name** and **Authentication password**).

10.2.8 Network mailbox configuration

If a network mailbox is available for the VoIP account assigned to the handset, you have to activate this function.

Network mailbox configuration

Call number or SIP name (URI) ?

☐ Activate network mailbox

- ▶ Enter the **Call number or SIP name (URI)** for the network mailbox.
- ▶ Activate the function via the check box.

10.2.9 Group pick-up

Group pick-up enables a user to accept a call for another subscriber, e.g., a pick-up group. Users belonging to the same call pick-up group can accept all calls for the group. A pick-up group must be established during SIP account registration. The call number or the SIP URI of a pick-up group can be assigned to the mobile device.

Group pick-up

Call number or SIP name (URI) ?

☐ Activate group pick-up

- ▶ Enter the **Call number or SIP name (URI)** of the pick-up group.
- ▶ Activate the function via the check box.

Mobile devices

Registering/de-registering handsets

10.2.10 Call manager

Call manager

Accept calls directly via Call Manager ?

- From the **Accept calls directly via Call Manager** option menu select whether calls that are transferred via the PBX call manager are to be accepted directly **via Headset, via Handsfree** or not at all (**No**).

10.2.11 Missed calls and alarms

You can define if missed and accepted calls should be counted and if new messages of specific types should be indicated via the MWI LED on the handset's message key.

Missed calls and alarms

Missed/accepted calls count ?

☒ Yes ☐ No

Flashing LED (MWI) for missed calls ?

☒ Yes ☐ No

Flashing LED (MWI) for missed alarms ?

☒ Yes ☐ No

Flashing LED (MWI) for network mailbox ?

☒ Yes ☐ No

- Select **Yes/No** next to **Missed calls count/Accepted calls count**, to activate/deactivate the call counter for missed and accepted calls. The information is displayed in the handset's call lists, missed calls are also shown on the handset's idle display.
- Select **Yes/No** next to the message type (missed calls, missed alarms, new message on the network mailbox), to activate/deactivate the MWI LED for the message type.
If **Yes** is selected, the message key will flash, if a new message of the selected types is received.

10.3 Handset Registration Centre

The registration centre allows you to register groups of handsets in one registration process. All handsets which are listed in the mobile devices list and have the registration status **To register** or **Registering** can be registered together.

It is available in the Integrator user interface for both the user role admin and user.

► **Settings** ► **Mobile devices** ► **Registration Center**

Mobile devices

Handset Registration Centre

Mobile devices	
with RegStatus: "To register" ?	0
with RegStatus: "Registering" ?	0
Total ?	0

DECT managers	
with Registrations Window open	0
Total	2

Current time ? 2018-05-30 16:05:26

Registration start time ?

Registration duration ?

d

h

min

s

The page shows the number of mobile devices in registration status **To register**, **Registering** and the total number of entries in the mobile devices list, including those in registration status **Registered** and **Not registered**.

Additionally, the page shows the total amount of DECT managers and DECT managers that are currently ready to register handsets. DECT managers are set in registration status **Registering** when a registration process is started automatically according to the time settings on this page or when registering handsets manually.

10.3.1 Registering handsets time-controlled

Shows the current system time. Time settings: → p. 121

- ▶ In the **Registration start time** field enter the time when the next registration process should be started. Format: YYYY-MM-DD HH:mm.
- ▶ Click on **Start now**. . . . the DECT manager starts a registration process at the given time. If no time is set, the DECT manager will start registration at once.

Setting the registration duration

- ▶ In the **Registration duration** fields determine how long (days, hours, minutes and seconds) the DECT manager should stay in registration mode. Default: 3 min.

Closing the window and resetting the timers

- ▶ Click on **Close** . . . the registration window is closed, the time settings are reset.



When the first handset tries to register, the base closes the registration window and finalises the registration within a very few seconds. During this time any second handset registration attempt would be rejected. When the first handset is fully registered the base re-opens the registration window as long as defined with the **Registration start time** and **Registration duration** parameters.

If all handsets try to register in parallel, a lot of them will enter the base one by one and so will be successfully registered, but others might enter while another registration is not yet completed and so they will be rejected.

Single handsets that are rejected have to be registered by a new registration procedure or manually.

Mobile devices

Handset Registration Centre

11 Telephony settings

The menu is only available in the Integrator user interface.

11.1 General VoIP settings

This page allows you to make some general settings for the VoIP connections.
It is only available in the Integrator user interface for the user role admin

► Settings ► Telephony ► VoIP

This page allows you to make some general settings for the VoIP connections.

SIP

SIP port ?

5060

Secure SIP port ?

5061

SIP timer T1 ?

500

ms

SIP session timer ?

1800

s

Failed registration retry timer ?

300

s

Subscription timer ?

1800

s

☐ PRACK ?

SIP security certificate ?

File not uploaded

Delete

» Certificate

Browse...

» Private key

Browse...

SIP security password ?

Quality of Service (QoS)

SIP ToS / DiffServ ?

34

RTP ToS / DiffServ ?

46

SIP port
► Enter the SIP port used for VoIP connections.
Range: 1-65535; Default: 5060

Telephony settings

Security settings

Secure SIP port

- ▶ Enter the SIP port used for secure VoIP connections (TLS).

Range: 1-65535; Default: 5061

SIP timer T1

- ▶ Enter the estimated round trip time of an IP packet between a SIP client and a SIP server (the time it takes between sending out the request to the point of getting a response).

Default: 500 ms

SIP session timer

- ▶ Defines a session expiry interval: If the session isn't refreshed within the interval, the session is released. Session refresh is started after half of the interval by a re-INVITE message, which the peer side has to confirm to get the session refreshed.

Values: max. 4 digits, min. 90 sec; Default: 1800 sec;

Failed registration retry timer

- ▶ Specify after how many seconds the phone should attempt to re-register when the initial registration has failed.

Values: max. 4 digits, min. 10 sec; Default: 300 sec;

Subscription timer

- ▶ Defines the expiration time (in seconds) of a subscription. In order to keep subscriptions effective, subscribers need to refresh subscriptions on a periodic basis.

Default: 1800 s

PRACK

- ▶ (Provisional Response Acknowledgement) SIP provisional responses do not have an acknowledgement system so they are not reliable. The PRACK method guarantees a reliable and ordered delivery of provisional responses in SIP.

11.2 Security settings

The phone system supports the establishment of secure voice connections over the internet via TLS certificates. Thereby, public and private keys are used to encrypt and decrypt the messages that are exchanged between SIP entities. The public key is contained within the certificate of an IP entity and is available for everyone. The private key is kept secret and is never revealed to anyone. The server certificate and the private key must be uploaded to the base stations.

- ▶ Click on **Browse...** and choose the file containing the certificate or the private key from the file system of your computer or network ▶ click on **Upload** . . . the file is uploaded and shown in the appropriate list.

SIP security password

- ▶ If your private key is protected by a password, enter it here.

11.3 Quality of Service (QoS)

The voice quality depends on the priority of the voice data in the IP network. Prioritising the VoIP data packets is done using the QoS protocol DiffServ (Differentiated Services). DiffServ defines a number of classes for the quality of service and, within these classes, various priority levels for which specific prioritisation procedures are defined.

You can specify different QoS values for SIP and RTP packets. SIP packets contain the signalling data, while RTP (Real-time Transport Protocol) is used for the voice transfer.

- ▶ Enter your chosen QoS values in the **SIP ToS / DiffServ** and **RTP ToS / DiffServ** fields. Value range: 0 - 63.

Common values for VoIP (default setting):

SIP	34	High service class for fast switching of the data flow (Expedited Flow)
RTP	46	Highest service class for fast forwarding of data packets (Expedited Forwarding)



Do not change these values without consulting your network operator first. A higher value does not necessarily mean a higher priority. The value determines the service class, not the priority. The prioritisation procedure used in each case meets the requirements of this class and is not necessarily suitable for transferring voice data.

11.4 Audio quality

The phone system allows the user to make calls with excellent voice quality using the wideband codec G.722. One base station enables a maximum of five wideband calls.

The page allows you to enable/disable the use of the wideband codec G.722 for the telephone system.

It is only available in the Integrator user interface for the user role **admin**.

▶ Settings ▶ Telephony ▶ Audio

- ▶ Mark/unmark the check box to enable/disable wideband calls
- ▶ Click on **Set** to save the settings of this page.



To allow users to make wideband calls, the codec G.722 must have been activated for the provider profile that is used for the connection (→ p. 77).

11.5 Call settings

On this page you can make advanced settings for VoIP connections.

It is only available in the Integrator user interface for the user role admin.

► **Settings** ► **Telephony** ► **Call settings**

11.5.1 Call transfer

Participants can transfer a call to another participant as long as the PBX/provider supports this function. The call is transferred using the handset menu (via the display key) or using the R key. You can expand or change the settings for call transfer.

Call Transfer

Call transfer via R key ?

☒ Yes ☐ No

Transfer call by on-hook ?

☒ Yes ☐ No

Determine target address ?

☒ From transfer target's AOR
☐ From transfer target's transport address

Call transfer via R key

Activated: Users can connect two external callers with each other by pressing the R key. The connections with both parties are terminated.

Transfer call by on-hook

Activated: The two participants are connected with one another when the user presses the end call key. The intermediary's connections with the participants are terminated.

Determine transfer target address

► Select how the transfer target address (Refer-To URI) is to be derived:

From transfer target's AOR (Address of Record)

From transfer target's transport address (Contact URI)

Most common PBX platforms show good results by using the AOR as transfer target address.

In case there are problems with transfer especially via transparent proxies, rather than call switching PBX, it might be worthwhile to test with transfer target address derived from transfer target's transport address.

11.5.2 Access Code

You may have to enter an access code for external calls (external prefixes e.g., "0"). You can save this access code in the DECT manager configuration. These settings apply to all registered handsets.

Access Code

Access Code ?

is added to numbers ?

☐ From incoming calls list
☐ From network directory
☐ Always

- ▶ Enter an access code in the **Access Code** text field. Value: max. 3 digits (0 – 9, *, R, #, P)
- ▶ Select when the phone numbers should be automatically prefixed with the digits, e.g. when dialling from a call list or a directory.

11.5.3 Area Codes

If you use VoIP to make a call to the fixed line, you may also have to dial the area code for local calls (depending on the provider).

You can set your telephone system so that the access code is automatically predialled when any VoIP call is made in the same local area, and also for national long-distance calls. This means that the access code is set before all phone numbers that do not start with 0 – even when dialling numbers from the directory and other lists.

You can change these settings if required.

Area Codes

Country ?

Germany ▼

International

Prefix ?

00

Area code ?

49

Local

Prefix ?

0

Area code ?

Telephony settings

Call settings

You can set your telephone system so that the access code is automatically predialled when any VoIP call is made in the same local area, and also for national long-distance calls. This means that the access code is set before all phone numbers that do not start with 0 – even when dialling numbers from the directory and other lists.

You can change these settings if required.

Country

- From the option menu select the country or region where your telephone system is to be used . . . the international and national prefix is then entered in the **Prefix** and **Area code** fields.

11.5.4 International settings

Prefix Prefix of the international area code. Value: max. 4 digits, 0-9

Area code International area code. Value: max. 4 digits, 0-9

Example "Great Britain": **Prefix** = 00, **Area code** = 44

Local settings

Prefix Prefix of the local area code. Value: max. 4 digits, 0 - 9. These digits are placed in front of the local area code for national long-distance calls.

Area code Local area code for your town/city (depending on country/provider). Value: max. 8 digits, 0-9

Example "London": **Prefix** = 0, **Area code** = 207

11.5.5 Tone Selection

Tones (e.g., dialling tone, ring tone, busy tone or call waiting tone) vary from one country or region to another. You can choose from various tone groups for your telephone system.

Tone Selection

Tone scheme ?

Austria ▼

Tone scheme

- Select the country or region whose ring tones are to be used for your phone from the option menu.

12 Online directories

You can set up to ten corporate directories in LDAP format for the phone system and make one of them available to the registered handsets.

Use the handset settings (→ p. 86) to specify which keys are to call up the directory.

The menu is only available in the Integrator user interface.

12.1 Corporate online directories (LDAP)











If you wish to use a company directory on the telephone system, you must activate it on the Web configurator.

The page lists the available LDAP directories.

It is only available in the Integrator user interface for the user role **admin**.

► **Settings** ► **Online directories** ► **Corporate**

LDAP directory

		Name	Server url	Activation status
1		LDAP 1		✗
2		LDAP 2		✗
3		LDAP 3		✗
4		LDAP 4		✗
5		LDAP 5		✗
6		LDAP 6		✗
7		LDAP 7		✗
8		LDAP 8		✗
9		LDAP 9		✗
10		LDAP 10		✗

Name	The name that you have defined for the directory is displayed, or the default name (LDAP1 - LDAP10). It can be edited (→ p. 91).
Server url	If the directory is configured, the server URL is displayed.


Online directories

Configuring LDAP directories

Activation status Indicates if the directory is activated or not.

- ✓ The directory is activated.
- ✗ The directory is not activated.

12.2 Configuring LDAP directories

► Click on  next to the name of the LDAP directory you want to edit . . . the LDAP configuration page is opened (→ p. 102).

12.2.1 Configuring a LDAP directory

On this page you can edit the data for the selected LDAP directory.

It is only available in the Integrator user interface for the user role **admin**.

Access to the LDAP data server

The directory is provided via an LDAP server. You need the server address, the server port and the access data for the directory that you wish to use.

Access to the LDAP data server

Directory name ?	LDAP 1
	<input type="checkbox"/> Enable directory
Server address ?	
Server port ?	389
LDAP Search base (BaseDN) ?	0
Username ?	admin
Password ?	●●●●●●●●
Secure LDAP	None ▼

- Enter a name in the **Directory name** field (max. 20 characters). This is the name under which the directory will be displayed on the handsets.
- Mark the **Enable directory** option, so that the directory is displayed on the telephones.

Server address / Server port

- Enter the URL of the LDAP server and the port the LDAP server expects database requests (Default: 389)

LDAP Search base (BaseDN)

- ▶ The LDAP database is hierarchical in design. With the **LDAP Search base (BaseDN)** parameter, stipulate in which area the search should begin.
Default: 0, the search starts at the upper area of the LDAP database.

User access data

If you want to define access data that have to be used by all users:

- ▶ Enter the access data for the LDAP directory in the **Username** and **Password** fields (max. 254 characters each).

Online directories

If you want to use individual access data for each handset, the access data is to be set during the handset configuration (→ p. 87).

Secure LDAP

By default, LDAP traffic between the phone system and the LDAP directory server is handled via an insecure connection. You can encrypt traffic by enabling secure LDAP. This is accomplished by installing a CA certificate signed by the secure LDAP server onto the system (→ p. 119).

- ▶ Select the security protocol **SSL/TLS or STARTTLS** to be used for encryption or **None** to dispense with encryption.

12.2.2 Settings for searching the LDAP database and displaying the result

Search in LDAP database	
	<input checked="" type="checkbox"/> Enable list mode
Name filter	<input type="text" value="((cn=*)(sn=*))"/>
Number filter	<input type="text" value="((telephoneNumber=*)(mobile=*))"/>
Additional filter #1 name	<input type="text" value="City"/>
Additional filter #1 value	<input type="text" value="(!=)"/>
Additional filter #2 name	<input type="text" value="Street"/>
Additional filter #2 value	<input type="text" value="(!street=)"/>
Display format	<input type="text" value="%sn, %givenName"/>
Max. number of search results	<input type="text" value="50"/>

Enable list mode

Online directories

Configuring LDAP directories

- Define what should be initially shown, when the user opens the LDAP directory.

Activated: A list of all entries of the LDAP directory is shown.

Not activated: An editor is opened first that allows the user to select a specific search area within the LDAP database and thereby to reduce the number of entries.

Filters

Using the filters, you can define criteria against which specific entries can be searched in the LDAP database. One filter consists of one or more search criteria. A search criterion contains the query for an LDAP attribute.

Example: `sn=%`

The **sn** attribute stands for surname. The percent sign (%) is a place holder for the user entry.

Rules for defining filters:

- Multiple criteria can be connected using logical AND (&) and/or OR (|) operators.
- The logical operators "&" and "|" are placed before the search criteria.
- The search criterion must be placed in brackets and the whole expression must be terminated with a bracket again.
- AND and OR operations can be combined.

Examples:

AND operation: `(& (givenName=%) (mail=%%)) .`

. Searches for entries in which the first name **and** mail address begin with the characters entered by the user.

OR operation: `(| (displayName=%) (sn=%%)) .`

. Searches for entries in which the display name **or** surname begins with the characters entered by the user.

Combined operation: `(|(& (displayName=%) (mail=%%))(& (sn=%) (mail=%%))) .`

. Searches for entries in which the display name **and** mail address **or** the surname **and** mail address begin with the characters entered by the user.

Information on
Attributes(→page
96). Name filter

.

For information on attributes, see p. 106

Name filter

The name filter decides which attribute is used for the search.

Examples:

`(displayName=%)`. The percent sign (%) is replaced by the name or part of the name entered by the user.

If a user enters the letter "A", for example, all entries in which the attribute **displayName** begins with "A" are searched for in the LDAP database. If the user then enters a "b", entries are searched in which the **displayName** begins with "Ab".

Number filter

The number filter stipulates the criteria for the automatic completion of telephone numbers.

Examples:

(|(telephoneNumber=%)(mobile=%)). The percent sign (%) is then replaced by the part of the telephone number entered by the user.

When dialling, if a user enters the numbers "123", for example, all telephone numbers that begin with "123" are searched for in the LDAP database. The telephone number is completed with the addition of information from the database.

Additional filters

You can set two additional filters that will be offered to the user in order to specify the search more detailed.

- ▶ In the additional name fields enter the attribute name.
- ▶ In the corresponding value fields enter the attribute values.

Example:

Additional filter #1 name.	City.
Additional filter #1 value.	((l=%)).
Additional filter #2 name.	Street.
Additional filter #2 value.	((street=%)).

In addition to the fields defined in the **Name filter** parameter, the **City** and the **Street** fields are provided to the user. The user input for **City** is passed to the LDAP server in the **l** attribute, the user input for **Street** is passed in the **street** attribute.

Display format

In the **Display format** field you can stipulate how the search result is to be displayed on the handset.

- ▶ Enter combinations of different name and number attributes and special characters. You can select common formats from the attributes that are listed in the **Configuration of directory items** section of the page.

For the attribute values to be shown for the required attribute, the attribute name must be preceded by a percent sign (%).

Example:

Data of an directory entry on the LDAP server:

displayName.	Peter Black.	telephoneNumber.	0891234567890.
givenName.	Peter.	mobile.	012398765432.
sn.	Black.	.	.
...	.	.	.

Attribute definition in the Web configurator:

Display format. %sn, %givenName; %telephoneNumber/%mobile.

.

The entry is shown on the handset as follows:

Black, Peter; 0891234567890/012398765432

Max. number of search results

- ▶ Enter the maximum number of search results that is to be returned by one search operation.

12.3 Attributes

A range of attributes are defined in the LDAP database for a directory entry, e.g. surname, first name, telephone number, address, company, etc. The quantity of all attributes which can be saved in one entry is stored in the relevant LDAP server scheme. In order to be able to access attributes or define search filters, you must know the attributes and their designation in the LDAP server. The majority of attribute designations are standardised, however specific attributes can also be defined.

Configuration of directory items ?

First name	<input type="text"/>
Surname	<input type="text"/>
Phone (home)	<input type="text"/>
Phone (office)	<input type="text"/>
Phone (mobile)	<input type="text"/>
E-mail	<input type="text"/>
Fax	<input type="text"/>
Company	<input type="text"/>
Street	<input type="text"/>
City	<input type="text"/>
Zip	<input type="text"/>
Country	<input type="text"/>
Additional attribute	<input type="text"/>

☐ Additional attribute can be dialled ?

- For each field of a directory entry that should be displayed on the handsets enter the name of the corresponding LDAP attribute. Multiple attributes can be separated by commas.
- Mark the check box **Additional attribute can be dialled**, if an additional attribute is defined and it is a phone number.

A detailed configuration example can be found in section "LDAP directory – configuration example"
→ p. 151

12.4 LDAP configuration with Windows Active Directory server

Active Directory Domain Services (AD DS) is the directory service for Windows server. In a multidomain AD DS forest (container within an Active Directory configuration containing domains, users, hosts and group policy) the Global Catalog is a distributed data repository that contains a searchable, partial representation of every object in every domain. The global catalog is stored on domain controllers that have been designated as global catalog servers and is distributed through multi-master replication. Searches that are directed to the global catalog are faster, because they do not involve referrals to different domain controllers.

Online directories

In addition to configuration and schema directory partition replicas, every domain controller in a forest stores a full writeable replica of a single domain directory partition. A domain controller can locate only the objects in its domain. Locating an object in a different domain would require the user or application to provide the domain of the requested object.

To use an LDAP directory provided via Active Directory service you can use the following ports:

Default ports: 389 (LDAP) / 636 (LDAPS)

These ports are used for requesting information from the local domain controller. LDAP requests sent to port 389/636 can be used to search for objects only within the global catalogues home domain. However, the requesting application can obtain all of the attributes for those objects.

Default ports: 3268 (LDAP) / 3269 (LDAPS)

These ports are used for queries specifically targeted for the Global Catalog. LDAP requests sent to port 3268/3269 can be used to search for objects in the entire forest. However, only the attributes marked for replication to the Global Catalogue can be returned.

12.5 Central phone book

You can provide a central phone book for all users' handsets. The phone book can be provided via a server in the network or uploaded directly from a computer to the phone system.

It is only available in the Integrator user interface for the user role **admin**.

The phone book must be available in well-defined XML format.

Example:

```
<?xml version="1.0" encoding="utf-8"?>
<!DOCTYPE LocalDirectory>
<list>
  <entry name="Firstname" surname="Lastname" mobile1="" mobile2=""
office1="0049123456789" office2="" home1="" home2="" />
  <entry name="First" surname="Last" mobile1="" mobile2=""
office1="0049987654321" office2="" home1="" home2="" />
</list>
```

Online directories

Central phone book

► Settings ► Online directories ► Central phonebook

Central phonebook

☐ Enable directory

Directory name CentralBook

Server address

Daily refresh time 00:00

Max number of search results 99

☐ Enable list mode

Load phonebook from PC

Phonebook file Browse...

Phonebook download

Save phonebook

Phonebook delete

Delete phonebook

Directory name

- Enter a name for the phone book in the **Directory name** field. This is the name under which the phone book will be displayed on the handsets.
- Mark the **Enable directory** option, so that the directory is displayed on the handsets.

Server address

- Enter the URL of the server providing the phone book in the text field.

Daily refresh time

The phone book will be refreshed automatically once a day.

- Enter the time when the automatic refresh should take place.

Max. number of search results

- Enter the maximum number of search results that is to be returned by one search operation.

Enable list mode

- Define what should be initially shown, when the user opens the phone book.

Activated: A list of all entries of the phone book is shown.

Not activated: An editor is opened first that allows the user to select a specific search area within the phone book and thereby to reduce the number of entries.

Load the phone book from PC

You can download an XML phone book from your computer directly to the phone system.

Phonebook file

- Click **Browse...** and select the XML phone book file from your computer's file system ► click on **Upload** . . . the selected file is loaded and can be made available for the users.

Save the phone book to PC

You can backup the central phone book to your computer.

- ▶ Click on **Save phonebook** ▶ Select the location where the phone book should be stored using the system file selection dialogue. Enter a name for the phone book backup file.

Delete the phone book

- ▶ Click on **Delete phonebook** to remove the phone book from the handsets.



A search in the central telephone book returns all entries that contain the characters entered by the user somewhere in the first or last name. Alternatively, the following can be set via provisioning: Only those entries are returned that have the entered characters at the beginning.

13 Online Services

13.1 Application-Server

The phone system supports the AML feature (Alarming - Messaging - Location). AML includes the following functions:

Alarming: The user can start an alarm from the DECT handset.
The alarm is forwarded to an alarm server.

DGUV support: DGUV-compliant protection of employees working alone in dangerous situations with the aid of special DECT devices. For example, alarms that are triggered in certain cases: "man down" function triggered, emergency button pressed, explosion, detached cable.

Messaging : Messages from an alarm server (or another server/platform) are sent to the DECT handsets. Reactions from users can be sent back to the server.
Messages may contain an icon (coloured) if the DECT phone supports this, e.g. for fire alarm, nurse call, . . . Prioritised messages can be signalled with specific different ringtones.

Location: The location of a handset is made visible on an alarm server. The alarm server can show visited and neighbouring base stations including signal strength.



► Settings ► Online services ► Application Servers

On this page you enter the servers to be used for AML.

This page is only available in the Integrator user interface for the user role **admin**.


► Settings ► Online services ► Application Servers


Application Servers

<input type="checkbox"/>	AS Id	AS Name
 <input type="checkbox"/>	as1	alarm_service
 <input type="checkbox"/>	as2	alarm_service 2

10 entries

+ Add

 Delete



The page shows the following information about the servers:

AS Id Automatically assigned ID for the application server.

AS Name Name you can set for the server.

13.1.1 Actions


Adding an application server

- ▶ Click on **Add** . . . the application server page is opened.

Deleting an application server from the list

- ▶ Select the check box next to the application server you want to delete. Multiple choice is possible. ▶ Click on **Delete** ▶ Conform with **Yes** . . . all selected application server are deleted.

Editing the data of an application server

- ▶ Click on  next to the application server you want to edit . . . the application server configuration page is opened.

Adding/editing an application server

Application Servers

AS Id ?

as1

Application server name ?

alarm_service

Password ?

.....

☐ Show password ?

AS Id

- ▶ ID that external clients need for access. The ID is automatically assigned as soon as you set up an entry for the application server.

Application server name

- ▶ Enter the user name for accessing the server in the text field.

Password

- ▶ Enter a password for accessing the server (min. 32 characters).

14 System settings

14.1 Web configurator access rights

On this page you define the access rights for the web configurator user interface.

It is available in the Integrator and DECT manager user interface for both the user role admin and user. The user is only allowed to change the own password.

► **Settings** ► **System** ► **Web configurator**

14.1.1 Changing the web configurator password

For security reasons, you should frequently change the admin password for web configurator access.

There are two user roles with different user IDs, admin and user (→ p. 28). The user ID is disabled by default. You can activate it here.

The password is set depending on the user role. The administrator is allowed to change the password for both admin and user. Logged on as user you can only change the password for user

Admin access

New password ?

Repeat password ?

☐ Show password ?

User access

Activate user access ☐ Yes ☒ No

New password ?

Repeat password ?

☐ Show password ?



If you have forgotten the password, you will have to reset the device to the factory settings (→ p. 23).

New password (Admin)

► Enter a new password for the administrator access to the web configurator. Default: **admin/user**

Repeat password

► Repeat the new password entered in the **Repeat password** field.

System settings

Web configurator access rights

Show password

- ▶ To view the entered characters mark the check box near **Show password**.

Activate user access

- ▶ Click on Yes/No to enable/disable the ID for the user role.

Change password for all DECT Managers

- ▶ Click on the button, if you want the password to be assigned to all DECT managers.

The password can also be set individually for each DECT manager using the web configurator on the DECT manager systems.

Activate user access

- ▶ Click on **Yes/No** to enable/disable the ID for the **user** role.

14.1.2 Enabling CLI access to the device configuration

Only available in the Integrator user interface.

It is possible to perform the device configuration via CLI (Command Line Interface) using SSH from a remote system. Secure Shell (SSH) is a program for logging into a remote machine and for executing commands on a remote machine. It provides secure encrypted communications between two untrustworthy hosts over an insecure network.

CLI access via ssh

Activated if password is longer than 7 characters ?

✕

CLI Password (Admin) ?

Repeat password

☐ Show password ?

Detailed information on CLI commands can be found in the online help of the web configurator.


Activated if password is longer than 7 characters

The CLI access is automatically enabled if you have entered a valid password that has more than seven characters and click on the **Set** button. ✓ = enabled; ✕ = disabled

CLI Password (Admin)

- ▶ Enter a password for the administrator access to the configuration via SSH. Value: min. 8, max. 74 characters

Repeat password

 The user name for the CLI access is **cli**.

- ▶ Repeat the new password entered in the **CLI Password (Admin)** field.

Show password

- ▶ To view the entered characters mark the check box next to **Show password**.

System settings

Loading the web security certificate


14.2 Loading the web security certificate


Only available in the Integrator user interface.

The web configurator is protected by SSL/TLS security mechanism. That means that data transfer is encrypted and that the website is identified to be who it claims to be. The Internet browser checks the security certificate to determine that the site is legitimate. The certificate may be updated from time to time. If a new certificate is available you can download it to your computer or network and then upload it to the device.

Web security certificate

Web security certificate ?

File not uploaded  Delete

 Browse...

Web security password ?

- ▶ Click on **Browse...** next to **Web security certificate** and select the local certificate file from your computer's file system ▶ click on **Upload...** the selected certificate file is loaded and added to the certificate lists.
- ▶ If the certificate requires a password, enter it in the web security password field.

14.3 Capacity licensing

Only available on the Integrator.

▶ **Settings** ▶ **System** ▶ **Capacity licensing**


Capacity licensing

Item under Licencing	Available Licences	Used Licences	Status
Base licence	1	1	Activation period. Days left: 30
DECT Manager	100	2	Activation period. Days left: 30
Integrator Software	1	1	Activation period. Days left: 30
Application Connectivity	0	0	Activation period - expired

Licencing type ?

Remote CLA ▼

Address ?

 Refresh

When the system is booted for the first time you have 30 days to order and create a license. OpenScape Cordless IP V2 multicell system can be licensed either as product or as feature of OSBIZ.

Item under Licensing Features that are licensed:

Base License: One base station is needed to license the OpenScape Cordless IP V2 multicell system, i.e., it is needed for all deployments except where the system is licensed as a feature of the OSBIZ.

DECT Manager: Number of DECT managers of the system (1 in case of small and medium deployments).

Integrator Software: The integrator virtual/embedded (1 in case of large deployments)

Application Connectivity: In case of AML feature (→ p. 110) is used with remote CLA (1 to activate AML feature set independent of deployment)

Available Licenses

Feature quantity of the ordered licenses. During the activation period the maximum quantity is available.

Used Licenses

How many licenses are needed by the current configuration.

Status

Remaining days of the activation period (or expired). When a license is activated, the SIEL-ID of the license file is shown.

If an OpenScape Cordless IP V2 product license was ordered and created for a dedicated CLA server

- ▶ Select **Remote CLA** (Customer License Agent) from the **Licencing type** options menu.
- ▶ Enter the IP address of the remote license server where the license is imported.
- ▶ Click on **Set**.

If an OpenScape Cordless IP V2 product license was ordered and created on Cloud CLA

- ▶ Select **Cloud CLA** from the Licencing type options menu.
- ▶ Enter the DNS name of the Cloud CLA in the **Address** field (default: cloudcla.unify.com).
- ▶ Enter the license key from CLS for your license in the **Cloud License Key** field.
- ▶ Click on **Set**.

If an OSBIZ license with Cordless IP features was ordered

- ▶ Select **OSBiz** from the **Licencing type** options menu.
- ▶ Enter the IP address of the OSBiz where the license resides.
- ▶ Click on **Set**.

Updating the license information

- ▶ Click on **Refresh** . . . license information is updated based on the license on the CLA or OSBiz server.



For more information about licensing (especially which servers can be used as remote CLA) please refer to the service documentation for OpenScape Cordless IP V2.

14.4 Provisioning and configuration

This page allows you to define the provisioning server for the telephone system or download a configuration file and to start an auto-configuration process.

It is only available in the Integrator user interface for the user role admin

Provisioning is the process for uploading the necessary configuration and account data to the VoIP phones (here the DECT bases). This is done by means of profiles. A profile is a configuration file that contains VoIP phone-specific settings, VoIP provider data as well as user-specific content. It has to be available on an HTTP provisioning server which is accessible in the public (Internet) or local network.


Auto-configuration is defined as the mode of operation by which the telephone system connects automatically to a server and downloads both provider-specific parameters (such as the URL of the SIP server) and user-specific parameters (such as the user name and password) and stores them in its non-volatile memory. Auto-configuration is not necessarily limited to the parameters required for doing VoIP telephony. Auto-configuration can also be used to configure other parameters, e.g. settings for online service, if the VoIP phones support these features. However, for technical reasons auto-provisioning is not possible for all configuration parameters of the phone.


► Settings ► System ► Provisioning and configuration

Provisioning and configuration

Provisioning server

Auto configuration file

 Browse...

 Start auto configuration

This page allows you to define the provisioning server for the telephone system or download a configuration file and to start an auto-configuration process.

Provisioning server

- Enter the URL of your provisioning server in the text field. Value: max. 255 characters

Auto configuration file

If you have received a configuration file from your provider, you download it to the phone system.

- Click **Browse...** and select the configuration file from your computer's file system ► click on **Upload** . . . the selected configuration file is loaded.

Start auto configuration

- Click on the button . . . the provisioning profile is downloaded and installed on the system.



The process will take some time and requires a system restart. Connections with mobile devices will be terminated.

For security reasons you should save the configuration before you start an auto-configuration process (→ p. 124).

14.5 Security

The page allows you to organise the certificates used for secure internet communication and to define the credentials for HTTP authentication.

It is only available in the Integrator user interface for the user role **admin**.

► **Settings** ► **System** ► **Security**

14.5.1 Certificates

The phone system supports the establishment of secure data connections on the Internet with the TLS security protocol (Transport Layer Security). With TLS, the client (the phone) uses certificates to identify the server. These certificates must be stored on the base stations.

Certificates

Accept all certificates ? ☐ Yes ☒ No

Server certificates ?

Certificate Name	Status	Actions
Unify Production Default Certificate	Accepted	Remove, Details

CA certificates ?

Certificate Name	Status	Actions
		Remove, Details

Invalid certificates ?

Certificate Name	Status	Actions
		Accept, Reject, Remove, Details

Import local certificate ?

Accept all certificates

► Mark the **Yes** radio button, If you want to accept all certificates.

Server certificates / CA certificates

The lists contain the server certificates or CA certificates that have been certified by a certification authority (CA). The certificates in both lists have already been implemented by default or have been downloaded via the Web configurator and are classed as valid, i.e., have been accepted.

If one of the certificates becomes invalid, e.g., because it has expired, it is transferred to the **Invalid certificates** list.

System settings

Security

Invalid certificates

The list contains the certificates that have been received from servers but have not passed the certificate check, and certificates from the **Server certificates** / **CA certificates** lists that have become invalid. Accepting / rejecting invalid certificates

Accepting a certificate:

- ▶ Select the certificate and click on the **Accept** button . . . depending on its type, the certificate is transferred to one of the **Server certificates** / **CA certificates** lists (even if it has already expired). If a server responds again with this certificate, this connection is accepted immediately.

Reject a certificate:

- ▶ Select the certificate and click on the **Reject** button . . . the certificate is transferred to the **Server certificates** list with the label **Rejected**. If a server responds again with this certificate, this connection is rejected immediately.

Checking information about a certificate

- ▶ Select the certificate and click on the **Details** button. . . . a new web page appears, displaying the properties of the certificate.

Deleting a certificate from one of the lists

- ▶ Select the certificate and click on the **Remove** button. The certificate is deleted from the list immediately.

Import local certificate

You can make available further certificates to your phone system. The certificates must have been downloaded to your computer before.

- ▶ Click **Browse...** and select the local certificate file from your computer's file system ▶ click on **Upload** . . . the selected certificate file is loaded and, depending on its type, added to one of the certificate lists.

14.5.2 HTTP authentication

Define the credentials (user name and password) for HTTP authentication. The credentials are used for HTTP digest authentication of the provisioning client with the provisioning server.

HTTP Authentication	
HTTP digest username ?	<input type="text"/>
HTTP digest password ?	<input type="password"/>

HTTP digest username

- ▶ Enter the user name for HTTP authentication. Value: max. 74 characters

HTTP digest password

- ▶ Enter the password for HTTP authentication. Value: max. 74 characters

14.6 Date and time

By default, the system is configured so that the date and time are transferred from a time server on the internet. The page allows you to change the time servers, to set your time zone, and to make arrangements in case the internet time servers are not available.

It is only available in the Integrator user interface for the user role **admin**.

► **Settings** ► **System** ► **Date and time**

Date and time

Time server ?	0.europe.pool.ntp.org,1.europe.pool.ntp.org,
Last sync time ?	2021-10-05 13:19:14
Time Zone ?	(UTC+01:00) Europe/Berlin ▼
System time ?	2021-10-05 14:36
Act as Local Time Server ?	<input type="radio"/> Yes <input checked="" type="radio"/> No

Time server

There are some common time servers preset in the field.

- Enter your preferred time server in the text field. Multiple time servers can be entered separated by commas. Value: max. 255 characters

Last sync time

Time of last synchronisation.

Time Zone

- Select the time zone for your location from the option menu.

System time

Shows the time currently set for the phone system. It is updated every minute.

14.6.1 Fallback option

In case the internet time servers are not available you can set the time manually.

- Enter the time in the **System time** text field. Once you have started editing the automatic time update stops.

Act as Local Time Server

You can determine the internal time server to act as local time server for your network. If you have a time server available, you should not activate this function.

- Click on **Yes/No** to determine the internal time server to act/not to act as local time server.

System settings

Firmware



Date and time are synchronised system-wide on all base stations and handsets. It can take up to one hour until the manually changed time is visible on every handset.

Synchronisation is carried out in the following cases:

- If a handset is registered to the telephone system.
- If a handset is switched off and switched back on again, or is outside the wireless range of the telephone system for more than 45 seconds and then comes back into range.
- Automatically every night at 4.00 am.

You can change the date and time on the handset. This setting only applies for that handset and will be overwritten when the next synchronisation takes place.

The date and time are displayed in the format set for that handset.

14.7 Firmware

Use this page to make adjustments in order to keep the phone system up-to-date via firmware updates.

It is only available in the Integrator user interface for the user role **admin**.

Regular updates to the firmware for the Integrator/DECT manager and base stations are provided by Unify via SWS (Software Supply Server). You can upload these updates onto the Integrator as required.



The base stations' firmware is updated automatically by the DECT manager.

► Settings ► System ► Firmware

System firmware

Current version ?	V2R1.8.0 (V2.8.0+build.34d393b)
Backup available for previous version ?	V2R1.7.0 (V2.7.0+build.d9eeb81)
	Downgrade to any other version will reset device to factory settings.
URL to firmware file ?	<input type="text" value="http://localhost/swupdate/einstein_alt"/> <input type="button" value="Browse..."/>
Planned schedule ?	<input type="text" value="2018-07-31 11:45"/> <input checked="" type="checkbox"/> Immediately
Confirmed schedule ?	

14.7.1 Firmware of the local system

Current version

Shows the current firmware version of the Integrator/DECT manager on which you are logged in.

Backup available for previous version

You can downgrade the firmware by installing any older version. When installing a new firmware the system automatically creates a data backup for the recent firmware. If you later downgrade to this version the data backup will be installed on the system. This way you have a downgrade to previous firmware version and data settings.



Downgrade to any other version will reset the device to factory settings.

Selecting the firmware update file

- ▶ In the **URL to firmware** file text field specify the URL of the configuration server where the firmware is located.

or

- ▶ Click **Browse...** and select the firmware file from your computer's file system.

Starting the firmware update

At a specific date: ▶ Deselect the check box **Immediately** ▶ Enter the exact start time in the format: YYYY-MM-DD HH:mm

Immediately: ▶ Select the check box next to **Immediately** (default) . . . the firmware update is started when you click on the **Set** button.

Confirmed schedule

Shows **Immediately** or the date for the next planned firmware update.

- ▶ Click on **Set** to save the settings and to start the firmware update.

Once the update process starts, the system updates the DECT manager and all subordinate base stations automatically. No action is needed. The handsets lose their connection to the bases during the updating process. You can tell that the update has been successful when the handsets re-establish the connection to the base.

You can monitor in the base station list the current version of base station and the base station and DECT managers offline most likely for firmware update.



The firmware update may take up a longer period. Do not disconnect the devices from the local network during this time.

System settings

Save and restore

14.8 Save and restore

This page allows you to save and restore the system configuration.

It is available in the Integrator user interface for both the user role **admin** and **user**. The user is only allowed to save the settings but not to restore them..


► Settings ► System ► Save and restore

Once you have configured the phone system and after making any changes to the configuration, particularly registering or de-registering handsets, you should save the latest settings in a file on the computer so that the current system can be restored quickly if problems occur.


If you change the settings accidentally or you need to reset the device due to a fault, you can reload the saved settings from the file on your computer to your telephone system.

The configuration file contains all system data including the DECT registration data of the handsets, but not the calls list on the handsets.

Save settings



Restore settings

Settings file 

Saving configuration data

- Click on **Save settings** ► Select the location where the configuration file should be stored using the system file selection dialogue. Enter a name for the configuration file.

The default file name is

<MAC address of integrator><firmware version><date of export>_device-settings

Restoring configuration data

- Click on **Browse...** ► Select the previously saved configuration file from the file system of your computer. ► Click on **Upload** . . . the selected configuration file is loaded.



The secure configuration file can also be loaded onto a new device.

Prerequisites:

- The old device must no longer be in operation.
- The firmware version of the new device must correspond, at least, with the version of the device from which the data is saved, including the set patches.


Automatic backup

You can automatically back up your configuration to an SFTP server at regular intervals (SFTP = Secure File Transfer Protocol).

Enable automatic backup

- Select the check box next to **Enabled** . . . the automatic backup of your configuration is activated according to the following settings when you click on the **Set** button.

Server

- ▶ Enter the address of the server to which the backup should be sent.
 -  The URL must end with a slash (/), otherwise the SFTP upload will not start

Example: 192.168.178.200/

The system creates a backup file with the following name:

<MAC address>_<software version>_YYYY_MM_DD_device-settings

You can also enter the name of the file directly:

Example: 192.168.178.200/system_backup.cfg

Server port

- ▶ Enter the port number, where the SFTP server expects to receive requests (default: 22).

Authentication name

- ▶ Specify the authentication name for the access to the SFTP server.

Authentication password

- ▶ Enter the password for the access to the SFTP server.

Planned schedule

At a specific date:

- ▶ Deselect the check box **Immediately** ▶ Select one or more days of the week on which a backup should be executed ▶ Enter the start time in format: HH:MM

Immediately:

- ▶ Select the check box to **Immediately** ... the backup is started when you click o the **Set** button.

Confirmed Schedule

Shows **Immediately** or the date for the next planned backup.

System settings


Reboot and reset

14.9 Reboot and reset

This page allows you to reboot the device and to reset the system to factory settings.. It is available in the Integrator user interface for both the user role admin and user

► **Settings** ► **System** ► **Reboot and reset**

14.9.1 Manual reboot



The screenshot shows a web interface for rebooting a device. At the top, there is a header 'Reboot'. Below it, on the left, is the label 'Device'. On the right, there is a button labeled 'Reboot now' with a power icon.

► Click on **Reboot now** ► Confirm with **Yes** . . . the reboot starts immediately.



On a system with embedded Integrator you can decide, if you want to reboot the local DECT manager too. All existing connections managed by the affected base stations are terminated.

To reboot one single DECT manager: → p. 38

To reboot one single base station: → p. 54


14.9.2 Reset to factory settings

All configuration settings can be reset to the factory default. This will delete all settings, disconnect all connections, and terminate all calls!



When resetting to factory defaults all settings are lost. You can save your current configuration previously (→ p. 124).

Factory reset can also be performed by using the device key (→ p. 20).



The screenshot shows a web interface for resetting to factory settings. At the top, there is a header 'Reset to'. Below it, on the left, is the label 'Reset to device' with a question mark icon. To the right of the label is a dropdown menu showing 'Integrator only - dynamic IP'. Below the dropdown menu is a button labeled 'Reset to' with a circular arrow icon.

Defining the role

- From the Reset to device option menu select the role the device should have after the reset.

Base only

The device is used as base station.

All in one - dynamic IP

The roles Integrator + DECT manager + base station are active. The network configuration is set to dynamic IP.

All in one - static IP

The roles Integrator + DECT manager + base station are active. The network configuration is set to the following static IP settings:

IP address: 192.168.143.1
Subnet mask: 255.255.0.0
Gateway: 192.168.1.1

DECT-Manager+Base - dynamic IP

The roles base station + DECT manager are active. The network configuration is set to dynamic IP.

DECT-Manager+Base - keep IP

The roles base station + DECT manager are active. The network configuration is set to static IP.

Integrator only - dynamic IP

Only the Integrator role is active in the device. The network configuration is set to dynamic IP.

Integrator only - keep IP

Only the Integrator role is active in the device. The network configuration is set to static IP.



If you have installed the Integrator on a virtual machine

- only the **Integrator only** roles are available (→ p. 20).
- you have to use the device key in order to reset the devices (p. 22).

System settings

DECT settings

Resetting the device

- Click on the **Reset to** button to reset the device to factory condition according to the selection made in **Reset to device** . . . a confirmation dialogue is opened ► confirm with

Yes The **Save and restore** page is opened allowing you to save the current configuration on your computer (→ p. 124).

No The reset procedure starts at once. The current configuration will be lost.

Cancel The reset procedure is interrupted.

14.10 DECT settings

This page allows you to make settings for the DECT radio network.

It is only available in the Integrator user interface for the user role admin.

Settings ► System ► DECT settings

DECT settings

Change of these settings forces a restart of the DECT interface: Running calls will be cancelled.

Eco DECT

DECT Radiation power ? ☒ Maximum range ☐ Limited range

DECT Security Settings

DECT Encryption ? ☒

Enhanced Security - Early Encryption and Re-Keying ? ☒

Enhanced Security - Automatic release for non-encrypted calls ? ☒

DECT Radio settings

Please select the DECT frequency band your system should operate according to your region. This is a system wide setting. Changing the setting will reboot the DECT radio part. Wrong setting may cause violation of legal regulations. In case of doubt, contact your Telecommunications Authority.

DECT Radio band ? ☒ 1880 MHz - 1900 MHz (Europe)
☐ 1910 MHz - 1930 MHz (Latin America)
☐ 1910 MHz - 1920 MHz (Brazil)
☐ 1880 MHz - 1895 MHz (South East Asia)



Changing one of these settings requires a restart of the system. Ongoing calls will be cancelled.

ECO DECT

ECO DECT is an environment-friendly technology which reduces the power consumption and enables a variable reduction of transmission power.

DECT Radiation power

- ▶ Set the DECT radiation power to your needs:

Maximum range: The device range is set to maximum (default). This guarantees the best connection between the handset and the base stations. In idle status, the handset will not send radio signals. Only the base station will maintain contact with the handset via a low wireless signal. During a call, the transmission power automatically adapts to the distance between the base station and handset. The smaller the distance to the base, the lower the radiation.

Limited range: The radiation is reduced by up to 80 %. This will also reduce the range.

DECT security settings

DECT radio traffic between base stations and handsets is encrypted by default. The following options allow you to define the security settings in more detail.

DECT Encryption

- ▶ Activate/deactivate the option.

Activated: All calls are encrypted.

Deactivated: No calls are encrypted.

Enhanced Security - Early Encryption and Re-Keying

- ▶ Activate/deactivate the option.

Activated: The following messages are encrypted:

- ▶ CC (Call Control) messages in a call
- ▶ Data that may be sensitive at early stages of the signalling, e.g., dialling or CLIP information sending

The key used for encryption is changed during an ongoing call and thus improving the security of the call.

Deactivated: No CC messages or early data are encrypted.

System settings

DECT settings

Enhanced Security - Automatic release for non-encrypted calls

- ▶ Activate/deactivate the option.

Activated: If encryption is activated, it will be released in the case that a call is initiated by a device that is not supporting encryption.

Deactivated: Encryption is never released.

DECT radio settings

Due to different national regulations DECT units are required to use different frequency ranges to make them compatible with DECT systems in other areas. You can adapt the frequency range of the OpenScape Cordless IP V2 to the requirements of your region.

DECT Radio band

- ▶ Select the radio frequency band used in your region.



Please select the DECT frequency band your system should operate according to your region. This is a system wide setting. Changing the setting will reboot the DECT radio part. Wrong setting may cause violation of legal regulations. In case of doubt, contact your Telecommunications Authority.

15 Diagnostics and troubleshooting

15.1 Status information

The status page offers important information on the system operation and the involved devices.

► Status ► Overview

The following information is provided:

Integrator status

- Device name
- Device role
- MAC address
- IP address
- DECT Frequency band
- DECT PARI
- Firmware version
- Date and time
- Last backup
- License information

DECT managers

- Number of DECT managers
- Number of DECT managers with deviating Firmware Version

Base stations

Only with a multicell system

- Number of active base stations
- Number of pending base stations
- Number of online base stations
- Number of offline base stations
- Call limit for base station

Mobile devices

- Number of registered mobile devices (reachable/all)
- Number of mobile devices to register
- Number of mobile devices with SIP registration(connected/all)



The list shows the items that are shown on the Integrator. Items marked by an asterisk (*) are also displayed on the status page of the DECT managers.

► Click on **% See also...** in the header line . . . a list of all pages providing information or settings for diagnostic purposes is shown.

Diagnostics and troubleshooting

Base station events

System backup

Besides **Last backup** date and time of the last backup is shown. As long as no backup has been created, **Never** is displayed instead.

Creating a new backup or restoring an existing backup file:

- Click on  **System** ► **Save and restore** . . . the **Save and restore** page is opened.
(→ p. 124)

Administration of DECT manager, base stations or mobile devices

For DECT managers, base stations, and mobile devices you can directly jump to the associated Web configurator page.

- Click on the  button next to the corresponding entry in the table.

15.2 Base station events

This page displays counters for diagnostic purposes relating to various events that affect the base stations, e.g. active radio connections, handovers, unexpectedly terminated connections, etc.

It is available in the Integrator user interface for both the user role admin and user.

► Status ► Statistics ► Base stations

Base stations

Choose column

Condition

Filter

Clear

View

DECT Manager: DM1

2021-10-04 11:45:02 - 2021-10-06 13:27:29

Missed calls: 0

Active calls: 0

Cluster: 1-c

Conn: 18

Ho setup: 0

Ho release: 0

Call drops: 0

Async: 0

Busy: 0

Conn. drops: 0

Active calls: 0

Sync swaps: 0

Base station: LocalBS

0

0

0

0

0

0

Base station: BS 7c2f80e0d639

0

0

0

0

0

0

Base station: BS 7c2f80e0d670

0

0

0

0

0

0

Base station: BS 7c2f80e0d68b

0

0

0

0

0

0

DECT Manager: DM2

2018-07-04 03:42:02 - 2018-07-04 10:56:04

Missed calls: 0

Refresh all

Reset all

Export


Show Cluster graph

The following information is given:

DECT manager Name of the DECT manager responsible for the base stations, time period in which the events have been collected, total number of missed and active calls of all managed base stations within the given time period.

Missed Calls: These are incoming calls that were successfully received by the DECT manager but did not reach the handset, e.g. due to insufficient coverage. This does not refer to missed calls by the user.

- ✕ Click on  next to the **DECT manager** entry to display the clusters of the DECT manager.

Note: The symbol  next to the DECT manager name indicates that there could be a situation which requires attention.

Cluster Cluster number, summary of the collected events for all cluster base stations

- ✕ Click on  next to the **Cluster** entry to display the base stations of the cluster.

Base station Name of the base station



Some of the following information may be hidden. Use the **View** option menu to display the desired columns.

Properties


MAC address	MAC address of the base station
RPN	Radio Fixed Part Number, identifying the radio-entity
Sync RPN	RPN of the other base station the base station is synchronising with
Sync Level	Synchronisation level

Statistics

Conn	Number of established connections on DECT MAC layer. For example, through user actions: VoIP calls, accesses to an online phone book, Internet connections, etc. Or through system actions: Updating idle displays, date/time synchronisation, locating handsets for roaming, etc.
Ho setup	Number of incoming handovers
Ho releasee	Number of outgoing handovers
Call drops	Number of lost connections, i.e. interrupted calls
Async	How often the base station has lost on-air DECT synchronisation
Busy	How often the maximum number of possible connections of the module was achieved. The base station has entered busy-state and pointed to other modules for load balancing.
Conn. drops	How often the LAN connection to the base station was interrupted
Calls	Active calls
Calls-pk	Peak number of parallel calls
Sync swaps	Number of sync swaps, i.e. , how often the sync master has been changed due to a sync master crash.
q-idx-lt	LAN synchronisation quality > 90% > 93%
o-thr-exc	PTP offset threshold exceeded counter If the PTP deviation > 500 ns, the counter is increased. The requirement for the network is that the PTP deviation is < 500 ns.
d-thr-exc	DLS offset threshold exceeded counter If the DLS deviation > 1000 ns, the counter is increased.

15.2.1 Actions

Displaying detailed statistical data on the base stations

- Click on the  button next to the name of a base station . . . statistical evaluations about the base station synchronisation as well as further system information are output

Exporting the information into a CSV file

For further processing of the statistic data you can export the data into a file with CSV (Comma separated Value) format.












- Click on **Export**. Select the location where the file should be stored using the system file selection dialogue.

Displaying a graphical view of the cluster hierarchy


You can open a graphic that shows the cluster base stations, their relationship to the surrounding base stations, and the synchronisation hierarchy.

- Open the cluster tree of a DECT manager Select a cluster Click on **Show Cluster graph** . . . the base stations of the selected cluster are shown in a graphic.

Presentation:

Connections		RSSI range 43 -100, good - excellent
		RSSI range 0 - 42, poor
		No data available
Base Status		Active and synchronised
		Other status (click on the symbol for more information)
		Deactivated
Synchronisation Mode		DECT, internal synchronisation
		DECT, external synchronisation
		LAN, internal synchronisation
		LAN, external synchronisation
		RFPI, external synchronisation

Example:



Saving the graph as a file: Click on Save image Select the location where the graphic file should be stored using the system file selection dialogue . . . the graph is stored in PNG format.

Resetting the statistics

- Click on **Reset all** . . . the counters in the table are reset to 0.

Filtering the list

- From the **Choose column** option menu select the column for which you want to set a filter.
- In the text field enter the filter criteria ► Click on **Filter** . . . only the entries matching the filter are shown.

For filtering the list according to specific counter values the following operators are possible:

< less than > more than = equal to

<= less or equal >= more or equal

For the **MAC address** column only the following condition is allowed: = MAC address

The MAC address must be in the following format: **aabbccddeeff** (without colons)

Deleting the filter: Click on Clear

Examples:

Only base stations with more than 20 busy situations should be displayed in the table. This could be achieved by the following filter settings.

Busy ▼

>20

Filter

✕ Clear

Only base stations with less than 5 call interruptions should be displayed in the table. This could be achieved by the following filter settings.

Diagnostics and troubleshooting

Incidents

Call drops ▾

<5

Filter

✕ Clear

Displaying/ hiding columns

- ▶ Click on the **View** option menu on the right ▶ Select the columns you want to be displayed in the table (👁 / 👁 = displayed/hidden).
- Names of columns which cannot be hidden are greyed out.

15.3 Incidents

The page contains information on incidents concerning DECT manager operation.

It is available in the Integrator user interface for both the user role admin and user. The user is not allowed to delete entries.

▶ Status ▶ Statistics ▶ Incidents

Incidents				
<input type="checkbox"/> Timestamp ▾	DM Name ▾	Incident Type ▾	Severity ▾	Info ▾
<input type="checkbox"/> 2019-06-11 18:43:42	local	Reboot	Info	Reboot occurred
<input type="checkbox"/> 2019-06-07 12:28:28	local	Process termination	Info	lighttpd terminated

10 entries ▾

Refresh

Download

Delete

Timestamp	Date and time of the incident
DECT manager	DECT manager affected
Incident Type	e.g. Crash, Reboot, Reset
Severity	Degree of severity: Critical, High, Medium, Low, Info
Info	Detailed information, e.g., the component producing the problem

15.3.1 Actions

Downloading detailed information to a file

To get detailed information about the circumstances causing the error, you can download the incident information to a file. If required, you can pass it to the responsible service personnel.

- ▶ Mark the check box next to one or more incidents you want to download or next to **Timestamp**, if you want to download all incidents.

- ▶ Click on **Download** and select the desired file location for the log files in the file system . . . for each selected incident a log file is created. All log files are taken into a tar file.

Deleting entries

- ▶ Mark the check box next to one or more incidents you want to delete or next to **Timestamp**, if you want to delete all incidents.
- ▶ Click on **Delete**.

Refreshing the list

- ▶ Click on **Refresh**, to update the information in the table.

15.4 System log and SNMP manager

The system report (SysLog) gathers information about selected processes performed by the DECT manager and base stations during operation and sends this to the configured SysLog server.

It is only available in the Integrator user interface for the user role **admin**.

- ▶ **Settings ▶ System ▶ System log**

System log

☐ Activate system log ?

Server address ?

Server port ?

514

Transport protocol ?

UDP

↻ Use on all DECT Managers

Log level ?

☒ Info

☐ Debug

☒ Warning

☒ Error

Activate system log

- ▶ Mark/unmark the check box to activate/deactivate the logging function.

Server address

- ▶ Enter the IP address or the (fully qualified) DNS name of your Syslog server. Value: max. 240 characters

Server port

Diagnostics and troubleshooting

System log and SNMP manager

- ▶ Enter the port number, where the Syslog server expects to receive requests.

Range: 1-65535; Default: 514

Transport protocol

- ▶ Select the transport protocol used for communication with the Syslog server.

Log level

- ▶ Mark/unmark the check boxes next to the log information that should be included/not included in the system log.

If you want to use the same system log server configuration for all DECT managers:

- ▶ Click on the **Use on all DECT Managers** button



To set up the system log server individually for each DECT manager p. 31

15.4.1 SNMP statistics

The Simple Network Management Protocol (SNMP) is a common protocol used for monitoring and controlling of network devices. To gather management and statistic information concerning base station events to be processed by an SNMP manager you have to enter the address and authentication information according to the SNMP server configuration. SNMPv3 is supported, with authentication and privacy communication.

SNMP statistics

SNMP manager address ?	0.0.0.0
SNMP manager port ?	162
SNMP username ?	admin
SNMP password ?	snmp-admin
↶ Use on all DECT Managers	
⬇ Download MIB	

- ▶ Enter the IP address of the SNMP manager server in the **SNMP manager address** field and the port number used by the SNMP manager in the **SNMP manager port** field. Default: 162

To access the SNMP database authentication is necessary.

- ▶ Enter the **SNMP username** and the **SNMP password**.

The SNMP manager access data can be set for all DECT managers here or for each individual DECT manager (p. 31).

- ▶ If the access data defined here should be used for all DECT managers, click on **Use on all DECT Managers**.

Configuration

OpenScape Cordless IP V2 default configuration

User name: admin
Authentication protocol: SHA
Password: snmp-admin
Privacy protocol: AES
Target for SNMP traps (SNMP manager IP address and port): 0.0.0.0:162

SNMP manager configuration example

Target host: OpenScape Cordless IP V2 IP address
User name: admin
Target port: 161
Security level: Auth, Priv
Authentication protocol: SHA
Authentication password: snmp-admin
Privacy protocol: AES128
Privacy password: snmp-admin

SNMP-Kommandos (Beispiele):

Obtaining MIB information starting from a specific MIB variable:

```
snmpwalk -v3 -l authPriv -u admin -a SHA -A snmp-admin -x AES -X snmp-admin "ipaddress" 1.3.6.1.4.1.32775.1.1.1
```

Obtaining next information in the MIB tree:

```
snmpgetnext -v3 -l authPriv -u admin -a SHA -A snmp-admin -x AES -X snmp-admin "ipaddress" 1.3.6.1.4.1.32775.1.1.1.1
```

Configuring SNMP-Traps:

```
trapsess -v 3 -u admin -l AuthPriv -a SHA -A snmp-admin -x AES -X snmp-admin "ipaddress"
```

Storing management information in MIB format

You can store management information for all base stations in MIB syntax.

- ▶ Click on **Download MIB** ▶ Select the location where the MIB file should be stored using the system file selection dialogue . . . the file with the MIB information is stored in TXT format.

16 Diagnostics

For diagnostic purposes you can create a dump with different contents. A dump may help software developers and system administrators to diagnose, identify and resolve problems that led to system failures.

Settings ▶ System ▶ Diagnostics

Diagnostics

Download logs with:

- ☐ Core dump
- ☐ Ram dump
- ☐ Last incident sysdump
- ☒ Save settings

 Download

A standard set of diagnostic info will be downloaded. Additionally you can add following options:

- Core dump** Includes, if available, a core dump of a crashed application.
- Ram dump** Includes, if available, a RAM dump of a crashed CSS (co-processor for DECT and media real-time processing).
Core dump and CSS RAM dump can be used by service personnel for post-mortem debugging. Because the file size is several MBytes, not all data can be collected due to limited overall sysdump file size. Therefore, these options should be used carefully.
- Last incident sysdump** Dump of the last incident. Contains only the system memory part that represents the last incident.
- Save settings** If the option is activated, the diagnostic file contains the complete backup (default). A full backup makes problem resolution faster because all settings are included.
The option can be deactivated if the client does not want to include such a backup for confidentiality reasons. In this case, the check mark must be removed each time a diagnostic file is created.

- ▶ Mark the check mark next to the dump type you want to include.
- ▶ Click on **Download** ▶ Select the location where the dump file should be stored using the system file selection dialogue. Enter a name for the dump file. The file is stored as tar archive. The default file name is
<MAC address of integrator><firmware version><date of export>_diagnostics.tar

17 Migration

In order to migrate a small or medium OpenScape Cordless IP V2 multicell system with one single DECT manager into a multi DECT manager installation, please perform the following steps:

- 1 Install the required licences, see → p. 116
- 2 Export the base station and handset configuration of your current installation
 - ▶ **Settings ▶ Base stations ▶ Administration**, see → p. 51
 - ▶ **Settings ▶ Mobile devices ▶ Administration**, see → p. 81
- 3 Import the integrator virtual machine (*.ova file) into hypervisor, see Installing the Integrator (large installation)
- 4 Define the device role for the devices that are defined to act as DECT manager in the future
- 5 Add DECT managers to the Integrator's administration
 - ▶ **Settings ▶ DECT manager ▶ Administration**, see → p. 37
- 6 Register the DECT managers on the Integrator
 - ▶ **Settings ▶ System ▶ Integrator Config**, see → p. 45
- 7 Import the base station and handset configuration into the new configuration
 - ▶ **Settings ▶ Base stations ▶ Administration**, see → p. 51
 - ▶ **Settings ▶ Mobile devices ▶ Administration**, see → p. 81
- 8 Set up the new base station synchronisation hierarchy
 - ▶ **Settings ▶ Base stations ▶ Synchronization**, see → p. 56
- 9 If necessary, set up cross-cluster synchronisation via DECT manager synchronisation
 - ▶ **Settings ▶ DECT manager ▶ Synchronization**, see → p. 37



During migration the base station synchronisation will be lost. Ongoing calls would be cancelled. Please ensure, that the phone system is not in use during the migration procedure.

The base station import does not contain the data of the local base station, because the local base station is physically bound to the new DECT manager.



The procedure only applies to the migration of a first DECT manager to a new multi DECT manager system. The handsets of a second system imported into the multi DECT manager system cannot import their old system PARI into the new multi DECT manager installation, thus these handset will be imported as To register and need to repeat on air DECT registration procedure.

Base station import of a second system does not need repetition of base station registration.

18 Using handset connected to a BSIP2 base

The functions of your OpenScape Cordless IP V2 are available on the registered handsets. The functions of the telephone system are added to the handset menu. Handset-specific functions, e.g., local directory or organiser, are not described here. Information about this will be found in the relevant handset user guide. The availability of functions or their designations may differ on individual handsets.

18.1 Making calls

You can make calls using any handset registered to your OpenScape Cordless IP V2.

Prerequisite: You are located in the cell of at least one of the base stations registered to the telephone system.

The cells of the base stations together form the DECT wireless network of the telephone system. You can initiate or answer calls on a handset across the whole wireless network and change cells during a call (handover).

Prerequisite for handover: The base stations involved must be assigned to the same cluster and must be synchronised | (→ p. 56).

Each handset is assigned a send and receive connection (→ p. 86).



If your OpenScape Cordless IP V2 is connected to a PBX that permits the formation of groups, VoIP connections can also be assigned to groups. In this case, you will also receive calls on your handset that have been sent to your group number.

The OpenScape Cordless IP V2 uses a VoIP Communication System or the services of a VoIP provider for Internet telephony. The availability of some phone functions depends on whether they are supported by the PBX/provider and whether they have been enabled. If necessary, you can obtain a description of the services from the operator of your PBX.





Depending on the specifications of your PBX, you may need to dial an access code for calls outside the area covered by your VoIP PBX (→ p. 99).

18.1.1 Calling

► . . . use  to enter a number ► **Briefly** press the Talk key 

or

► Press and **hold** the Talk key  ► . . . use  to enter a number




The connection is established using the SIP connection assigned to the handset (→ p. 86).



If you make a call to the fixed line network, you may also have to dial the area code for local calls (depending on the PABX/provider). This is not necessary if the area code is entered in the telephony configuration (→ p. 99).

18.1.2 Dialling from the redial list

The redial list contains the numbers last dialled with the handset.

- ▶ **Briefly** press the Talk key  . . . the redial list is opened ▶ . . . use  to select an entry ▶ Press the Talk key 

Dialling from the call list

The call lists contain the most recent accepted, outgoing and missed calls.

-  ▶ . . . use  to select  **Call Lists** ▶ **OK** ▶ . . . use  to select a list ▶ **OK** ▶ . . . use  to select an entry ▶ Press the Talk key 



The **Missed Calls** list can also be opened by pressing the Message key .

18.1.3 Initiating ringback

If the number you have called is engaged or the participant called does not reply, you can arrange a ringback if your PBX/provider supports the CCBS and CCNR services.

CCBS (Completion of Call to busy Subscriber) Ringback if busy

CCNR (Completion of Calls on No Reply) Ringback if no answer

The service code for activating/deactivating CCBS, CCNR must be configured with the provider settings (→ p. 79).

Activating ringback:


- ▶ Enter the service code defined for the PBX/provider, e.g., *6

If you decide you do not want a ringback, you can switch the function off again:

- ▶ Enter the service code defined for the PBX/provider, e.g., #6

18.2 Accepting calls

Incoming calls for the connection assigned to your handset are signalled.

► Press the Talk key  to accept the call.

Switch off ringtone: ► **Silence** . . . the call can be accepted for as long as it is shown on the display

Reject a call: ► Press the End call key 

Information about the caller

The caller's phone number is displayed, if provided. If the caller's number is saved in the directory, the name is displayed.

Using a PBX call manager

In case a PBX call manager is used it is possible to define that incoming calls are accepted directly via headset or handsfree. This has to be configured for the handset via web configurator in the **Call manager** section (→ p. 90).



18.2.1 Group pickup

You can also accept incoming calls for the group.

Group pickup must be activated and the call number or SIP URI of the group must be entered. This has to be configured for the handset via web configurator in the **Group pick-up** section (→ p. 89).

18.2.2 Accepting/rejecting call waiting


A call waiting tone indicates a call during an external call. The number or the name of the caller is displayed if the phone number is transferred.

- Reject a call: ► **Options** ►  **Reject waiting call** ► **OK**
- Accept a call: ► **Accept** ► . . . speak to the new caller. The previous call is placed on hold.
- End the call, resume the on-hold call: ► Press the End call key .

18.3 Conversation with three participants


18.3.1 Consultation calls

Make another external call during an external call. The first call is placed on hold.

► **Ext. Call** ► . . . use  to enter the number of the second participant . . . the active call is placed on hold and the second participant is called

If the second participant does not answer: ► **End**


Ending a consultation call

► **Options** ►  **End Active Call** ► **OK** . . . the connection to the first caller is reactivated

Using handset connected to a BSIP2 base


Conversation with three participants

or


- ▶ Press the End call key  . . . a recall to the first participant is initiated

18.3.2 Call swapping

Switching between two calls. The other call is placed on hold.

- ▶ During an external call, dial the number of a second participant (consultation call) or accept a waiting caller . . . the display shows the numbers and/or names of both call participants
- ▶ Use the control key  to switch back and forth between participants

Ending a currently active call

- ▶ **Options** ▶  **End Active Call** ▶ **OK** . . . the connection to the other caller is reactivated

or

- ▶ Press the End call key  . . . a recall to the first participant is initiated

18.3.3 Conference

Speaking to both participants at the same time.

- ▶ During an external call, dial the number of a second participant (consultation call) or accept a waiting caller . . . then


Initiate conference call:


- ▶ **Confer.** . . . all callers can hear one another and hold a conversation with one another

Return to call swapping:

- ▶ **End Conf.** . . . You will be reconnected to the participant with whom the conference call was initiated



End call with both participants:

- ▶ Press the End call key 

Each of the participants can end their participation in the conference call by pressing the End call key  or hanging up.

18.3.4 Call transfer

Connecting an external call with a second external participant.

- ▶ Use the display key **Ext. Call** to establish an external consultation call ▶ . . . use  to enter the number of the second participant . . . the active call is placed on hold . . . the second participant is called ▶ press the End call key  (during a conversation or before the second participant has answered) . . . the call is transferred



Call transfer options must be set correctly for the PBX/provider (→ p. 76).

18.4 Message indication

Notifications about accepted and missed calls, missed alarms and messages on the network mailbox are saved in messages list and can be displayed on the handset display.


Which messages are displayed on the handset is defined during handset configuration in the **Missed calls and alarms** section (→ p. 90).

Missed/accepted calls count

If the option is activated, the number of missed and accepted calls will be shown on the handset display in idle mode.

Message Waiting Indication (MWI)

For each message type (missed call, missed alarm, new message the network mailbox) the MWI option can be activated or deactivated via the web configurator.

If activated, the LED on the message key  flashes, in the case a **new message** arrives indicating missed calls, cating missed calls, missed alarms or new messages on the network mailbox.

18.5 Using directories


The options are:

- The (local) directory for your handset (see handset user guide)
- Corporate directories provided by an LDAP server (→ p. 151).


The directories available are defined by the web configurator of the telephone system (→ p. 101).

18.5.1 Opening directories

Opening the corporate directory using the INT key

The INT key  (press left on control key) on the handsets opens a corporate directory, provided that this is set up via the web configurator using the **Corporate directory for INT key** option and can be accessed by the telephone system. The directory to be opened can be set for each handset, see →p. 88.

Opening directories using the directory key

The directory key  (press down on the control key) for the handset is normally set as follows:

- Press **briefly** to open the selection of available online directories.
- Press and **hold** to open the local directory.

This assignment can be changed for each handset via the web configurator using the **Directory for direct access** option (¢ p. 87). Direct access can be assigned to a specific online directory. In this case, open the local directory by pressing and holding the directory key.

The description below assumes the default assignment.

Using handset connected to a BSIP2 base

Using the network mailbox

Opening directories via the menu

Depending on the handset used you can access all available directories also via the handset's menu:

►  ► . . . use  to select  **Directory** ► **OK**
List of all online directories set up on the telephone system.

►  ► . . . use  to select  **Net Directories** ► **OK**

The directories are displayed with the names specified in the web configurator.

The directories are displayed with the names specified in the web configurator.

Example for handling a corporate directory on the handset (→ p. 157).



If handsets are connected to a OpenScape Cordless IP V2, it is not possible to transfer entries from the local directory to another handset.

18.6 Using the network mailbox

The network mailbox accepts incoming calls made via the corresponding line (corresponding VoIP phone number).

In order to record calls, a network mailbox must be set up for the VoIP connection assigned to the handset. This is done during handset configuration in the **Network mailbox configuration** section (→ p. 89).

Prerequisites

In order to allow the user to listen voice messages stored on a network mailbox the following settings are necessary:

On the VoIP PBX (Telephony Server)

► Set up a network mailbox for the VoIP connection that is to be assigned to the handset.


On the OpenScape Cordless IP V2

► ✕ In the provider/PBX configuration activate the **SIP SUBSCRIBE for Net-AM MWI** option (p. 55). A subscription is established for the purpose of receiving notifications about new messages on the network mailbox.



► In the mobile devices configuration enter the **Call number or SIP name (URI)** and activate the network mailbox in the **Network mailbox configuration** section (p. 67).

► Optional: In the mobile devices configuration enable the **Flashing LED (MWI) for network mailbox** option (p. 68). New messages on the network mailbox are indicated by the MWI light on the Message key.

Playing back messages on the handset


► Press and **hold**  (if key 1 has been assigned to the network mailbox)

or

► Press the Message key  ► ... use  to select the network mailbox ► **OK**

or

►  ► ... use  to select  **Voice Mail** ► **OK** ► **Play Messages** ► **OK** ►
 Network Mailbox ► **OK**

Listen to announcement out loud: ► Press the handsfree key 

Using handset connected to a BSIP2 base

Using the network mailbox

19 LDAP directory – configuration example


To allow the entries of an LDAP directory to be displayed on the handsets, you will need to configure the phone's LDAP client. This involves the following:


- Setting up access to the LDAP server and database
- Specifying the attributes to be displayed (→ p. 153)
- Defining search criteria (filters) (→ p. 153).

19.1 Access to the LDAP server

To ensure that entries from the LDAP database are displayed on the phones, enter the access data via the web configurator.

► **Settings ► Online directories ► Corporate**

- Click on  next to the name of the LDAP directory you want to edit . . . the LDAP configuration page is opened.



- Enter a name for the directory in the Directory name field.
This is the name under which the directory will appear in the list of network directories on the telephones (→ p. 157).
- Select the option **Enable directory**, so that the directory will be displayed on the telephones.
- Enter the access data for the LDAP server
- | | |
|----------------------------|---|
| Server address | IP address or domain name of the LDAP server, e.g. 10.25.62.35 or ldap.example.com |
| Server port | Port on which the LDAP server expects queries from the clients. Normally the port number 389 is used (default). |
| Username / Password | Credentials for access to the LDAP server. |



It is also possible to use individual access data for each handset (→ p. 86).

LDAP directory – configuration example

Access to the LDAP server

LDAP Search base (BaseDN)

The **LDAP Search base (BaseDN)** parameter specifies the starting point for the search in the LDAP directory tree. This starting point must be defined on the LDAP server and entered here for the LDAP client according to the server configuration. BaseDN is a special LDAP name which represents an object including its position in a hierarchical directory.

BaseDN is used to define which section of the hierarchical LDAP database is to be searched. Access to the entire directory can be enabled (e.g. to the corporate directory) or only to a subdirectory (e.g. the directory of a particular organisational unit).

BaseDN is created from series of RDNs (Relative Distinguished Names) found by walking up the directory information tree.

The BaseDN is specified as follows:

- The directory hierarchy is specified from left to right from the lowest level to the highest, e.g. object, organisational unit, organisation, domain.
- A hierarchical level has the following format: keyword=object, e.g. cn=PhoneBook.
- Hierarchical levels are separated by commas.
- It must be unique in the directory information tree.

The following objects are often used as hierarchical levels:

cn: common name
ou: organisational unit
o: organisation
c: country
dc: domain component

But other objects can also be used. For this parameter you require information on the structure of the LDAP server.

For the meaning of the objects, see section Filters (→ p. 153).

Examples:

Starting point: Object PhoneBook, in the domain example.com

Definition: cn=PhoneBook,dc=example,dc=com

Starting point: Object PhoneBook in the subdirectory sales/support, in the domain example.sales.com.

Definition: cn=PhoneBook,o=support,ou=sales,dc=example,dc=sales,dc=com

19.2 Filters

With filters you define criteria by which the phone searches for certain objects in the LDAP database

- The name filter determines which attributes are used in the search for directory entries.
- The number filter specifies which attributes are used for the automatic search in the LDAP database when phone numbers are entered.
- Additional filters can be defined to enable detailed search

Search in LDAP database

☒ Enable list mode

Name filter

((cn=%)(sn=%))

Number filter

((telephoneNumber=%)(mobile=%))

Additional filter #1 name

City

Additional filter #1 value

((l=%))

Additional filter #2 name

Street

Additional filter #2 value

((street=%))

Display format

%sn, %givenName

Max. number of search results

50



The LDAP protocol offers various setting options for filters and search functions, e.g. wildcards, fixed character strings and further operators. For full details see the [RFC 4515](#).

19.2.1 Filter format

A filter consists of one or more criteria. A criterion defines the LDAP attribute in which the entered string is to be searched for, e.g. `sn=`. The percent sign (%) is a placeholder for the user input.

Operators

Following operators can be used to create filters:

Operator	Meaning	Example
=	Equality	(attribute1=abc)
!=	Negation	(!(attribute1=abc))
>=	Greater than	(attribute1>=1000)
<=	Less than	(attribute1<=1000)
~	Proximity (LDAP server dependent)	(attribute1~=abc)
*	Wildcard	(attr1=ab*) or (attr1=*c) or (attr1=*b*)

Multiple criteria can be connected with logical AND (&) and/or OR operators (|). The logical operators "&" and "|" are placed in front of the criteria. The criterion must be placed in brackets and the whole expression must be bracketed again. AND and OR operations can also be combined.

Examples

AND operation: (&(givenName=*)(mail=*))

Searches for entries in which the first name **and** e-mail address begin with the characters entered by the user.

OR operation: (|(displayName=*)(sn=*))

Searches for entries in which the display name **or** surname begins with the characters entered by the user.

Combined operation: (|(&(displayName=*)(mail=*))(&(sn=*)(mail=*)))

Searches for entries in which the display name **and** e-mail address **or** the surname **and** e-mail address begin with the characters entered by the user.

Special characters

It is also possible to find entries containing special characters. If you want to compare these characters within an attribute string use backslash (\) and a 2-digit hex ASCII code as follows:

Special character	ASCII code
(\28
)	\29
<	\3c
>	\3e
/	\2f
\	\2a

Special character	ASCII code
=	\3d
&	\26
~	\7e
*	\2a
	\7c

Example

(givenName=James \28Jim\29)

will find any entry with givenName attribute's value equal to "James (Jim)"

19.2.2 Name filter

The name filter determines which attributes are used for the search in the LDAP database.

Examples:

- (displayName=%) The attribute **displayName** is used for the search.
The percent sign (%) is replaced with the name or part of the name entered by the user.
If you enter e.g. the character "A", the phone searches the LDAP database for all entries in which the attribute **displayName** begins with "A". If you then enter a "b", it searches for entries in which the **displayName** begins with "Ab".
- (|(cn=%)(sn=%%)) The attributes **cn** or **sn** are used for the search.
If you enter e.g. the character "n", the phone searches the LDAP database for all entries in which the attribute **cn** or **sn** begins with "n". If you then enter an "o", it searches for entries in which the attribute **cn** or **sn** begins with "no".



LDAP does not distinguish between upper and lower case in the search request.

19.2.3 Number filter

The number filter defines which attributes are used in the automatic search for a directory entry. The automatic search is performed when a phone number is entered and in the case of an incoming call with calling line identification. If an entry is found for a phone number, the display shows the name instead of the number.

Entries are only found and displayed if the stored phone number matches the entered phone number exactly.

Examples:

- (homePhone=%) The attribute **homePhone** is used for the search.
The percent sign (%) is replaced with the phone number entered by the user.
If you enter the numbers "1234567" when dialling, the phone searches the LDAP database for entries with the private phone number "1234567".
- (|(telephoneNumber=%)(mobile=%)(homePhone=%%))
The attributes **telephoneNumber**, **mobile** and **homePhone** are used for the search.
If you enter the numbers "1234567" when dialling, the phone searches the LDAP database for entries with the private **or** mobile **or** work number "1234567".

19.3 Attributes

For a directory entry (an object), a series of attributes are defined in the LDAP database, e.g. surname, first name, phone number, address, company etc. The set of all attributes that can be stored for an entry is stored in the schema of the relevant LDAP server. To access attributes or define search filters, you must know the attributes and their names in the LDAP server. Most attribute names are standardised, but there can also be specific ones defined.

Which attributes can actually be displayed on a phone depends on

- which attributes are defined for an entry in the LDAP database,
- which attributes are set in the web configurator for display on the phone,
- which attributes can be displayed on the phone or handset.

19.3.1 Available attributes on handsets or phones

The following table shows the attributes that could be used for a directory entry on a handset or phone. Of course, the set of attributes that are actually shown depends on the specific handset used.

Attributes of a directory entry	Attribute name in the LDAP database
First name	givenName
Surname	sn, cn, displayName
Phone (home)	homePhone, telephoneNumber
Phone (office)	telephoneNumber
Phone (mobile)	mobile
E-mail	mail
Fax	facsimileTelephoneNumber
Company	company, o, ou
Street	street
City	I, postalAddress
Zip	postalCode
Country	friendlyCountryName, c
Additional attribute	can be freely defined

19.3.2 Specifying attributes for display on the phone

In the web configurator (→ p. 101) you specify which of the available attributes from the LDAP database are to be queried and displayed on the phone.

- For each attribute of a directory entry, select the appropriate attribute from the LDAP database. There are predefined settings at choice. Alternatively you can enter manually a different attribute defined in the LDAP database for this field.
- If an attribute is not to be displayed, select the option **none**.

In the **Additional attribute** field, you can enter an additional attribute that is available in the LDAP database and should be displayed. If the attribute is a number to be dialled, the option **Additional attribute can be dialled** must be checked.

The attributes **First name** and **Surname** will be used for the following functions:

- Display in the list of directory entries in the form **Surname, First name**
- Alphabetical sorting of the directory entries on the phone
- Name display of a caller or call participant

If the database query only produces one of the attribute values (e.g. because a contact is only stored with their first name), only this one will be displayed.

19.4 Display on the handsets

If one or more LDAP directories are set up in the web configurator, they will be available on the handsets with the following functions:


- Scroll through directory or search for directory entries,
- Display directory entries with detailed information (no edit or delete),
- Dial phone numbers directly from the directory,
- Add directory entries to the local directory.

When a phone number is entered or a call comes in, the directory is automatically searched for an entry that matches the phone number. If an entry is found, the name is displayed instead of the phone number.

To display the corporate directory on the telephone screen

The corporate directory is assigned to the INT key: ► press 



Depending on the settings for the handset in the web configurator (→ p. 87), you may also be able to access a corporate directory via the directory key .

Some handsets provide access also via the display menu. For details, see the user guide for your phone.

19.4.1 Entries in the directory

The following description shows an example for the display of an LDAP directory on a handset.

The menu shows all directories that have been set up and activated on the **Online directories** page in the web configurator. Each one appears with the name entered under **Directory name** in the web configurator (→ p. 151). In the example on the right, the LDAP directory is shown as **Our Directory**.

► . . . use  to select the directory ► **OK**

The phone initiates a query to the LDAP server defined in the web configurator.

Directories	
Our Directory	
Directory 3	
Directory 4	
Directory 5	
Directory 6	
Back	OK

LDAP directory – configuration example



Display on the handsets

The LDAP directory is displayed according to the following rules:

- The search begins in the directory/subdirectory which is defined as the search base on the LDAP server and specified with the **LDAP Search base (BaseDN)** parameter in the web configurator (→ p. 152).
- The entries are listed in alphabetical order.
- The entries are displayed with **Surname** and **First name** if both attributes are available in the LDAP database. Otherwise only the surname or first name is displayed.

Our Directory	
Albert	
Bond	
Bond, James	
Bond, Paul	
Brown, Charly	
View	Options

19.4.2 Searching the directory

- ▶ Use  to scroll through the directory
- or
- ▶ Use  to enter a name (or the first few letters).



As soon as you press a key on the keypad, the telephone goes into search mode. You can enter up to 15 characters. All entries in the LDAP directory that match your input are displayed.

- ▶ Use  to delete the last character you entered.

The current search string is shown in the top line.

b	br
Bond	Brown, Charly
Bond, James	
Bond, Paul	
Brown, Charly	
<C Options	<C Options

19.4.3 Displaying a directory entry



- ▶ Use  to select the entry you want.
- ▶ Press the display key **View** or the navigation key .
- or
- ▶ Press the display key **Options** ▶ **View**

The directory entry is displayed with its detailed information. Only attributes for which a value is stored are shown (→ p. 153).



- ▶ Use  to scroll through the entry.
- ▶ Press the End call key  or the **Back** display key to close the entry.

Brown, Charly	
Surname:	
Brown	
First Name:	
Charly	
Phone (home):	
1234567890	
▼	
Back	

19.4.4 Dialling a number from the directory

- ▶ Use  to select the entry you want in the directory.
- ▶ Press the Talk key . If only one phone number is stored, it is dialled. If there are several phone numbers, they are displayed in a selection list.

or

- ▶ Use  to select the phone number you want in the detailed view of an entry:
Phone (home), Phone (office) or Phone (mobile).
- ▶ Press the Talk key . The number is dialled.







Brown, Charly
Phone (office):
0987654321
Phone (mobile):
0908987876
Street:
Avenue 12
Back

LDAP directory – configuration example

Display on the handsets

A Appendix

A.1 Safety precautions

Read the safety precautions and the user guide before use.	
	Comprehensive user guides for all telephones and telephone systems as well as for accessories can be found online at www.unify.com in the Support category. We thereby help to save paper while providing fast access to the complete up-to-date documentation at any time.
	Do not use the devices in environments with a potential explosion hazard (e.g. paint shops).
	The devices are not splashproof. For this reason do not install them in a damp environment such as bathrooms or shower rooms.
	Use only the power adapter indicated on the device.
	Use only the cable supplied for LAN connection and connect it to the intended ports only.
	Remove faulty devices from use or have them repaired by our Service team, as these could interfere with other wireless services.
	Using your telephone may affect nearby medical equipment. Be aware of the technical conditions in your particular environment, e.g. doctor's surgery. If you use a medical device (e.g. a pacemaker), please contact the device manufacturer. They will be able to advise you regarding the susceptibility of the device to external sources of high frequency energy (for the specifications of your Unify product see "Specifications" →p. 163).

A.2 Service

Information and support for our products can be found on the Internet at:

<http://www.unify.com/>.

Technical notes, current information about firmware updates, frequently asked questions and lots more can be found on the Internet at:

<http://wiki.unify.com/>.

A.3 Authorisation

The device conforms to the EU directive 1999/5/EC as attested by the CE marking.

A.4 Disposal

All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.



Proper disposal and separate collection of your old appliance will help prevent potential damage to the environment and human health. It is a prerequisite for reuse and recycling of used electrical and electronic equipment.

For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service, the shop where you purchased the product or your sales representative.

The statements quoted above are only fully valid for equipment which is installed and sold in the countries of the European Union and is covered by the directive 2002/96/ EC. Countries outside the European Union may impose other regulations regarding the disposal of electrical and electronic equipment.

B Technical data

B.1 Specifications

B.1.1 Power consumption

Operation as OpenScape Cordless IP V2(DECT manager) < 3.8 W

Operation as OpenScape Cordless IP V2 (base station) < 3.8 W

B.1.2 General specifications

DECT Manager and base stations	
Power over Ethernet	PoE IEEE 802.3af < 6.5 W (Class 2)
LAN interface	RJ45 Ethernet, 10/100 Mbps Protection class IP20
Ambient conditions for operation	+5°C to +45°C indoors; 20% to 75% relative humidity
Protocols	IPv4, SNTP, DHCP, DNS, TCP, UDP, VLAN, HTTP, TLS, SIP, STUN, RTP, MWI, SDP, SRTP
Base stations	
DECT standard	DECT EN 300 175-x
Transmission power	10 mW average power per channel, 250 mW pulse power
No. of channels	120 channels
DECT standard	DECT EN 300 175-x
Radio frequency range	1880–1900 MHz (Europe), 1910-1930 MHz (Latin America), 1910-1920 MHz (Brazil) 1880 MHz - 1895 MHz (South East Asia/Taiwan)
Transmission power	10 mW average power per channel, 250 mW pulse power
No. of channels	120 channels
Number of connections	10 simultaneous connections per base station (G.711), 8 simultaneous connections (G.729), 5 connections in wideband operation (G.722)
Range	Up to 300 m outdoors, up to 50 m indoors
Codec	G.711, G.722, G.729ab
Quality of Service	TOS, DiffServ

Index

- A**
 - Access code 99
 - Access data for LDAP server 151
 - Activating base station 56
 - Additional attributes 156
 - Address of LDAP server 151
 - Alarm server 110
 - AML (Alarming - Messaging - Location) 110
 - AND operator 154
 - Answer machine, playing back messages 149
 - Antennas
 - aligning 15
 - mounting 15
 - third-party 15
 - Application server 110
 - Area code
 - local 100
 - prefix 100
 - Area codes 99
 - Attribute 156
 - c 156
 - cn 156
 - company 156
 - displayName 156
 - facsimileTelephoneNumber 156
 - friendlyCountryName 156
 - givenName 156
 - homePhone 156
 - I 156
 - mail 156
 - mobile 156
 - o 156
 - ou 156
 - postalAddress 156
 - postalCode 156
 - sn 156
 - street 156
 - telephoneNumber 156
 - user-defined 156
 - Attributes
 - defining for display 156
 - in LDAP database 156
 - Audio quality 97
 - Authentication code for handset registration 85
 - Automatic backup 124
 - Automatic search 157
- B**
 - Backup
 - automatic 124
 - Base station 8, 12
 - activating 56
 - administration 51
 - assign to a DECT manager 53
 - belonging cluster 68
 - connected 52
 - deleting 56
 - firmware 52
 - IP address type 55
 - LED display for operational states 23
 - LED display for synchronisation status 23
 - LED display, DECT traffic 23
 - MAC address 52
 - name 52
 - number 131
 - organising clusters 56
 - pending 53
 - rebooting 56
 - resetting 24
 - responsible DECT manager 52
 - sync level 68
 - synchronisation status 52, 68
 - Base stations
 - synchronised 68
 - synchronising 56
- C**
 - Call
 - external 143
 - Call list
 - dialling 144
 - Call manger, accepting call directly 90
 - Call on hold settings 78
 - Call swapping
 - two external calls 146
 - Call transfer settings 98
 - Call waiting, external
 - accepting/rejecting 145
 - Calling
 - external 143
 - Calling party information 78
 - Certificate 96
 - Certificates 119
 - CLI (Command Line Interface) 114

- CLI access to the device configuration 114
- Cluster 9, 68
 - configuring 56
- cn, attribute 156
- Codecs 76
- Column
 - displaying/hiding 39, 136
- Communication system 8
- company, attribute 156
- Conference 146
- Conference call
 - end 146
 - two external calls 146
- Connected base stations 52
- Connecting the PC to the web configurator 27
- Connecting to the LAN 19
- Connection name 71
- Consultation call
 - ending 145
- Consumption of electricity, see Power consumption
- Customer Care 161

D

- Database access 151
- Date
 - synchronisation 122
- Date, setting 121
- DECT base station 8, 12
- DECT integrator 7, 10
- DECT level 68
- DECT manager 7
 - adding 39
 - administration 37
 - capacity 38, 40
 - configuration 37
 - identifier 39
 - LED display DECT traffic 24
 - number 131
 - reboot 41
 - registering at the Integrator 45
 - reseting 24
 - synchronisation 47
- DECT network 9
- DECT registration state
 - handset 82
- DECT traffic
 - base station 23
 - DECT manager 24
- Deployments 10
- Device role 20
 - setting 20

- DHCP server 34
- Diagnostics 140
- Dialling
 - from the call list 144
 - from the redial list 143
- DiffServ (Differentiated Services) 97
- Directory
 - accessing 147
 - attributes 156
 - configuring 101
 - configuring handset access 87
 - displaying attributes 156
 - opening 157
 - searching 158
 - using 147
- Directory entry
 - searching 158
- Direectory
 - name 151
- Display name
 - handset 82
- displayName, attribute 156
- DM zone 9
- DNS (Domain Name System) 34
- DNS redundancy method 74
- Domain name 151
- Domain part of the user address 71
- Download log files 136
- Dump 140
- Dynamic IP address
 - base station 55

E

- Embedded integrator 12
- Entering the number
 - of the network mailbox 149
- Environment 162

F

- facsimileTelephoneNumber, attribute 156
- Factory settings see Reset 21, 22
- Failed registration retry timer 96
- Filter 153
 - criteria 154
 - format 154
 - name 155
 - number 155
- Firmware
 - base station 52
 - current version 123
 - handset 82
 - update 122

Index

- Firmware update
 - LED display 23
 - scheduled 123
- friendlyCountryName, attribute 156

G

- G.711 77
- G.722 77
- G.729A 77
- givenName, attribute 156
- Group pick-up 89

H

- Handover 9
- Handset 8, 12
 - belonging DECT manager 82
 - configuring mailbox access 89
 - DECT registration state 82
 - de-registering 86
 - directory assignment 87
 - display name 82
 - Firmware 82
 - LDAP authentication 88
 - menu 143
 - MWI settings 90
 - PIN for DECT registration 85
 - registering 81, 84
 - registration centre 92
 - settings 86
 - time-controlled registration 92
 - type 82
 - user name 81
 - VoIP account registration data 86
- Handsets
 - administration 81
 - registered 81
- Help function, web configurator 29
- homePhone, attribute 156
- HTTP authentication 120

I

- Installation
 - large 11
 - medium 11
 - small 10
- Installing 18
 - Integrator 20
- INT key 147
 - assigning directory 88
- Integrator 7, 10
 - embedded 12
 - installation 20

- status 131
- virtual 12
- IP Address
 - IPv4 34, 55
- IP address of LDAP server 151
- IP address type 34
 - base station 55
- IP configuration 33
- IPUI (International Portable User Identity) 81
- IPv4 34

L

- LAN master 68
- LAN master/slave 58
- LAN port 19
- LAN synchronisation 58
 - advantages 58
 - quality 133
- Large installation 11
- LDAP attributes 156
- LDAP authentication for handset 88
- LDAP filter see Filter
- LDAP name 101
- LDAP search base 152
- LDAP server
 - address 151
 - domain name 151
 - IP address 151
 - port 151
 - User ID 151
- LDAP server, URL 101
- LEDs 23
- List
 - filtering 39
 - sorting 39
- Local area code 100
- Local network 33
- Log file
 - download 136
- Log level 138
- Logical operators see Operator

M

- MAC address, base station 52
- mail, attribute 156
- Mailbox configuration 89
- Making calls
 - external 143
- Medical equipment 161
- Medium installation 11
- Menu overview
 - handsets 143

- MIB (Management Information Base) 43
- Migration 141
- Mobile devices
 - number 131
- mobile, attribute 156
- Multicell system 7
- MWI settings 90

N

- Name filter 153, 155
- Network mailbox
 - entering number 149
- Network MB, see Network mailbox
- Network protocol 34
- Non-SRTP calls, accepting 74
- Number filter 153, 155

O

- OpenScape Cordless IPV2 DECT
 - multicell system 7
- Operator
 - AND 154
 - OR 154
- OR operator 154
- ou, attribute 156
- Outbound proxy mode 75
- Outbound proxy port 75
- Outbound server address 75
- Overload balancing 9

P

- Package content 17
- P-Asserted-Identity (PAI) 78
- Password 151
- Password, web configurator 28
 - changing 113
- PBX access code 99
- PBX profile 71
- PCMA/ PCMU 77
- Pending base stations 53
- Phone number
 - dialling 159
- Phone number in directory 156
- Phonebook, central
 - backup 109
 - deleting 109
- Place holder for user input 154
- PoE (Power over Ethernet) 20
- Port 151
- postalAddress, attribut 156
- postalCode, attribute 156
- Power adapter 161

- Power consumption 163
- P-Preferred-Identity (PPI) 78
- PRACK (Provisional Response Acknowledgement) 96
- Priority of voice data 97
- Profile 118
- Profile, VoIP provider/PBX 72
- Provider profile 71
- Provisioning server 118
- Proxy server
 - address 73
 - port 73

Q

- QoS (Quality of Service) 97

R

- Reboot
 - base station 56
 - LED display 23
 - manually 41
- Redial list 143
- Registering a set of handsets 84
- Registering DECT managers at the Integrator 45
- Registering handsets 81, 84
 - time-controlled 92
- Registering, with web configurator 28
- Registration centre 91
- Registration refresh time 73
- Reset
 - to factory settings 24
 - using the device button 22
 - via power procedure 24
- Restore configuration 124
- RFPI 47
- Ringback
 - switching function off if busy 144
 - when the number is busy 144
- Roaming 9
- RPN 52
- RPN group 40
- RTP (Realtime Transport Protocol) 97
- RTP packetisation time (ptime) 78

S

- Safety precautions 161
- Save configuration 124
- SDP (Session Description Protocol) 78
- Search base 152
- Search mode 158
- Search start point 152
- Secure Real Time Protocol 74

Index

- Secure Shell (SSH) 114
- SFTP (Secure File Transfer Protocol) 124
- SIP port 95
- SIP redundancy 74
- SIP server port 74
- SIP session timer 96
- SIP timer T1 96
- Small installation 10
- sn, attribute 156
- SNMP (Simple Network Management Protocol) 43
- SNMP configuration 139
- SNMP manager 43
- Specifications 163
- SRTP options 73
- Standard gateway 34
- street, attribut 156
- Subnet mask 34
- Subscription timer 96
- Sync level 57, 68
- Sync master/slave 57
- Sync reference 68
- Sync slave 68
- Synchronisation 56
 - best base of DM 47
 - cross-cluster 47
 - DECT manager 47
 - external with RFPI 47
 - over LAN 56
 - over the air 56, 57
 - via LAN 58
- Synchronisation example
 - large, DECT-DECT-DECT 63
 - large, DECT-DECT-LAN 64
 - large, LAN-PTP domain-LAN 66
 - small/medium, DECT-LAN mixed 62
 - small/medium, pure DECT 61
 - small/medium, pure LAN 62
- Synchronisation hierarchy 57
- Synchronisation planning 56
- Synchronisation status
 - base station 23, 52, 68
- SysLog 42, 137
- System backup 132
- System configuration 27
- System report (SysLog) 42, 137

T

- Telephone system
 - overview 7
 - preparing to use 17
- telephoneNumber, attribute 156
- Time

- synchronisation 122
 - zone 121
- Time server 121
- Time, setting 121
- Timer
 - failed registration retry 96
 - SIP session 96
 - SIP timer T! 96
 - subscription 96
- Tone scheme 100
- Transport protocol 73
- TX power, reduce 55

U

- Update 122
- user ID 151
- User input, place holder 154
- User name
 - handset 81
 - web configurator 28

V

- Virtual integrator 12
- Virtual machine 20
- Voice quality 97
- VoIP provider, configure profile 72

W

- Wall mounting 22
- Web configurator
 - applying/discarding changes 29
 - changing password 113
 - connecting with PC 27
 - logging in 28
 - logging off 28
 - online help function 29
 - password 28
 - starting 27
 - working with lists 30