



Battery Pack Charger OpenScape WLAN Phone WL4/WL4 Plus

Installation Guide

A31003-M2000-J106-01-7631

Provide feedback to further optimize this document to edoku@atos.net

As reseller please address further presales related questions to the responsible presales organization at Unify or at your distributor. For specific technical inquiries you may use the support knowledgebase, raise - if a software support contract is in place - a ticket via our partner portal or contact your distributor.

Our Quality and Environmental Management Systems are implemented according to the requirements of the ISO9001 and ISO14001 standards and are certified by an external certification company.

Contents

1 Introduction.....	4
1.1 Safety.....	4
1.2 Regulatory Compliance Statements (EU/EFTA only).....	5
1.3 Labeling.....	5
1.4 Regulatory Compliance Statements (USA/Canada only).....	5
2 Installation.....	7
2.1 Mounting.....	7
2.1.1 Remove the Top Cover.....	8
2.2 Electrical Installation.....	8
2.2.1 Install Single Unit.....	9
2.2.2 Install Multiple Units.....	9
2.3 Charging.....	13
2.4 Battery Disconnection.....	13
3 Troubleshooting.....	14

Introduction

This document describes how to install and operate the Battery Pack Charger.
Each Battery Pack Charger charges six batteries simultaneously.




Figure 1: The Battery Pack Charger

Supply voltage:	100-240VAC/0.7A 50/60 Hz
Building fuse for fixed installation:	10 A max.

Single Unit

The Battery Pack Charger can be installed as a single unit.

Multiple Units

A number of Battery Pack Chargers and Charging Racks may be connected together. Maximum five units may be connected. An installation with multiple units requires a fixed electrical installation.



In the USA and Canada the Battery Pack Charger must only be installed as a single unit. Connection of several units is not permitted.

Safety

- It is not allowed to supply more than one unit by the power cord with the C14 connector.
- The safety covers on top of the supply voltage terminal blocks must be mounted to prevent hazardous situations, like electric shock.
- When servicing the unit, the power cord must be disconnected.
- For permanently connected equipment, a readily accessible disconnect device shall be incorporated in the building installation wiring. The disconnect device shall disconnect both poles.

- For pluggable equipment, the wall outlet shall be installed near the equipment and shall be easily accessible.

In Sweden, Norway and Finland the unit must be connected to protective earth (safety grounding). For other countries it is recommended to use a protective earth connection.

- Suomi: Laite on liitettävä suojamaadoituskoskettimilla varustettuun pistorasiaan.
- Norge: Apparatet må tilkoples jordet stikkontakt.
- Sverige: Apparaten skall anslutas till jordat uttag.

Regulatory Compliance Statements (EU/EFTA only)

This equipment is intended to be used in the whole EU & EFTA.

This equipment is in compliance with the essential requirements and other relevant provisions of Low Voltage Directive (LVD) 2014/35/EU and the EC Council Directive 2011/65/EU on the restriction of the use of certain hazardous substances (RoHS). The Declaration of Conformity may be consulted at: https://wiki.unify.com/wiki/Declarations_of_Conformity

Labeling



The compliance of the equipment according to EU directives is confirmed by the CE mark. This Declaration of Conformity and, where applicable, other existing declarations of conformity as well as further information on regulations that restrict the usage of substances or affect the declaration of substances used in products can be found in the Unify Expert WIKI at <http://wiki.unify.com> under the section "Declarations of Conformity".

Regulatory Compliance Statements (USA/Canada only)

FCC Compliance Statements for USA

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC Requirements for Canada

CAN ICES-3 (B)/NMB-3(B)

Modifications

Changes or modifications to the equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Installation

- A fixed electrical installation must be done by an authorized electrician.
- Maximum five units may be connected in a fixed electrical installation.
- The unit shall be placed in a dry environment with a temperature range from +5° C to + 40° C (41° F to 104° F).
- The unit shall be mounted to a vertical wall.
- The unit shall be mounted to concrete or plaster walls only.
- Avoid mounting the unit in a sunlit place. This can affect the charging capacity.

Delivery Includes

- Battery Pack Charger
- Power cord including IEC C14 connector (male)
- Inlet accessory kit, including cable support holders and screws

A suitable extension cord is needed to connect a single unit to a wall outlet, unless the C14 connector is replaced (by an electrician). The following item can be ordered from Siemens Enterprise Communications GmbH & Co. KG:

Item	Item Number
EU cord	L30280-Z600-F105
UK cord	L30280-Z600-F102
SWZ cord	L30280-Z600-F103
US cord	L30280-Z600-F101

Required Tools etc.

- Screwdrivers
- Cutting pliers
- Multimeter
- Screws and wall plugs for wall mounting.

Make sure the screws and wall plugs have the correct length for the type of wall used.

Wall material	Plug length	Screw diameter
Single plasterboard	Thorsman TP1	3.5 – 5 mm
Double plasterboard	Thorsman TP2	3.5 – 5 mm
Concrete	Thorsman TP2	3.5 – 5 mm

Mounting

- 1) First, make an outline of how the units are to be placed.
- 2) If several Battery Pack Chargers (or Charging Racks) are to be mounted close to each other, mount them so that there is enough space between them to be able to disconnect the batteries or the handsets (vertical distance) and to be able to open the top cover (horizontal distance).

When you are planning the location of the units, start to mount them in a height that makes it easy to reach the batteries.

- 3) Measure and mark the drill holes by using the dimensions in [Figure 2](#).
- 4) Drill and fasten the unit to the wall with four screws.




Figure 2: Mounting dimensions in mm - Charging Rack seen from back

Remove the Top Cover

Remove the top cover by first pressing on the sides of the top cover, then lifting it upwards.




Figure 3: Removing the top cover

Electrical Installation

Install Single Unit



It is not allowed to supply more than one unit by the power cord with the C14 connector.




Figure 4: IEC C14 connector and extension cord with IEC C13 connector

Test Installation

- 1) Connect the power cord to the wall outlet.
- 2) Place a battery in the charging slot.
- 3) A yellow LED indicates that charging starts while a green LED indicates a fully charged battery.

Install Multiple Units



Maximum five units may be connected in a fixed electrical installation.

Any of the two terminal blocks can be used for AC input. The other is then used to connect the next unit.




Figure 5: Units mounted and connected in a fixed installation (example)

Install First Unit

To install the first unit:

- 1) Remove the C14 connector from the power cord.
- 2) Measure, cut and strip the power cord.
- 3) Connect the power cord to the disconnect device.

The IEC color code is used in the power cord supplied.

Wiring color codes:

IEC	US	Old ¹	Load	Also called
Brown	Black	Red	Active	Line, Hot
Blue	White	Black	Neutral	Return, Cold, Grounded connector
Gr/Ye ²	Green	Green	Earth	Ground, Safety Earth, Earth Ground, Grounding conductor ³

Install Additional Unit

- 1) Mount the additional unit to the wall.
- 2) Remove the top cover from the previous unit.

¹ The “Old” standard was used in various countries (including Australia), and some wiring may still use these colours.

² Gr/Ye - Green with Yellow stripe - this is the standard world wide, although it is not common in the US or Canada at present.

³ There is an important distinction between “Grounding conductor” (safety earth) and “Grounded conductor” (Neutral). These are US terms for the conductors and they are not interchangeable, despite the similarity of the names !

- 3) Remove the safety cover from the unused terminal block.




Figure 6: Remove safety cover

- 4) Mount the cable support holder at the unused opening on the previous unit. The cable support holder is provided in the parts bag.




Figure 7: Remove safety cover

- 5) Remove the C14 connector from the additional unit.

- 6) Cut and strip the power cord to the length required.
- 7) Run the power cord through the cable support holder of the previous unit.
- 8) Connect the power cord of the additional unit to the unused terminal block in the previous unit.



Note the embossed markings L, earth symbol and N.




Figure 8: Terminal block for power cord

- 9) Secure the power cord with two screws, which are provided in the parts bag.




Figure 9: Securing the power cord

- 10) Mount the safety cover and fasten it with one screw.
- 11) Replace the top cover.
- 12) Fasten the power cord to the wall depending on local regulations.
- 13) Repeat the same steps to install additional units.

Test Installation

- 1) When the fixed installation is completed, apply AC power by switching on the disconnect device.
- 2) Place a battery in the charging slot.
- 3) A yellow LED indicates that charging starts while a green LED indicates a fully charged battery.

Operation

When the charger is connected to external power supply, normal operation is done as follows:

Charging

- 1) Connect the charger to the AC power supply.
- 2) Place a battery in the charging slot to start charging. Secure the battery by moving the lock switch.

Battery Disconnection

- 1) Unlock the lock switch on the battery.
- 2) Remove the battery by lifting it.

Troubleshooting

Fault	Solution
Charging does not start	Check that the battery is properly inserted in the charger. Check the AC power supply connection.